



Monitor Performance

Performance monitoring (PM) parameters are used by service providers to gather, store, set thresholds for, and report performance data for early detection of network issues. You can configure and retrieve PM counters for the various controllers in flex-bin, 30-second, 15-minute, or 24-hour intervals. These parameters simplify troubleshooting operations and enhance data that can be collected directly from the equipment.

- [Monitor performance, on page 1](#)
- [Photodiodes \(PDs\) refresh rate, on page 6](#)
- [Configure and view PM parameters, on page 7](#)
- [7-day support for 15-Min PM bin, on page 16](#)

Monitor performance

You can set and retrieve PM counters for the OTS, OTS-OCH, OSC, DFB, OCH, and OMS controllers for various intervals.

The OCH and OMS controllers are created when the Mux/Demux panel and breakout panels are powered up using the USB 2.0 connection from the NCS 1010 EITU card. You can only view the current and historical PM parameters for the panels. You cannot configure the PM parameters for these controllers.

This table lists the PM parameters, their descriptions, and precision levels.

Table 1: PM parameters for controllers

PM parameter (Unit of Measure)	Description	Resolution
OPT [dBm]	Total Tx(C+OSC) power	1/100
OPR [dBm]	Total Rx(C+OSC) power	1/100
OPT(C+L) [dBm]	Total Tx(C+L+OSC) power	1/100
OPR(C+L) [dBm]	Total Rx(C+L+OSC) power	1/100
OPR(S) [dBm]	C Band Received Signal Power	1/100
OPT(S) [dBm]	C Band Transmitted Signal Power	1/100
OPBR [dBm]	Back Reflection Power	1/100

EAGN [dB]	Egress Amplifier Gain	1/100
EATL [dB]	Egress Amplifier Tilt	1/100
IAGN [dB]	Ingress Amplifier Gain	1/100
IATL [dB]	Ingress Amplifier Tilt	1/100
RAMAN-TOT [mW]	Raman Total Pump power	1/10
RAMAN-1 [mW]	Raman 1 Pump power	1/10
RAMAN-2 [mW]	Raman 2 Pump power	1/10
RAMAN-3 [mW]	Raman 3 Pump power	1/10
RAMAN-4 [mW]	Raman 4 Pump power	1/10
RAMAN-5 [mW]	Raman 5 Pump power	1/10

The tables list the maximum and minimum thresholds that can be set for the PM parameters for OLT nodes

Table 2: PM thresholds for OLT OTS controller (0/0/0/0)

PM parameter	Minimum threshold	Maximum threshold
OPT	-2000	4000
OPR	-3000	1800
OPT(C+L)	-2000	6085
OPR(C+L)	-3000	3600
OPR(S)	-3000	1800
OPT(S)	-500	2800
OPBR	-3000	-1400
EAGN	1390	3100
EATL	-500	500
IAGN	1030	3800
IATL	-500	500
RAMAN-TOT	2000	14100
RAMAN-1	450	3900
RAMAN-2	400	3900
RAMAN-3	400	2200

RAMAN-4	400	2200
RAMAN-5	350	1900

Table 3: PM thresholds for OLT OTS controller (0/0/0/2 and 0/0/0/3)

PM parameter	Minimum threshold	Maximum threshold
OPT	-3000	1500
OPR	-2500	1800
IAGN	1300	1900
IATL	-500	500

Table 4: PM thresholds for OLT OTS controller (0/0/0/4 to 0/0/0/33)

PM parameter	Minimum threshold	Maximum threshold
OPT	-3000	1500
OPR	-1500	1000

Table 5: PM thresholds for OLT OTS-OCH controller

PM parameter	Minimum threshold	Maximum threshold
OPT	-3000	1500
OPR	-3000	1500

Table 6: PM Thresholds for OLT OSC controller (0/0/0/0)

Parameter	Minimum threshold	Maximum threshold
OPT	-2000	1200
OPR	-3000	0

Table 7: PM thresholds for OLT DFB controller (0/0/0/0)

PM Parameter	Minimum Threshold	MaximumThreshold
OPT	-2000	1000
OPR	-3000	1500

The tables list the maximum and minimum thresholds that can be set for the PM parameters for ILA nodes.

Table 8: PM thresholds for ILA OTS controller (0/0/0/0)

PM Parameter	Minimum Threshold	Maximum Threshold
OPT	-3000	4000
OPR	-3000	2000
OPT(C+L)	-3000	6085
OPR(C+L)	-3000	4000
OPR(S)	-3000	2800
OPT(S)	-3000	2000
OPBR	-3000	-1400
EAGN	590	3600
EATL	-500	500
RAMAN-TOT	2000	14100
RAMAN-1	450	3900
RAMAN-2	400	3900
RAMAN-3	400	2200
RAMAN-4	400	2200
RAMAN-5	350	1900

Table 9: PM thresholds for ILA OTS controller (0/0/0/2)

PM Parameter	Minimum Threshold	Maximum Threshold
OPT	-3000	4000
OPR	-3000	2000
OPT(C+L)	-3000	6085
OPR(C+L)	-3000	4000
OPR(S)	-3000	2800
OPT(S)	-3000	2000
OPBR	-3000	-1400
EAGN	590	3600
EATL	-500	500

RAMAN-TOT	2000	14100
RAMAN-1	450	3900
RAMAN-2	400	3900
RAMAN-3	400	2200
RAMAN-4	400	2200
RAMAN-5	350	1900

Table 10: PM thresholds for ILA OSC controller (0/0/0/0 and 0/0/0/2)

PM Parameter	Minimum Threshold	Maximum Threshold
OPT	-2000	1200
OPR	-3000	0

Table 11: PM thresholds for ILA OTS-OCH controllers

PM Parameter	Minimum Threshold	Maximum Threshold
OPT	-3000	1500
OPR	-3000	1500

Table 12: PM thresholds for ILA DFB controllers (0/0/0/0 and 0/0/0/2)

PM Parameter	Minimum Threshold	Maximum Threshold
OPT	-2000	1000
OPR	-3000	1500

This table lists the maximum and minimum thresholds that are set for the PM parameters for OCH controllers.

Table 13: PM thresholds for OCH controllers

PM Parameter	Minimum Threshold	Maximum Threshold
OPT	-30	15
OPR	-30	15

This table lists the maximum and minimum thresholds that are set for the PM parameters for OMS controllers.

Table 14: PM thresholds for OMS controllers

PM Parameter	Minimum Threshold	Maximum Threshold
OPT	-30	15

PM Parameter	Minimum Threshold	Maximum Threshold
OPR	-30	15

Photodiodes (PDs) refresh rate

Table 15: Feature History

Feature Name	Release Information	Feature Description
Improved Performance Monitoring	Cisco IOS XR Release 7.11.1	NCS 1010 now measures the power values of Photo Diodes (PDs) at various measurement points at a faster refresh rate to improve the node performance monitoring. With the upgraded FPDs, the refresh rate has reduced from 250 ms to 50 ms. This faster refresh rate applies to all the NCS 1010 PIDs for the following line card FPDs: <ul style="list-style-type: none"> • ILA • OLT • Raman-1 • Raman-2

NCS 1010 measures the power values of Photo Diodes (PDs) at various measurement points to provide values for PM parameters. The measured values are refreshed at a defined rate for the latest values.

From Release 7.11.1, the rate at which the values of specific PDs are refreshed is reduced from 250 ms to 50 ms. This faster refresh rate is applicable to all the NCS 1010 OLT and ILA PIDs.

The following table provides the list of photo diodes that support the new refresh rate of 50 ms.

Table 16: Line cards and impacted PDs

Line cards	PDs
OLT-C	PD1, PD9, PD14, PD20
OLT-L	PD1, PD9, PD11, PD15
ILA-C	PD1, PD3, PD5, PD7, PD13, PD14, PD21, PD22
ILA-L	PD1, PD3, PD5, PD7, PD9, PD10, PD17, PD18
OLT and ILA cards with RAMAN	PD2, PD7

In the OLT-C card, the newer refresh rate impacts the following PM parameters and controllers.

Photo diode	controller	PM parameter
PD1	OTS	OPR-S
PD9	OSC	OPR

Photo diode	controller	PM parameter
PD9	OTS	OPR
PD14	OTS	OPT-S
PD20	OSC	OPT
PD20	OTS	OPT

In the ILA-C card, the newer refresh rate impacts the following PM parameters and controllers.

Photo Ddodes	controller	PM parameter
PD1, PD3	OTS	OPR-S
PD5, PD7	OSC	OPR
PD13, PD14	OTS	OPT-S
PD21, PD22	OSC	OPT

Configure and view PM parameters

You can configure the performance monitoring parameters for the controllers. To configure PM parameters, use these commands in the configuration mode:

Table 17: Feature history

Feature Name	Release Information	Feature Description
Threshold Crossing Alert (TCA) for Span Loss	Cisco IOS XR Release 7.11.1	<p>You can now activate TCA reporting and set specific minimum and maximum threshold values for both Tx and Rx span loss across all time intervals.</p> <p>This enhancement provides prompt notifications for deviations from normal span loss values, which can be viewed using the show alarms brief system active command.</p> <p>To implement this feature, two new parameters slr-cl and slt-cl have been introduced for the pm command.</p> <p>Additionally, the output of the show controllers ots R/S/I/P pm command now captures both the actual and configured threshold values for span loss.</p>

Table 18: Feature History

Feature Name	Release Information	Feature Description
PM History Persistence	Cisco IOS XR Release 7.11.1	<p>PM history parameters for Optics, Ethernet, and coherent DSP controllers are now retained even after the occurrence of an operation disruptive event like:</p> <ul style="list-style-type: none"> • Various reloads • Power cycle • System upgrade <p>This functionality maintains prolonged access to performance history for extended device health monitoring and assessment</p>

```
controller controllertype R/S/I/P { pm { 15-min | 24-hour | 30-sec | flex-bin } { optics | ots } { report |
threshold } { opr | opt | eagn | eatl | iagn | iatl | slr-cl | slt-cl | opbr | opr | opr-cl | opr-s | opt | opt-cl |
opt-s | raman-1 | raman-2 | raman-3 | raman-4 | raman-5 | raman-tot } { max-tca | min-tca } { enable |
value }
```

Examples

The following example enables the maximum and minimum Threshold Crossing Alert (TCA) reporting on the OTS controller for a 15 minute interval on a C+L band network. The sample also configures the maximum and minimum Rx span loss threshold to 36db and 33db respectively. These values are compared against the current maximum span loss value to determine if a TCA should be generated.

```
RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller pts 0/0/0/0 pm 15-min ots report slr-cl max-tca enable
RP/0/RP0/CPU0:ios(config)#controller pts 0/0/0/0 pm 15-min ots threshold slr-cl max 3600
RP/0/RP0/CPU0:ios(config)#controller pts 0/0/0/0 pm 15-min ots report slr-cl min-tca enable
RP/0/RP0/CPU0:ios(config)#controller pts 0/0/0/0 pm 15-min ots threshold slr-cl min 3300
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
```

The following example shows the TOT-SPAN-LOSS-TX-CL-MAX alert is triggered when the current TX span loss value exceeds the maximum TX span loss threshold:

```
RP/0/RP0/CPU0:P1D_DT_04#show alarms brief system conditions | include SPAN
Thu Oct 5 04:49:21.462 UTC
0/0          NotAlarmed  Controller      10/05/2023 04:49:00 UTC  Ots0/0/0/0 -
Threshold Crossing Alert For TOT-SPAN-LOSS-TX-CL-MAX In 30 Second Bucket
```

The following example sets the reporting status to maximum TCA for the eagn parameter of the OTS controller for a 15-minute interval.

```
RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller ots 0/0/0/0 pm 15-min ots report eagn max-tca enable
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
```

The following example configures the maximum threshold for the eagn parameter of the OTS controller to 20 dB.



Note The OTS controller commands accept PM parameter values in two decimal places. In this example, the *eagn* parameter is entered as *2000* to configure the *eagn* parameter to *20 dB*.

```
RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller ots 0/0/0/0 pm 15-min ots threshold eagn max 2000
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
```

To view the current PM parameters on an OTS controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers ots 0/0/0/0 pm current 15-min optics 1
```

The following output shows the current PM parameters on an OTS controller for a 15-minute interval and highlights the *maximum threshold* set for the *eagn* parameter that is configured for *20 dB*.

```
Tue May 17 06:37:00.529 UTC

Optics in the current interval [06:30:00 - 06:37:00 Tue May 17 2022]

Optics current bucket type : Valid
Configured  TCA
MIN          AVG          MAX          Operational  Configured  TCA  Operational
Threshold(max) Threshold(max(max)
OPT[dBm]      : 20.00    20.00    20.00    -20.00    NA    NO    40.00    NA
```

```

NO
OPR [dBm] : 20.00 20.00 20.00 -30.00 NA NO 18.00 NA
NO
OPT (C+L) [dBm] : 20.00 20.00 20.00 -20.00 NA NO 60.85 NA
NO
OPR (C+L) [dBm] : -10.00 -10.00 -10.00 -30.00 NA NO 36.00 NA
NO
OPT (S) [dBm] : 20.00 20.00 20.00 -5.00 NA NO 28.00 NA
NO
OPR (S) [dBm] : 20.00 20.00 20.00 -30.00 NA NO 18.00 NA
NO
OPBR [dBm] : -30.00 -30.00 -30.00 -30.00 NA NO -14.09 NA
NO
EAGN [dB] : 30.00 30.00 30.00 16.00 NA NO 20.00 20.00
YES
EATL [dB] : -4.80 -4.80 -4.80 -5.00 NA NO 5.00 NA
NO
IAGN [dB] : 25.00 25.00 25.00 12.00 NA NO 25.00 NA
NO
IATL [dB] : -2.40 -2.40 -2.40 -5.00 NA NO 5.00 NA
NO
RAMAN-TOT [mW] : 300.00 300.00 300.00 200.00 NA NO 1410.00 NA
NO
RAMAN-1 [mW] : 45.00 45.00 45.00 45.00 NA NO 390.00 NA
NO
RAMAN-2 [mW] : 40.00 40.00 40.00 40.00 NA NO 390.00 NA
NO
RAMAN-3 [mW] : 40.00 40.00 40.00 40.00 NA NO 220.00 NA
NO
RAMAN-4 [mW] : 40.00 40.00 40.00 40.00 NA NO 220.00 NA
NO
RAMAN-5 [mW] : 35.00 35.00 35.00 35.00 NA NO 190.00 NA
NO

```

Last clearing of "show controllers OPTICS" counters never

To view the historical PM parameters on an OTS controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers ots 0/0/0/0 pm history 15-min optics 1 bucket 1
```

The following output shows the historical PM parameters on an OTS controller for a 15-minute interval.

Tue May 17 07:02:26.911 UTC

Optics in interval 1 [06:45:00 - 07:00:00 Tue May 17 2022]

Optics history bucket type : Valid

```

MIN AVG MAX
OPT [dBm] : 20.00 20.00 20.00
OPR [dBm] : 20.00 20.00 20.00
OPT (C+L) [dBm] : 20.00 20.00 20.00
OPR (C+L) [dBm] : -10.00 -10.00 -10.00
OPT (S) [dBm] : 20.00 20.00 20.00
OPR (S) [dBm] : 20.00 20.00 20.00
OPBR [dBm] : -30.00 -30.00 -30.00
EAGN [dB] : 30.00 30.00 30.00
EATL [dB] : -4.80 -4.80 -4.80
IAGN [dB] : 25.00 25.00 25.00
IATL [dB] : -2.40 -2.40 -2.40
RAMAN-TOT [mW] : 300.00 300.00 300.00
RAMAN-1 [mW] : 45.00 45.00 45.00
RAMAN-2 [mW] : 40.00 40.00 40.00
RAMAN-3 [mW] : 40.00 40.00 40.00

```

```
RAMAN-4 [mW] : 40.00    40.00    40.00
RAMAN-1 [mW] : 35.00    35.00    35.00
```

To view the current PM parameters on an OTS-OCH controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers ots-och 0/0/0/1 pm current 15-min optics 1
```

The following output shows the current PM parameters on an OTS-OCH controller for a 15-minute interval.

```
Tue May 17 10:27:20.387 UTC

Optics in the current interval [10:15:00 - 10:27:20 Tue May 17 2022]

Optics current bucket type : Valid
      MIN  AVG  MAX  Operational  Configured  TCA  Operational  Configured
      TCA
      Threshold(min)  Threshold(min)  (min)  Threshold(max)
Threshold(max) (max)
OPT[dBm] : 1.20 1.30  1.30  -30.00      NA          NO          15.00
NA      NO
OPR[dBm] : -12.31-12.25-12.20  -30.00      NA          NO          15.00
NA      NO
Last clearing of "show controllers OPTICS" counters never
```

To view the current PM parameters on an OSC controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controller osc 0/0/0/0 pm current 15-min optics 1
```

The following output shows the current PM parameters on an OSC controller for a 15-minute interval.

```
Tue May 17 08:24:32.642 UTC

Optics in the current interval [08:15:00 - 08:24:32 Tue May 17 2022]

Optics current bucket type : Valid
      MIN  AVG  MAX  Operational  Configured  TCA  Operational
      Configured  TCA
      Threshold(min)  Threshold(min)  (min)
Threshold(max) Threshold(max) (max)
OPT[dBm] : -10.00 -10.00 -10.00 -20.00      NA          NO  12.00
NA      NO
OPR[dBm] : -30.00 -30.00 -30.00 -30.00      NA          NO  0.00
NA      NO
Last clearing of "show controllers OPTICS" counters never
```

To view the current PM parameters on a DFB controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controller dfb 0/0/0/0 pm current 15-min optics 1
```

The following output shows the current PM parameters on a DFB controller for a 15-minute interval.

```
Tue May 17 08:28:37.455 UTC

Optics in the current interval [08:15:00 - 08:28:37 Tue May 17 2022]

Optics current bucket type : Valid
      MIN  AVG  MAX  Operational  Configured  TCA  Operational  Configured  TCA
      Threshold  Threshold  Threshold  Threshold  Threshold  Threshold  Threshold  Threshold
      (min)      (min)      (min)      (max)      (max)      (max)      (max)      (max)
OPT[dBm]: 20.00 20.00 20.00  -25.23    NA          NO  18.00      NA          NO
OPR[dBm]: 10.00 10.00 10.00  -30.00    NA          NO  12.00      NA          NO
Last clearing of "show controllers OPTICS" counters never
```

To view the current PM parameters for an OCH controller for a 30-second interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm current 30-sec optics 1
```

The following output shows the current PM parameters for an OCH controller for a 30-second interval.

```
Tue May 10 11:28:29.896 UTC
```

```
Optics in the current interval [11:28:00 - 11:28:29 Tue May 10 2022]
```

```
Optics current bucket type : Valid
```

	MIN	AVG	MAX	Operational	Configured	TCA	Operational
	Configured	TCA		Threshold(min)	Threshold(min)	(min)	Threshold(max)
	Threshold(max) (max)						
OPT[dBm]	: -50.00	-50.00	-50.00	-30.00	NA	NO	15.00
	NA	NO					
OPR[dBm]	: -50.00	-50.00	-50.00	-30.00	NA	NO	15.00
	NA	NO					

```
Last clearing of "show controllers OPTICS" counters never
```

To view the historical PM parameters on an OCH controller for a 30-second interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm history 30-sec optics 1 bucket 1
```

The following output shows the historical PM parameters on an OCH controller for a 30-second interval.

```
Mon Jul 25 05:35:52.176 UTC
```

```
Optics in interval 1 [05:35:00 - 05:35:30 Mon Jul 25 2022]
```

```
Optics history bucket type : Valid
```

	MIN	AVG	MAX
OPT[dBm]	: -50.00	-50.00	-50.00
OPR[dBm]	: -50.00	-50.00	-50.00

```
Last clearing of "show controllers OPTICS" counters never
```

To view the current PM parameters for an OCH controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm current 15-min optics 1
```

The following output shows the current PM parameters for an OCH controller for a 15-minute interval.

```
Tue May 10 11:28:50.952 UTC
```

```
Optics in the current interval [11:15:00 - 11:28:50 Tue May 10 2022]
```

```
Optics current bucket type : Valid
```

	MIN	AVG	MAX	Operational	Configured	TCA	Operational
	Configured	TCA		Threshold(min)	Threshold(min)	(min)	Threshold(max)
	Threshold(max) (max)						
OPT[dBm]	: -50.00	-50.00	-50.00	-30.00	NA	NO	15.00
	NA	NO					
OPR[dBm]	: -50.00	-50.00	-50.00	-30.00	NA	NO	15.00
	NA	NO					

```
Last clearing of "show controllers OPTICS" counters never
```

To view the historical PM parameters for an OCH controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm history 15-min optics 1 bucket 1
```

The following output shows the historical PM parameters for an OCH controller for a 15-minute interval.

Mon Jul 25 05:36:12.167 UTC

Optics in interval 1 [05:15:00 - 05:30:00 Mon Jul 25 2022]

```
Optics history bucket type : Valid
                MIN      AVG      MAX
OPT[dBm]       : -50.00   -50.00   -50.00
OPR[dBm]       : -50.00   -50.00   -50.00
```

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters on an OCH controller for a 24-hour interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm current 24-hour optics 1
```

The following output shows the current PM parameters on an OCH controller for a 24-hour interval.

Tue May 10 11:29:09.270 UTC

Optics in the current interval [00:00:00 - 11:29:09 Tue May 10 2022]

```
Optics current bucket type : Invalid
                MIN      AVG      MAX      Operational      Configured      TCA      Operational
                Configured      TCA
                Threshold(max)      Threshold(min)      Threshold(min)      Threshold(max)
OPT[dBm]       : -50.00   -50.00   -50.00   -30.00      NA      NO      15.00
                NA      NO
OPR[dBm]       : -50.00   -50.00   -50.00   -30.00      NA      NO      15.00
                NA      NO
```

Last clearing of "show controllers OPTICS" counters never

To view the historical PM parameters on an OCH controller for a 24-hour interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm history 24-hour optics 1
```

The following output shows the historical PM parameters on an OCH controller for a 24-hour interval.

Mon Jul 25 05:36:35.165 UTC

Optics in interval 1 [00:00:00 - 24:00:00 Sun Jul 24 2022]

```
Optics history bucket type : Valid
                MIN      AVG      MAX
OPT[dBm]       : -50.00   -50.00   -50.00
OPR[dBm]       : -50.00   -50.00   -50.00
```

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters for an OMS controller for a 30-second interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers oms 0/3/0/8 pm current 30-sec optics 1
```

The following output shows the current PM parameters for an OMS controller for a 30-second interval.

Mon Jul 25 07:24:38.319 UTC

Optics in the current interval [07:24:30 - 07:24:38 Mon Jul 25 2022]

```
Optics current bucket type : Valid
MIN AVG MAX Operational Configured TCA Operational Configured TCA
Threshold(min) Threshold(min) (min) Threshold(max) Threshold(max) (max)
OPT[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO
OPR[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO
```

Last clearing of "show controllers OPTICS" counters never

To view the historical PM parameters on an OMS controller for a 30-second interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers oms 0/3/0/8 pm history 30-sec optics 1 bucket 1
```

The following shows the historical PM parameters on an OMS controller for a 30-second interval.

```
Mon Jul 25 07:13:51.228 UTC

Optics in interval 1 [07:13:00 - 07:13:30 Mon Jul 25 2022]

Optics history bucket type : Valid
      MIN      AVG      MAX
OPT[dBm]   : -50.00   -50.00   -50.00
OPR[dBm]   : -50.00   -50.00   -50.00
```

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters for an OMS controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers oms 0/3/0/8 pm current 15-min optics 1
```

The following output shows the current PM parameters for an OMS controller for a 15-minute interval.

```
Mon Jul 25 07:25:00.183 UTC

Optics in the current interval [07:15:00 - 07:25:00 Mon Jul 25 2022]

Optics current bucket type : Valid
MIN AVG MAX Operational Configured TCA Operational Configured TCA
Threshold(min) Threshold(min) (min) Threshold(max) Threshold(max) (max)
OPT[dBm]   : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO
OPR[dBm]   : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO
```

Last clearing of "show controllers OPTICS" counters never

To view the historical PM parameters for an OMS controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers oms 0/3/0/8 pm history 15-min optics 1 bucket 1
```

The following output shows the historical PM parameters for an OMS controller for a 15-minute interval.

```
Mon Jul 25 07:14:03.090 UTC

Optics in interval 1 [06:45:00 - 07:00:00 Mon Jul 25 2022]

Optics history bucket type : Valid
      MIN      AVG      MAX
OPT[dBm]   : -50.00   -50.00   -50.00
OPR[dBm]   : -50.00   -50.00   -50.00
```

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters on an OMS controller for a 24-hour interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers oms 0/3/0/8 pm current 24-hour optics 1
```

The following output shows the historical PM parameters for an OMS controller for a 15-minute interval.

```
Mon Jul 25 07:26:09.817 UTC

Optics in the current interval [00:00:00 - 07:26:09 Mon Jul 25 2022]

Optics current bucket type : Valid
MIN AVG MAX Operational Configured TCA Operational Configured TCA
Threshold(min) Threshold(min) (min) Threshold(max) Threshold(max) (max)
```

```
OPT[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO
OPR[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO
```

Last clearing of "show controllers OPTICS" counters never

To view the historical PM parameters on an OMS controller for a 24-hour interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers oms 0/3/0/8 pm history 24-hour optics 1
```

The following output shows the historical PM parameters on an OMS controller for a 24-hour interval.

```
Mon Jul 25 07:18:13.532 UTC
```

```
Optics in interval 1 [00:00:00 - 24:00:00 Sun Jul 24 2022]
```

```
Optics history bucket type : Valid
```

	MIN	AVG	MAX
OPT[dBm]	-50.00	-50.00	-50.00
OPR[dBm]	-50.00	-50.00	-50.00

Last clearing of "show controllers OPTICS" counters never

PM history persistence

PM history parameters are retained even after a line card cold reload, line card warm reload, rack reload, RP reload, power cycle, or upgrade of the NCS 1010 chassis.



Note PM history persistence is not supported on NCS1K4-QXP-K9.

After a software upgrade to the latest release, you can view the history performance monitoring parameters from the previous release. The PM history persistence is supported for 30-second, 15-minute, and 24-hour bucket types. After upgrade from Release 7.11.1 to a higher version, if new PM parameters are available in the new version, below error is displayed while fetching PM data.

```
RP/0/RP0/CPU0:ios#show controllers hundredGigEctr1r 0/0/0/8 pm history 15-min ether 5
Tue Apr 5 22:05:56.750 UTC
pm_display_int_15min_ether_index: bag_decode failed ('bag' detected the 'fatal' condition
'An irresolvable version conflict prevented the specified bag from being decoded')
```

However, the following list describes the time that is required to fill all historical buckets of each bucket type, later while fetching PM historical data, no error appears.

- For 30-second bucket type, 15 minutes is required to fill 30 historical buckets.
- For 15-minute bucket type, 8 hours is required to fill 32 historical buckets.
- For 24-hour bucket type, 24 hours is required to fill 7 historical bucket.

PM counters are updated continuously in current bucket for all bucket types (flex, 30-second, 15-minute, and 24-hour). After the timer expires for the respective bucket type, the current PM data is moved to the historical PM bucket. This process of moving PM data to the historical bucket is called Rollover. After rollover, you can access the current PM data as historical PM data.

In case of deletion or removal of the controller, the PM data is persistent for 3 hours. Unless the controller is brought up within 3 hours, the PM data is cleared because the controller is considered to be not in use.

Limitations

If NCS 1010 reload or software upgrade happens during the rollover time, one of the following scenarios occurs:

- The complete PM bucket is missing and the next PM bucket is marked as *Invalid*.
- PM bucket expiry message appears as follows:

```
RP/0/RP0/CPU0:ios#show controllers hundredGigEctr1r 0/3/0/2 pm history 30-sec ether 29
Fri Apr 1 01:32:20.646 UTC
History data is empty, Verify at least one collection period is expired
```

- PM bucket interval is marked as *Invalid* and counters are updated as zero.
- PM bucket interval is marked as *Invalid* and counters are updated as nonzero.

7-day support for 15-Min PM bin

PM is enhanced for controllers to collect 15-min bin for 7 days extension.

Table 19: Feature History

Feature Name	Release Information	Feature Description
7-day 15-minute optics PM history	Cisco IOS XR Release 25.4.1	<p>This enhancement enables the collection and storage of 15-minute performance monitoring samples, collecting up to 672 samples. Previously, the CLI bucket range was 1–32; now, it is increased to 1–672 as highlighted in the CLI command.</p> <p>Updated CLI command parameter:</p> <pre>show controllers Controller-type R/S/I/P pm history 15-min optics 1 bucket <1-672></pre> <p>New CLI command introduced:</p> <pre>performance-mgmt controller 15-min extend days <0-7> , where 0 stands for 8 hours.</pre> <p>This enhancement provides comprehensive visibility into interface performance by recording 15-minute counters over a 7-day period. This allows users to effectively monitor and assess network interface health status.</p>

The collection behavior depends on the controller Product ID (PID):

- For NCS1010-CTR2-B-K9, NCS1010-CTLR-B-K9, NCS1K14-CNTRLR-B-K9, and NCS1K14-CNT-B-K9 controllers, the node automatically collects 672 samples (corresponding to 7 days of data).
- For NCS1010-CNTRLR-K9, NCS1K14-CNTRLR-K9, NCS1010-CTR2-K9 controllers, 32 samples are collected by default. To capture 672 samples, explicit configuration is required.



Note While troubleshooting, showtech can only collect 32 samples, and not the complete 672 samples, regardless of the configured sample collection.

Configure 7-day 15-minute performance monitoring sample collection

Use this task to extend sample collection beyond 32 samples.

Procedure

Step 1 Enter global configuration mode.

Example:

```
RP/0/RP0/CPU0:ios#configure
```

Step 2 Run the **performance-mgmt controller 15-min extend days** command to configure the number of days for 15-minute performance monitoring sample collection.

You can specify 0 for 8 hours of retention, or a number from 1 to 7 for the corresponding number of days.

Example:

```
RP/0/RP0/CPU0:ios(config)#performance-mgmt controller 15-min extend days 7
```

Step 3 Commit and exit the configuration mode.

Example:

```
RP/0/RP0/CPU0:ios(config)#commit  
RP/0/RP0/CPU0:ios(config)#end
```

Step 4 Run the **show controllers ots <interface> pm history 15-min optics 1 bucket extend day <0-7>** command to verify the configured sample collection.

The output should reflect the extended bucket range (for example, 1-672).

The controller is now configured to retain 15-minute performance monitoring samples for the specified duration (for example, up to 7 days or 672 samples).

