

# **Preface**

The preface describes the revision history, audience, organization, and conventions of the Cisco NCS 4201. It also lists sources for obtaining additional information and technical assistance from Cisco.

## **Document Revision History**

The following table lists the major changes made to this document.

Date	Change Summary
August 5, 2016	Initial release

#### **Document Audience**

This guide is intended for users who are responsible for installing the Cisco NCS 4201. It is intended for users who may not be familiar with the initial configuration and troubleshooting tasks, the relationship among tasks, or the Cisco IOS software commands necessary to perform particular tasks.

## **Organization**

This guide includes the following sections:

Title	Description
Overview	Describes the features and specifications of the Cisco NCS 4201.
Preparing for Installation	Describes the installation of the Cisco NCS 4201 at your site.
Installing the Cisco NCS 4201	Describes the installation of chassis on a rack as well as installation of its components.
Initial Configuration	Describes basic chassis configuration.
Troubleshooting	Describes troubleshooting information.
Site Log	Provides a record of actions related to installing and maintaining the chassis.

#### **Conventions**

This document uses the following conventions:

Convention	Indication
<b>bold</b> font	Commands and keywords and user-entered text appear in <b>bold</b> font.
italic font	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic</i> font.
[]	Elements in square brackets are optional.
{x   y   z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
courier font	Terminal sessions and information the system displays appear in courier font.
<>	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!,#	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



Note

Means reader take note. Notes contain helpful suggestions or references to material not covered in the manual.



Tir

Means the following information will help you solve a problem . The tips information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.



Caution

Means reader be careful. In this situation, you might perform an action that could result in equipment damage or loss of data.



Timesaver

Means the described action saves time. You can save time by performing the action described in the paragraph.



#### Warning

#### IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

#### SAVE THESE INSTRUCTIONS



Warning

Statements using this symbol are provided for additional information and to comply with regulatory and customer requirements.

### **Obtaining Documentation and Submitting a Service Request**

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see What's New in Cisco Product Documentation.

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the What's New in Cisco Product Documentation RSS feed. The RSS feeds are a free service.

Preface