



Preface

This document describes the Cisco IOS XR Quality of Service (QoS) feature for prioritizing traffic flow and providing preferential forwarding for higher-priority packets. The QoS techniques described include allocating bandwidth, improving loss characteristics, avoiding and managing network congestion, metering network traffic, and setting traffic-flow priorities across the network.

For QoS command descriptions, usage guidelines, and examples, refer to the *Cisco ASR 9000 Series Aggregation Services Routers Modular Quality of Service Command Reference*.

The preface contains the following sections:

- [Changes to This Document](#), page IR-xi
- [Obtaining Documentation and Submitting a Service Request](#), page IR-xii

Changes to This Document

The following table lists the technical changes made to this document.

Table 1 Changes to This Document in Cisco IOS XR 4.1

Revision	Date	Change Summary
OL-24691-01	April, 2011	<p>In the “Configuring Modular QoS Congestion Management” module, added the following feature:</p> <ul style="list-style-type: none">• 2-rate 3-color (2R3C) policer—This feature includes the conform-color and exceed-color commands. it is applicable to the SIP 700 line cards, ingress side. <p>In the “Modular QoS Deployment Scenarios” module, added the following feature:</p> <ul style="list-style-type: none">• VPLS and VPWS QoS

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.