

# Release Notes for Cisco NCS 6000 Series Routers, Release 5.0.0

---

Text Part Number: OL-30503-01

## Release Notes for Cisco NCS 6000 Series Routers, IOS XR Release 5.0.0

The Cisco Network Convergence System (NCS) 6000 series router delivers outstanding network agility, packet optical convergence, and a system scale measured in petabits per second. It also facilitates the build-out of next-generation core to:

- support elastic capacity at the lowest total ownership cost
- deliver high-bandwidth mobile, video, and cloud services

Running the Cisco IOS XR operating system, Cisco's innovative virtualized operating environment, the Cisco NCS 6000 series router advances the concept of distributed routing and virtualization. With Cisco Virtualized IOS XR, the Cisco NCS 6000 series router brings new levels of programmability and virtualization to:

- enhance application service offerings
- increase provisioning speed
- optimize network economics

The Cisco NCS 6000 series router is engineered for environmental efficiency, with the use of adaptable power consumption. The Cisco NCS 6000 series router is powered by the Cisco nPower Network Processor Units (NPU). These technologies aid the Cisco NCS 6000 series router to achieve the lowest carbon footprint in service provider routing.

The Cisco NCS 6008 router, part of the Cisco NCS 6000 series routers, is the next-generation core routing system that provides industry-leading 8 Tbps of full-duplex network bandwidth through single chassis with eight line cards per chassis.

The Cisco NCS 6008 router runs on Cisco IOS XR software with Linux as the underlying host operating system. A Kernel-based Virtual Machine (KVM) hypervisor provides a virtualized environment to independently run system administration and routing functions on separate virtual machines. This provision makes the new system versatile and robust, and provides immense flexibility for future expansion without the need for a complete system overhaul.

A multi-slice architecture of line cards enables the system to be configured in a mixed operating mode, simultaneously supporting traffic at 10 Gbps and 100 Gbps on slice-level granularity.

This release notes describe the features provided in the Cisco IOS XR Software Release 5.0.0 for the Cisco NCS 6000 series router and are updated as needed.

This electronic documents may contain updates and modifications. For more information on obtaining Cisco documentation, see the [Obtaining Documentation and Submitting a Service Request](#), on page 12 section.

For a list of software caveats that apply to Cisco IOS XR Software Release 5.0.0 see the Caveats section.

Cisco IOS XR Software running on the Cisco NCS 6000 Series Router provides the following features and benefits:

- IP features—This supports a wide range of IPv4 and IPv6 services and routing protocols such as IPv4 unicast services, IPv6 unicast services, IPv4 Multicast services, IPv4 and IPv6 equal-cost multipathing (ECMP), IPv4 and IPv6 load balancing), Cisco Discovery Protocol, IPv4 and IPv6 addressing, Internet Control Message Protocol (ICMP), IPv4 LFA FRR, HSRP, and VRRP.
- IP Multicast Features—Multicast forwarding with support for source-based and shared distribution trees and protocols such as Protocol Independent Multicast Sparse Mode (PIM-SM), PIM Source Specific Multicast (PIM SSM), Automatic Rendezvous Point (AutoRP), Internet Group Management Protocol (IGMP) versions 2 and 3, and Multicast reverse path forwarding (RPF). The Multicast nonstop forwarding (NSF) and Multicast forwarding information base (MFIB) protocols are supported.
- Layer 3 routing protocols—This supports routing protocols such as Border Gateway Protocol Version 4 (BGPv4), Open Shortest Path First Version 2 (OSPFv2) and Version 3 (OSPFv3), Intermediate System-to-Intermediate System (IS-IS) Protocol, NSF using graceful restart for IS-IS, OSPF, and BGP.
- Forwarding features—This supports routing protocols such as Access control lists (ACLs), QoS and class of service (CoS) using modular QoS command-line interface (CLI; MQC), IP packet classification and marking, Queuing (ingress and egress), Policing (ingress and egress), Diagnostic and network management support, Link Bundles, Bi-Direction Forwarding detection ( BFD), LACP, and Ethernet OAM Link Monitoring (IEEE 802.3ah).
- Multiprotocol Label Switching (MPLS) Features—Supports MPLS features such as MPLS Label Distribution Protocol (LDP), Resource Reservation Protocol (RSVP), Diffserv Aware Traffic Engineering (TE), MPLS Traffic Engineering control plane (RFCs 2702 and 2430), MPLS forwarding, MPLS load balancing, NSF for RSVP and LDP, and MPLS FRR.
- Security—Features such as Message Digest Algorithm (MD5), Control packet policing, Dynamic control plane protection, and GTSM RFC 3682 (formerly BTSH) are supported.
- Accounting—This supports features such as IP and MPLS Accounting, Interface Counters and Statistics, and Sampled Netflow ( IPv4, IPv6, and MPLS).
- Control packet policing
- Dynamic control plane protection
- GTSM RFC 3682 (formerly BTSH)
- Network Management—This supports features like Enhanced CLI, XML interface, Simple Network Management Protocol (SNMP) and MIB support - (SNMPv1,SNMPv2c,SNMPv3), and Cisco Prime Network
- System redundancy—Features such as Power redundancy 1:1 or 1:N, Fan tray redundancy 1:1, Route processor redundancy 1:1, Virtual machine redundancy, Line-card online insertion and removal (OIR) support, Fabric card OIR support, Out of resource management, and IOS XR redundancy.

# What is New in Release 5.0.0

## Software Features

Routing and System Administration by Virtual Machines—On the Cisco NCS 6008 system, the routing functions and the system administration functions are run on separate virtual machines (VMs) over a Linux host operating system. The VM simulates a physical computing environment over common hardware. Available hardware resources like processor, memory, hard disk, and so on, are virtualized and allocated to individual virtual machines by the hypervisor.

## Hardware Features

- Cisco NCS 6008 Router
  - The Cisco NCS 6008 Router 8-Slot Line Card Chassis (LCC) is a fully distributed system. All packet-forwarding decisions and actions take place on the individual line cards to provide high-speed, flexible forwarding. The control plane is independently managed by the route processors, which communicate with other network elements, then send the feature and forwarding instructions to the line cards.
  - The Cisco NCS 6008 router provides an operationally efficient infrastructure. All common components, route processors, switching fabric, fans, and power supplies are fully redundant. In addition, the platform uses power on an as-needed basis, depending on system requirements. Power has been modularized to reduce capital expenditures (CapEx) and provide operationally efficient deployment. For environment efficiency, each line card's power consumption is adapted to the number of ports used.
  - Integrated technology includes IP and Multiprotocol Label Switching (MPLS) routing, fabric multicast replication, fabric quality of service (QoS), Cisco NetFlow Accounting, and a services implementation infrastructure to provide an outstanding quality of experience (QoE) at the lowest possible total cost of ownership (TCO).

- Cisco NCS 6000 Series 10-Port 100 Gbps Line cards

The Cisco NCS 6000 series router delivers the highest throughput, while allowing for natural evolution of existing network architectures and for tighter integration between the routing and optical transport networks. To help achieve these performance objectives, Cisco NCS 6000 series router line cards can be deployed in the following ways, based on the capabilities required:

- Multiservice (MS): Supports core and peering applications requiring high-scale IPv4/IPv6/MPLS forwarding and queuing capabilities.
- Label switch routing (LSR): Supports MPLS switching applications with limited IPv4/IPv6 capabilities.

Cisco NCS 6008 router supports the following line cards:

- 10-port 100-Gbps Multiservice Line Card with CXP optics
- 10-port 100-Gbps Multiservice Line Card with Cisco AnyPort technology and Cisco CPAK optics
- 10-port 100-Gbps Lean Core Line Card with CXP optics

- 10-port 100-Gbps Lean Core Line Card with Cisco AnyPort technology and Cisco CPAK optics

The Cisco NCS 6000 Series 10-port 100-Gbps Line Cards offer significant advantages:

- Throughput of 1 Tbps with full IPv4, IPv6, and MPLS forwarding capabilities, optimized for high-throughput LSR, Internet peering, and core applications.
- Advanced Cisco nPower Layer 3 forwarding NPU with wire-rate lookup, forwarding, and QoS performance for IP and MPLS flows.
- Built-in hardware acceleration for critical network control traffic.
- Support across all Cisco NCS 6000 Series single-chassis and multi-chassis configurations.
- Support for the Cisco AnyPort technology allowing short-reach solutions to mix and match 10 GigabitEthernet and 100 GigabitEthernet interfaces.
- Efficient environmental design by adapting the power consumption to active Cisco nPower resources.
- Independently programmable and upgradable NPUs with fault protection and isolation.
- Enhanced onboard multi-core CPU for accelerated and scalable software processing.

## Related Documentation

The most current Cisco NCS 6000 Series Router software documentation is located at this URL:

[http://www.cisco.com/en/US/products/ps13132/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps13132/tsd_products_support_series_home.html)

## Caveats

Caveats describe unexpected behavior in Cisco IOS XR Software releases. Severity-1 caveats are the most critical caveats; severity-2 caveats are less critical.

### Release 5.0.0

Bug ID	Severity	Headline
<a href="#">CSCui67903</a>	2	PON exits with PGM_SIZE_EXCEPTION.
<a href="#">CSCui67287</a>	2	BGP NSR sessions not synchronized.
<a href="#">CSCuj10061</a>	2	OSPFv3 neighbors does not come up when IPSec authentication is used.
<a href="#">CSCuj21258</a>	2	User-initiated dumpcore running can take more than 20 minutes to execute.
<a href="#">CSCui02391</a>	3	CPAK Intermittent PCS Lane Bit Errors during power-cycle.
<a href="#">CSCuj05333</a>	3	Insertion of optics takes more than 80 seconds to populate in inventory.
<a href="#">CSCui91589</a>	6	Adding new card shows in "POWERED-OFF" state in <b>show platform</b> command output.

## Cisco Bug Search Tool

Bug Search Tool (BST), the online successor to Bug Toolkit, is designed to improve the effectiveness in network risk management and device troubleshooting. The tool allows partners and customers to search for software bugs based on product, release, and keyword, and aggregates key data such as bug details, product, and version. The tool has provision to filter bugs based on credentials to provide external and internal bug views for the search input.

Use the BST to view the list of outstanding and resolved bugs in a release.

The BST is available at [Bug Search](#). To search for a specific bug, go to <https://tools.cisco.com/bugsearch/bug/bugid>. For more information on BST, see [Bug Search Help](#).

## Search Bugs in BST

Follow these instructions to search for bugs that are specific to Cisco IOS XR software release 5.0.0 in BST.

- 
- Step 1** Go to <https://tools.cisco.com/bugsearch/>. Log in to the tool using your Cisco.com user name and password. After successful login, the Bug Search Tool page opens.
- Step 2** To search for release 5.0.0 bugs, enter the following parameters in the page:
- Product—Select **Series**, enter **Cisco NCS 6008 - 8-Slot Chassis** in the text box. You can alternately navigate to the product name from the **Select from list** link.
  - Releases—Enter 5.0.0.
  - Show Bugs—Select **Affecting or Fixed in these Releases**.
- Step 3** Press **Enter**.
- Note**
- By default, the search results include bugs with all severity levels and statuses, and bugs that were modified during the life cycle of the bug. After you perform a search, you can filter your search results to meet your search requirements.
  - An initial set of 25 search results is shown in the bottom pane. Drag the scroll bar to display the next set of 25 results. Pagination of search results is not supported.
- 

## Release 5.0.0 Packages

This table lists the Cisco IOS XR Software feature set matrix (packages) and associated filenames available for the Cisco IOS XR Software Release 5.0.0 that is supported on the Cisco NCS 6008 router.

**Table 1: Cisco IOS XR Software Release 5.0.0 Packages**

Feature Set	Filename	Description
-------------	----------	-------------

<b>Composite Package</b>		
Cisco IOS XR IP Unicast Routing Core Bundle	ncs6k-mini-x.iso-5.0.0	Contains the required core packages, including OS, Admin, Base, Forwarding, Modular Services Card, Routing, SNMP Agent, FPD, and Alarm Correlation.
<b>Optional Individual Packages</b> (Packages are installed individually)		
Cisco IOS XR Manageability Package	ncs6k-mgbl.pkg-5.0.0	Extensible Markup Language (XML) Parser and HTTP server packages.
Cisco IOS XR MPLS Package	ncs6k-mpls.pkg-5.0.0	MPLS Traffic Engineering (MPLS-TE), Label Distribution Protocol (LDP), MPLS Forwarding, MPLS Operations, Administration, and Maintenance (OAM), Link Manager Protocol (LMP), Optical User Network Interface (OUNI), Resource Reservation Protocol (RSVP), and Layer-3 VPN.
Cisco IOS XR Multicast Package	ncs6k-mcast.pkg-5.0.0	Multicast Routing Protocols (PIM, Multicast Source Discovery Protocol [MSDP], Internet Group Management Protocol [IGMP], Auto-RP), Tools (SAP, MTrace), and Infrastructure [(Multicast Routing Information Base [MRIB], Multicast-Unicast RIB [MURIB], and Multicast forwarding [MFWD]).
Cisco IOS XR Security Package	ncs6k-k9sec.pkg-5.0.0	Support for Encryption, Decryption, IP Security (IPSec), Secure Shell (SSH), Secure Socket Layer (SSL), and Public-key infrastructure (PKI) (Software based IPSec support—maximum of 500 tunnels)
Cisco IOS XR Documentation Package	ncs6k-doc.pkg-5.0.0	.man pages for Cisco IOS XR Software.

This table lists the TAR files.

**Table 2: Cisco IOS XR Software Release 5.0.0 TAR Files**

Feature Set	Filename	Description
Cisco IOS XR IP/MPLS Core Software	NCS6000-iosxr-5.0.0.tar	<ul style="list-style-type: none"> <li>• Cisco IOS XR IP Unicast Routing Core Bundle</li> <li>• Cisco IOS XR Manageability Package</li> <li>• Cisco IOS MPLS Package</li> <li>• Cisco IOS XR Multicast Package</li> </ul>
Cisco IOS XR IP/MPLS Core Software 3DES	NCS6000-iosxr-k9-5.0.0.tar	<ul style="list-style-type: none"> <li>• Cisco IOS XR IP Unicast Routing Core Bundle</li> <li>• Cisco IOS XR Manageability Package</li> <li>• Cisco IOS XR MPLS Package</li> <li>• Cisco IOS XR Multicast Package</li> <li>• Cisco IOS XR Security Package</li> </ul>

## The show version Command

To determine the version of Cisco IOS XR Software running on your router, log in to the router and enter the **show version** command. Use this command to validate that the Cisco IOS XR Software version is the latest on your router.

### SUMMARY STEPS

1. Establish a Telnet session with the router.
2. Enter **show version** command from XR EXEC mode.

### DETAILED STEPS

**Step 1** Establish a Telnet session with the router.

**Step 2** Enter **show version** command from XR EXEC mode.

```
RP/0/RP0/CPU0:router# show version
Cisco IOS XR Software, Version 5.0.0
Copyright (c) 2013 by Cisco Systems, Inc.
```

·  
·  
·

## System Requirements

### Memory Requirements



#### Caution

If you remove the media in which the software image or configuration is stored, the router may become unstable and fail.

The minimum memory requirements for a Cisco NCS 6008 router running Cisco IOS XR Software Release 5.0.0 consist of the following:

- 48 GB memory on the NCS 6008 Route Processors (NCS6-RP)
- 16 GB memory on line cards

### Supported Hardware

The following table lists the supported hardware components on the Cisco NCS 6000 Series Router and the minimum required software release. For more information, see the *Firmware Support* section.

**Table 3: Cisco NCS 6008 Router Hardware and Software Compatibility Matrix**

Component	Part Number	Support from Release
NCS 6008 - 8-Slot Chassis	NCS-6008	5.0.0
NCS 6008 Fabric Card	NC6-FC	5.0.0
NCS 6008 Route Processor	NC6-RP	5.0.0
NCS 6008 Chassis Fan Tray	NC6-FANTRAY	5.0.0
NCS AC Power Tray	NCS-AC-PWRTRAY	5.0.0
NCS DC Power Tray	NCS-DC-PWRTRAY	5.0.0
NCS PDU Bracket	NCS-PDU-BRKT	5.0.0
NCS 6008 3-to-1 Phase DELTA PDU	NCS-PDU-DELTA	5.0.0



Component	Part Number	Support from Release
NCS 6008 3-to-1 Phase WYE PDU	NCS-PDU-WYE	5.0.0
NCS 100x10GE Patch Panel Short Reach	NCS-PP-100X10-SR	5.0.0
NCS 6000 10x100G Multi-Service CPAK	NC6-10X100G-M-K	5.0.0
NCS 6000 10x100G Multi-Service CXP	NC6-10X100G-M-P	5.0.0
NCS 6000 10x100G LSR CPAK	NC6-10X100G-L-K	5.0.0
NCS 6000 10x100G LSR CXP	NC6-10X100G-L-P	5.0.0
NCS Craft Panel Display Kit	NCS-CRFT	5.0.0
NCS 6008 Chassis Front Doors	NC6-DOOR-F	5.0.0
NCS 6008 Chassis Rear Doors	NC6-DOOR-R	5.0.0
NCS 6008 Chassis Drill Template	NC6-DRILLTEMP	5.0.0
NCS 6008 Chassis Front-Bottom Grille	NC6-GRILLE-FB	5.0.0
NCS 6008 Chassis Front-Top Grille	NC6-GRILLE-FT	5.0.0
NCS 6008 Chassis Rear Grille	NC6-GRILLE-R	5.0.0
NCS 6008 Power Control Module	NC6-PCM	5.0.0
NCS 6008 Chassis Trough	NC6-TROUGH	5.0.0
NCS 6008 Chassis Trough Wide	NC6-TROUGH-W	5.0.0
NCS 6008 & NCS Fabric Chassis Lift Dolly	NCS-LIFT	5.0.0
10X10G-LR Cisco CPAK module for SMF	CPAK-10X10G-LR	5.0.0
CPAK-100G-LR4 Transceiver module, 10 km SMF	CPAK-100G-LR4	5.0.0
CXP-100G-SR10 transceiver Module	CXP-100G-SR10	5.0.0

## Firmware Support

To check the firmware code running on the Cisco NCS 6008 router, Release 5.0.0, run the command in System Admin EXEC mode.

```
RP/0/RP0/CPU0:router(admin)#show hw-module fpd
```

Location	Card type	HWver	FPD device	Status	FPD Versions	
					Running	Download
0/3	NC6-10X100G-M	0.4	CCC FPGA	READY	1.14	1.14
0/3	NC6-10X100G-M	0.4	BAO-MB FPGA	READY	1.00	1.00
0/3	NC6-10X100G-M	0.4	CCC Power-On	READY	1.30	1.30
0/3	NC6-10X100G-M	0.4	Ethernet Switch	READY	1.32	1.32
0/3	NC6-10X100G-M	0.4	BIOS FPD	READY	9.10	9.10
0/3	NC6-10X100G-M	1.0	Slice-0 GN2411	READY	2.07	2.07
0/3	NC6-10X100G-M	1.0	Slice-1 GN2411	READY	2.07	2.07
0/3	NC6-10X100G-M	0.4	BAO-DB FPGA	READY	1.00	1.00
0/3	NC6-10X100G-M	1.0	S2 GN2411	READY	2.07	2.07
0/3	NC6-10X100G-M	1.0	S3 GN2411	READY	2.07	2.07
0/3	NC6-10X100G-M	1.0	S4 GN2411	READY	2.07	2.07
0/3	NC6-10X100G-M	1.0	Slice-2 GN2411	READY	2.07	2.07
0/3	NC6-10X100G-M	1.0	Slice-3 GN2411	READY	2.07	2.07
0/3	NC6-10X100G-M	1.0	Slice-4 GN2411	READY	2.07	2.07
0/RP0	NC6-RP	0.3	CCC FPGA	READY	1.00	1.00
0/RP0	NC6-RP	0.3	CCC Power-On	READY	1.31	1.31
0/RP0	NC6-RP	0.3	Ethernet Switch	READY	1.32	1.32
0/RP0	NC6-RP	0.3	CPU Complex FPD	READY	3.06	3.06
0/RP0	NC6-RP	0.3	BIOS FPD	READY	9.10	9.10
0/FC0	NC6-FC	0.2	CCC FPGA	READY	1.14	1.14
0/FC0	NC6-FC	0.2	CCC Power-On	READY	1.31	1.31
0/FT0	NC6-FANTRAY	0.4	Fantray FPGA	READY	2.01	2.01
0/FT1	NC6-FANTRAY	0.4	Fantray FPGA	READY	2.01	2.01
0/PT0	PWR-3KW-AC-V2	1.0	PM0-DT-PrimCU	READY	6.01	6.01
0/PT0	PWR-3KW-AC-V2	1.0	PM0-DT-Sec54vMCU	READY	6.01	6.01
0/PT0	PWR-3KW-AC-V2	1.0	PM0-DT-Sec5vMCU	READY	6.03	6.03
0/PT0	PWR-3KW-AC-V2	1.0	PM1-DT-PrimCU	READY	6.01	6.01
0/PT0	PWR-3KW-AC-V2	1.0	PM1-DT-Sec54vMCU	READY	6.01	6.01
0/PT0	PWR-3KW-AC-V2	1.0	PM1-DT-Sec5vMCU	READY	6.03	6.03
0/PT0	PWR-3KW-AC-V2	1.0	PM2-DT-PrimCU	READY	6.01	6.01
0/PT0	PWR-3KW-AC-V2	1.0	PM2-DT-Sec54vMCU	READY	6.01	6.01
0/PT0	PWR-3KW-AC-V2	1.0	PM2-DT-Sec5vMCU	READY	6.03	6.03
0/PT1	PWR-3KW-AC-V2	1.0	PM0-DT-PrimCU	READY	6.01	6.01
0/PT1	PWR-3KW-AC-V2	1.0	PM0-DT-Sec54vMCU	READY	6.01	6.01
0/PT1	PWR-3KW-AC-V2	1.0	PM0-DT-Sec5vMCU	READY	6.03	6.03
0/PT1	PWR-3KW-AC-V2	1.0	PM1-DT-PrimCU	READY	6.01	6.01
0/PT1	PWR-3KW-AC-V2	1.0	PM1-DT-Sec54vMCU	READY	6.01	6.01
0/PT1	PWR-3KW-AC-V2	1.0	PM1-DT-Sec5vMCU	READY	6.03	6.03
0/PT1	PWR-3KW-AC-V2	1.0	PM2-DT-PrimCU	READY	6.01	6.01
0/PT1	PWR-3KW-AC-V2	1.0	PM2-DT-Sec54vMCU	READY	6.01	6.01
0/PT1	PWR-3KW-AC-V2	1.0	PM2-DT-Sec5vMCU	READY	6.03	6.03

### Minimum Firmware Requirement

The following table provides the procedures and resources for minimum firmware requirements:

After completing an Return Material Authorization (RMA), upgrade the firmware as per the matrix in this link, which also links to PDF copies of the IOS XR Firmware Upgrade Guides	<a href="http://www.cisco.com/web/Cisco_IOS_XR_Software/index.html">http://www.cisco.com/web/Cisco_IOS_XR_Software/index.html</a>
--	---

For the upgrade procedure, see the <i>Performing System Upgrade and Installing Feature Packages</i> chapter of the <i>Cisco NCS 6008 System Setup and Software Installation Guide</i>	<a href="http://www.cisco.com/en/US/products/ps13132/tsd_products_support_series_home.html">http://www.cisco.com/en/US/products/ps13132/tsd_products_support_series_home.html</a>
---	---

## Important Notes

- Country-specific laws, regulations, and licenses—In certain countries, use of these products may be prohibited and subject to laws, regulations, or licenses, including requirements applicable to the use of the products under telecommunications and other laws and regulations; customers must comply with all such applicable laws in the countries in which they intend to use the products.
- Field replaceable unit (FRU) removal—For all card removal and replacement (including fabric cards, line cards, fan controller, and RP) follow the instructions provided by Cisco to avoid impact to traffic. See the *Cisco Network Convergence System 6000 Series Routers Hardware Installation Guide* for procedures.
- Exceeding Cisco testing—If you intend to test beyond the combined maximum configuration tested and published by Cisco, contact your Cisco Technical Support representative to discuss how to engineer a large-scale configuration for your purpose.

## MIBs Reference

These MIBs are not supported in Cisco IOS XR Release 5.0.0:

BRIDGE-MIB	CISCO-IETF-VPLS-GENERIC-MIB	CISCO-SONET-MIB
CISCO-DS3 -MIB	CISCO-IETF-VPLS-LDP-MIB	DS3-MIB
CISCO-ENHANCED-IMAGE-MIB	CISCO-IP-CBR-METRICS-MIB	FRAME-RELAY-DTE-MIB
CISCO-FLASH-MIB	CISCO-IP-STAT-MIB	IANA-MAU-MIB
CISCO-FRAME-RELAY-MIB	CISCO-OAM-MIB	IEEE8021-CFM-MIB
CISCO-IETF-PW-ENET-MIB	CISCO-OTN-IF-MIB	LLDP-MIB
CISCO-IETF-PW-MIB	CISCO-P2P-IF-MIB	MFR MIB
CISCO-IETF-PW-MPLS-MIB	CISCO-RTTMON-MIB	mgmtrap
CISCO-IETF-PW-TC-MIB	CISCO-ESS-BORDER-CIRL-RCALL-STAT-MIB	SONET-MIB
CISCO-IETF-VPLS-BGP-EXT-MIB	CISCO-ESS-BORDER-CIRL-REVENT-MIB	VPN-TC-STD-MIB

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see [What's New in Cisco Product Documentation](#).

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the [What's New in Cisco Product Documentation RSS feed](#). RSS feeds are a free service.

---

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2014 Cisco Systems, Inc. All rights reserved.