

Small form-factor pluggables

Small Form-Factor Pluggables (SFPs) that are not Cisco certified are called third-party SFPs. Cisco approved means the SFPs have undergone rigorous testing with Cisco products and the SFPs are guaranteed to have 100% compatibility.



Note

Cisco does not provide any kind of support for the third-party SFPs because they are not validated by Cisco.

• Configuring third-party SFPs, on page 1

Configuring third-party SFPs

Third-party SFPs are manufactured by companies that are not on the Cisco-approved Vendor List (AVL). Currently, Cisco 8100 Series Secure Routers support only Cisco-approved SFPs.

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 2	service unsupported-transceiver	Enables third-party SFP support.
	Example:	
	Router(config)# service unsupported-transceiver	
Step 3	interface type slot subslot port number	Selects an interface to configure.
	Example:	
	Router(config-if)# interface ethernet 0/3/0	
Step 4	media-type sfp	Changes media type to SFP.
	Example:	
	Router(config-if) #media-type sfp	

	Command or Action	Purpose
Step 5	speed value	Configures the speed of the interface.
	Example: Router# speed 100	Note For 100BASE SFPs, configure the speed to 100 Mbps only. Similarly, for 1000BASE SFPs, configure the speed to 1000 Mbps only.
Step 6	<pre>shutdown Example: Router(config) # shutdown</pre>	Disables the interface, changing its state from administratively UP to administratively DOWN.
Step 7	<pre>no shutdown Example: Router(config-if) # no shutdown</pre>	Enables the interface, changing its state from administratively DOWN to administratively UP.
Step 8	<pre>exit Example: Router(config-if) #exit</pre>	Exits the configuration mode and returns the global configuration mode.

Examples

This example shows how to configure a third-party SFP on Cisco 8100 Series Secure Routers:

```
Router# configure terminal
Router(config)# interface ethernet 0/3/0
Router(config-if)# service unsupported-transceiver
Router(config)# interface ethernet 0/3/0
Router(config-if)# media-type sfp
Router(config-if)# speed 100
Router(config-if)# shutdown
Router(config-if)# no shutdown
Router(config-if)# exit
Router(config)# exit
```