



Release Notes for Cisco IOS XRv 9000 Routers, IOS XR Release 24.2.21

[Release Notes for Cisco IOS XRv 9000 Router, IOS XR Release 24.2.21](#) 2

[Cisco IOS XRv 9000 Router Overview](#) 2

[Supported Cisco IOS XR Technologies](#) 8

[Caveats](#) 13

[Other Important Information](#) 13

[Full Cisco Trademarks with Software License](#) 15

Revised: May 7, 2025

Release Notes for Cisco IOS XRv 9000 Router, IOS XR Release 24.2.21

Cisco IOS XRv 9000 Router is a cloud-based router that is deployed on a virtual machine (VM) instance on x86 server hardware running 64 bit IOS XR software. Cisco IOS XRv 9000 Router provides traditional Provider Edge (PE) services in a virtualized form factor, as well as virtual Route Reflector (vRR) capabilities.

Cisco IOS XRv 9000 Router Overview

The Cisco IOS XRv 9000 Router is based on Cisco IOS XR software, so it inherits and shares the wide breadth of routing functionality available on other IOS XR platforms. The IOS XR features available on the Cisco IOS XRv 9000 Router are discussed in *Supported Cisco IOS XR Technologies* section.

When the Cisco IOS XRv 9000 Router virtual IOS XR software is deployed as a VM, the Cisco IOS XR software functions just as if it were deployed on a traditional Cisco IOS XR hardware platform. The Cisco IOS XRv 9000 Router combines Route Processor, Line Card, and virtualized forwarding capabilities into a single, centralized forwarding instance. The Cisco IOS XRv 9000 Router has a fully featured, high speed virtual x86 data plane.

Cisco IOS XRv 9000 Router supports the same look and feel as Cisco ASR 9000 Series Aggregation Services Routers and North-bound APIs. Cisco IOS XRv 9000 Router does not support hardware specific configurations. The configuration commands for control plane and data plane features follow the same syntax as the Cisco ASR 9000 Series Aggregation Services Routers. See [Cisco ASR 9000 Series Aggregation Services Routers command references](#) for more information on configuration commands.

What's New in Cisco IOS XR Release 24.2.21

Cisco IOS XR Release 24.2.21 is a Service Pack for Cisco IOS XRv 9000 routers. There are no new software features introduced in this release.

For more details on the Cisco IOS XR release model and associated support, see [Software Lifecycle Support Statement - IOS XR](#).

Licensing

Starting with Cisco IOS XR Release 24.1.1, Smart Licensing Using Policy (SLP) is the default Licensing model. When you upgrade to the Cisco IOS XR Release 24.1.1 release or later, the Smart Licensing Using Policy is enabled by default.

You can migrate your devices to Smart Licensing with Policy model, see *Migrating from Smart Licensing to Smart Licensing Using Policy*, [Smart Licensing Using Policy on Cisco IOS XR Routers](#).

We recommend that you update to the latest version of [SSM On-Prem](#) or [Cisco Smart Licensing Utility](#).



Note SSM On-Prem and CSSM both support SLP devices and SL devices. SLP devices and SL devices can coexist in a network. The Smart Licensing (SL) model is available in releases Cisco IOS XR Release 7.11.1 and earlier.

Software Features Enhanced and Introduced

To learn about features introduced in other Cisco IOS XR releases, select the release from the [Documentation Landing Page](#).

No new features introduced in this release.

Cisco IOS XRv 9000 Router Licensing Model

The Cisco IOS XRv 9000 Router supports activation using Cisco Smart Licensing. By default the Cisco IOS XRv 9000 Router (without license) is rate limited to 200 Kbps.

For more information on licensing model supported on Cisco IOS XRv 9000 Router, see the *Cisco IOS XRv 9000 Router Smart Licensing* chapter in the [Cisco IOS XRv 9000 Router Installation and Configuration Guide](#).

See [Cisco Smart Software Licensing Overview](#) for more information on Cisco Smart Licensing.

License Ordering Information

The Cisco IOS XRv 9000 Router offers a flexible licensing scheme, with multiple tiers to choose from, such as Scale, and Throughput. This table lists details of Cisco IOS XRv 9000 Router's pool of software licenses or entitlements, arranged according to licensing PIDs.



Note The XRv9000 router only consumes and reports VPE licenses. VRR licenses are not consumed or reported.

Table 1: Cisco IOS XRv 9000 Router Licensing PIDs

PIDs	Description
R-IOSEXRV-SUBSCRIP	Bundle PID for IOS XRV SBP
R-VROUTER-SUB	Subscription license for Cisco IOS XRv 9000 Software
R-IOSEXRV-SUB-IMG	ATO for XRv SUB
S-XRV-SUB-RR-1M	Subscription license for virtual Route Reflector (vRR) functionality with 1 million routes
S-XRV-SUB-RTU	IOS XRv 9000 license for one virtual router instantiation
S-XRV-SUB-RR-4M	Subscription license for virtual Route Reflector (vRR) scale upgrade from 4 million routes
S-XRV-SUB-RR-10M	Subscription license for virtual Route Reflector (vRR) scale upgrade from 4 to 10 million routes
S-XRV-SUB-RR-20M	Subscription license for virtual Route Reflector (vRR) scale upgrade from 10 to 20 million routes
S-XRV-SUB-XTC	Billing PID for SBP XRV9K -SR-PCE (XTC) RTU
S-XRV-B-SUB-1G	IOS XRv 9000 1G throughput license for IP MPLS base package
S-XRV-P-SUB-1G	IOS XRv 9000 1G throughput license for IP MPLS premium package
S-XRV-L3-B-SUB-1G	IOS XRv 9000 1G throughput license for IP MPLS L3VPN base package

PIDs	Description
S-XRV-L3-P-SUB-1G	IOS XRv 9000 1G throughput license for IP MPLS L3VPN premium package
S-XRV-LI-SUB-RTU	IOS XRv 9000 Advance software license for Lawful Intercept
S-XRV-HQOS-SUB-1G	IOS XRv 9000 1G Advance software license for HQoS
SVS-XRV-SUPT-BA	XRv Support - Basic

System Requirements

Appliance Model

Cisco IOS XRv 9000 Appliance is the pre-installed Cisco IOS XRv 9000 Router software that is sent from the factory on a bare metal UCS server hardware. It supports hyper scalability as it can scale to 70 Million route prefixes when run as a Virtual Route Reflector. Therefore, the extra layer of software (hypervisor) is not required.

The Appliance also supports Zero Touch Provisioning (ZTP) which allows easier insertion into existing networks. Current offering is based on UCS M5 Servers, comes with 2 Intel X710 quad-port 10G SFP+ NICs.

Hypervisors

A hypervisor enables multiple operating systems to share a single hardware host machine. While each operating system appears to have the dedicated use of the host's processor, memory, and other resources; the hypervisor controls and allocates only needed resources to each operating system and ensures that the operating systems (VMs) do not disrupt each other.

Installation of the Cisco IOS XRv 9000 Router is supported on selected Type 1 (native, bare metal) hypervisors. Installation is not supported on Type 2 (hosted) hypervisors, such as VMware Fusion, VMware Player, or Virtual Box. The following table lists release specific supported hypervisor versions.

Table 2: Support Matrix for Hypervisor Versions

Cisco IOS XR Version	VMWare ESXi	Kernel Based Virtual Machine (KVM)
Release 24.2.21	version 6.5, 6.7, 7.0	Linux KVM based on <ul style="list-style-type: none"> • Red Hat Enterprise Linux 7, 7.1, 7.2, 7.3, 7.4, 7.5, 7.6, 7.7, and 8.0 • Ubuntu 14.04.03 LTS • Ubuntu 16.04 LTS • CentOS 7, 7.1, 7.2, 7.3, 7.4, 7.5, 7.6, and 7.7 • Openstack 10

Virtual Machines

Cisco IOS XRv 9000 Router virtual machines must meet the following requirements:

Table 3: VM Requirement for VMware Environment

Parameters	Supported
VMware ESXi	Version 6.5, 6.7, 7.0
Virtual CPU cores	<p>1 socket with a minimum of 2 cores</p> <p>Note For production environment minimum of 4 cores is recommended.</p> <p>Note For multicast heavy deployments we recommend to configure 8 cores (with 4 assigned for control plane and 4 assigned for data plane).</p>
Virtual Machine memory size	12GB minimum, 19GB recommended for 10G interfaces
Virtual Machine hard disk size	64GB minimum for vPE and vRR image variants
Virtual Interfaces	<ul style="list-style-type: none"> • E1000 • VMXNET3 for traffic interfaces only
Physical NICs	<p>For pass-through:</p> <ul style="list-style-type: none"> • Intel X710 <p>SR-IOV supported for:</p> <ul style="list-style-type: none"> • Intel E810 XXV (Trunk VFs Only)
Number of interfaces	<p>Maximum of 11 NICs where:</p> <ul style="list-style-type: none"> • 1 for management • 2 are reserved • 8 for traffic
Default video, SCSI controller set	<p>Required</p> <p>SCSI controller not required for IDE disk.</p>
Virtual CD/DVD drive installed	Virtual CD/DVD is required when installing the Cisco IOS XRv 9000 Router on the VM using ISO template.
IDE hard disk	<p>Single IDE hard disk</p> <p>Note Multiple hard disk drives on a VM are not supported.</p>



Note The maximum traffic performance with pass-through NIC interfaces in ESXi is lower than the performance that can be achieved in KVM environments. This is because it is not possible to configure 1G huge-pages in the ESXi hypervisor (as of VMware ESXi 6.0).

Table 4: VM Requirement for KVM Environment

Parameters	Supported
KVM versions	<ul style="list-style-type: none">• Linux KVM based on Red Hat Enterprise Linux 7, 7.1, 7.2, 7.3 and 7.4• Ubuntu 14.04.03 LTS Server 64 Bits• Ubuntu 16.04 LTS• Openstack Release 5 (Icehouse), Openstack Juno/Icehouse (RHEL 7), Kilo (RHEL 7.1), Liberty (RHEL 7.2), Openstack 10 (Newton)• CentOS 7, 7.1, 7.2, 7.3, 7.4, 7.5, 7.6, and 7.7
Virtual CPU cores	1 socket with minimum of 2 cores. Note For multicast heavy deployments we recommend to configure 8 cores (with 4 assigned for control plane and 4 assigned for data plane).
Virtual Machine memory size	12GB Minimum, 19GB recommended for 10G interfaces
Virtual Machine hard disk size	64GB minimum
Virtual Interfaces	E1000, VirtIO and VMXNET3 for traffic interfaces only
Physical NICs	For pass-through: <ul style="list-style-type: none">• Intel X710

Parameters	Supported
Number of interfaces	<p>Minimum of 4 NICs where:</p> <ul style="list-style-type: none"> • 1 is for management • 2 are reserved • 1 is for traffic <p>Maximum of 11 NICs where:</p> <ul style="list-style-type: none"> • 1 is for management • 2 are reserved • 8 is for traffic
Virtual CD/DVD drive installed	Virtual CD/DVD drive is required for ISO installation



Note In the Cisco IOS XRv 9000 Router, some CPU cores are dedicated to the control plane while others are dedicated to the data plane. Each data plane's core runs a single thread that performs packet forwarding. To achieve maximum performance, these threads constantly look for data packets to process. As a result, the OS records that these cores run at 100% utilization. This is expected behavior and not an indication that packet forwarding has reached its threshold limit.

10G Optic Support

Product	Product Code	Supplier Part Number
Cisco 10GBASE SFP+, Short Range	Cisco SFP-10G-SR	<p>Cisco SFP-10G-SR</p> <p>Note This optic is recommended for the better performance and interoperability with IOS XRv 9000.</p>
Cisco 10GBASE SFP+, Long Range	Cisco SFP-10G-LR	<p>Cisco SFP-10G-LR</p> <p>Note This optic is recommended for the better performance and interoperability with IOS XRv 9000.</p>
Intel Ethernet SFP SR Optics Dual Rate 10GBASE-SR/1000BASE-SX	E10GSFPSR	FTLX8571D3BCVIT1 or AFBR-709DMZ-IN2

Server

The server must support:

- Intel Westmere or later CPU versions with clock frequency of 2.0GHz for instances with Gigabit or paravirtualized interfaces

- Intel Ivy Bridge or later CPU versions for instances with 10Gb or higher interfaces
- Intel CPU must support the **sse4_2** capability flag. This can be checked in KVM by looking for the **sse4_2** flag in the flags section of `/proc/cpuinfo`. For example:

```
cat /proc/cpuinfo | grep sse4_2
flags       : fpu vme de pse tsc msr pae mce cx8 apic sep mtrr pge mca cmov pat pse36 clflush mmx fxsr
sse sse2 ss syscall nx pdpe1gb rdtscp lm constant_tsc arch_perfmon nopl xtopology tsc_reliable nonstop_tsc
aperfperf pni pclmulqdq vmx ssse3 fma cx16 pcid sse4_1 sse4_2 x2apic movbe popcnt aes xsave avx f16c
rdrand hypervisor lahf_lm ida arat epb pln pts dtherm tpr_shadow vnmi ept vpid fsgsbase smep
```



Note To use passthrough interfaces in KVM, you must set the option **intel_iommu=on** command in the grub configuration.

Supported Cisco IOS XR Technologies

Cisco IOS XRv 9000 Router supports selected Cisco IOS XR technologies.

This table lists the major Cisco IOS XR technologies Cisco IOS XRv 9000 supports. Not all features in a given technology may be supported. To verify support for specific features, use [Cisco Feature Navigator](#).

Table 5: Cisco IOS XR Technologies Supported on the Cisco IOS XRv 9000 Router

Feature	See the Following Documentation	Introduced in Release
• Application Hosting	• Cisco IOS XR Application Hosting Configuration Guide	Release 6.1.2
• BFD over Logical Bundle	• Routing Configuration Guide for Cisco ASR 9000 Series Routers • Routing Command Reference for Cisco ASR 9000 Series Routers	Release 6.1.2
• Bi-directional Policing and Marking	• Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Configuration Guide • Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Command Reference	Release 5.4.0
• BGP Persistence	• Cisco ASR 9000 Series Aggregation Services Router Routing Configuration Guide • Cisco ASR 9000 Series Aggregation Services Router Routing Command Reference	Release 6.2.1
• BGP Optimal Route Reflector	• Cisco IOS XRv 9000 Router Installation and Configuration Guide	Release 6.0.1

Feature	See the Following Documentation	Introduced in Release
<ul style="list-style-type: none"> Broadband Network Gateway (BNG) IPoE 	<ul style="list-style-type: none"> Broadband Network Gateway Configuration Guide for Cisco ASR 9000 Series Routers IPoE Commands 	Release 6.3.1
<ul style="list-style-type: none"> Broadband Network Gateway (BNG) PPPoE 	<ul style="list-style-type: none"> Broadband Network Gateway Configuration Guide for Cisco ASR 9000 Series Routers PPPoE Commands 	Release 6.4.1
Customize Installation using Golden ISO	Customize Installation using Golden ISO	Release 7.3.1
Create User Profiles and Assign Privileges	System Setup and Software Installation Guide for Cisco ASR 9000 Series Routers	Release 7.1.1
<ul style="list-style-type: none"> Generic Routing Encapsulation (GRE) over IPv4 	<ul style="list-style-type: none"> MPLS Layer 3 VPN Configuration Guide for Cisco ASR 9000 Series Routers Generic Routing Encapsulation Commands 	Release 6.3.1
<ul style="list-style-type: none"> HSRP VRRP 	<ul style="list-style-type: none"> IP Addresses and Services Configuration Guide for Cisco ASR 9000 Series Routers Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Command Reference 	Release 6.2.1
<ul style="list-style-type: none"> Hierarchical Policers (including conform aware) 	<ul style="list-style-type: none"> Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Configuration Guide Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Command Reference 	Release 6.0.1
<ul style="list-style-type: none"> IPv4 Routing IPv6 Routing OSPF ISIS 	<ul style="list-style-type: none"> Cisco ASR 9000 Series Aggregation Services Router Routing Configuration Guide Cisco ASR 9000 Series Aggregation Services Router Routing Command Reference 	Release 5.4.0
<ul style="list-style-type: none"> IPSLA Platform Automated Monitoring 	<ul style="list-style-type: none"> Implementing IP Service Level Agreements Cisco ASR 9000 Series Aggregation Services Router System Monitoring Command Reference 	Release 6.0.0

Feature	See the Following Documentation	Introduced in Release
<ul style="list-style-type: none"> • IPv4 and IPv6 ACL 	<ul style="list-style-type: none"> • Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Configuration Guide • Access List Commands 	Release 5.4.0
<ul style="list-style-type: none"> • IPv4 L3VPN • 6PE, 6VPE 	<ul style="list-style-type: none"> • Cisco ASR 9000 Series Aggregation Services Router MPLS Layer 3 VPN Configuration Guide • Cisco ASR 9000 Series Aggregation Services Router VPN and Ethernet Services Command Reference 	Release 5.4.0
L2VPN VPWS	<ul style="list-style-type: none"> • L2VPN and Ethernet Services Configuration Guide for Cisco ASR 9000 Series Routers • VPN and Ethernet Services Command Reference for Cisco ASR 9000 Series Routers 	Release 6.4.1
<ul style="list-style-type: none"> • Link Aggregation Group (LAG) 	<ul style="list-style-type: none"> • Cisco ASR 9000 Series Aggregation Services Router Interface and Hardware Component Configuration Guide 	Release 6.1.2
<ul style="list-style-type: none"> • Lawful Intercept 	<ul style="list-style-type: none"> • Implementing Lawful Intercept • Cisco ASR 9000 Series Aggregation Services Router System Security Command Reference 	Release 5.4.0
<ul style="list-style-type: none"> • LDP 	<ul style="list-style-type: none"> • Cisco ASR 9000 Series Aggregation Services Router MPLS Configuration Guide • Cisco ASR 9000 Series Aggregation Services Router MPLS Command Reference 	Release 5.4.0
<ul style="list-style-type: none"> • LPTS 	<ul style="list-style-type: none"> • Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Configuration Guide • LPTS Commands 	Release 5.4.0

Feature	See the Following Documentation	Introduced in Release
Multicast features: <ul style="list-style-type: none"> • IPv4/IPv6 L3 Native Multicast: IGMP, MLD, PIM SM/SSM in default VRF • IPv4 MVPN Rosen GRE with IGMP, PIM SM/SSM in Non-Default VRF <ul style="list-style-type: none"> • Profile 0: Rosen MVPN GRE • Profile 3: Rosen MVPN GRE with BGP-AD • Profile 11: Rosen MVPN GRE with BGP C-Multicast routing 	<ul style="list-style-type: none"> • Multicast Configuration Guide for Cisco ASR 9000 Series Routers • Multicast Command Reference for Cisco ASR 9000 Series Routers 	Release 6.4.1
<ul style="list-style-type: none"> • MPLS 	<ul style="list-style-type: none"> • Cisco ASR 9000 Series Aggregation Services Router MPLS Configuration Guide • Cisco ASR 9000 Series Aggregation Services Router MPLS Command Reference 	Release 5.4.0
<ul style="list-style-type: none"> • MP-BGP, EBGp PE-CE 	<ul style="list-style-type: none"> • Cisco ASR 9000 Series Aggregation Services Router Routing Configuration Guide • Cisco ASR 9000 Series Aggregation Services Router Routing Command Reference 	Release 5.4.0
<ul style="list-style-type: none"> • Network Service Header (NSH) 	<ul style="list-style-type: none"> • Implementing NSH Based Service Chaining • Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Command Reference 	Release 6.1.2
<ul style="list-style-type: none"> • NSH Proxy Mode 	Cisco IOS XRv 9000 Router Specific Features	Release 6.2.1
<ul style="list-style-type: none"> • RT Constraint 	<ul style="list-style-type: none"> • Cisco ASR 9000 Series Aggregation Services Router Routing Configuration Guide • Cisco ASR 9000 Series Aggregation Services Router Routing Command Reference 	Release 6.2.1
<ul style="list-style-type: none"> • Segment Routing over IPv6 	<ul style="list-style-type: none"> • Segment Routing Configuration Guide for Cisco ASR 9000 Series Routers • Segment Routing Command Reference for Cisco ASR 9000 Series Routers 	Release 6.6.1
<ul style="list-style-type: none"> • Telemetry 	<ul style="list-style-type: none"> • Telemetry Configuration Guide for Cisco ASR 9000 Series Routers 	Release 6.0.0

Feature	See the Following Documentation	Introduced in Release
<ul style="list-style-type: none"> The Two-Way Active Measurement Protocol (TWAMP) 	<ul style="list-style-type: none"> System Monitoring Configuration Guide for Cisco ASR 9000 Series Routers Cisco ASR 9000 Series Aggregation Services Router System Monitoring Command Reference 	Release 6.0.1
<ul style="list-style-type: none"> Virtualised Local Mobility Anchor (vLMA) 	<ul style="list-style-type: none"> Configuring Proxy Mobile IPv6 Local Mobility Anchor Proxy Mobile IPv6 Local Mobility Anchor Commands 	Release 6.3.1
<ul style="list-style-type: none"> VRF Support on Docker and LXC Containers 	<ul style="list-style-type: none"> Cisco IOS XR Application Hosting Configuration Guide 	Release 6.3.1
<ul style="list-style-type: none"> SRv6 Traffic Engineering 	<ul style="list-style-type: none"> Segment Routing Configuration Guide for Cisco ASR 9000 Series Routers 	Release 7.3.2
Generic Route Encapsulation using IPv6	MPLS Layer 3 VPN Configuration Guide	Release 7.3.3
<ul style="list-style-type: none"> Running High Availability (HA) redundancy application for AWS QoS on IPv4 Release GRE Tunnels Increase in BFD scale limit and BFD sessions 	Cisco IOS XRv 9000 Router Installation and Configuration Guide	Release 7.3.3
<ul style="list-style-type: none"> Enhanced Networking Features with Elastic Network Adapter (ENA) on Amazon EC2 M5 Instances Updated DPDK Driver Version Enhanced router performance and scales ACL Based Forwarding (ABF) Redirect IPV4 and IPv6 traffic using PBR Support for IPv6 over SR-MPLS through a GRE Tunnel towards an IPv6 Next Hop device BFD on GRE Tunnel Interface 	Release Notes for Cisco IOS XRv 9000 Routers, IOS XR Release 7.3.3	Release 7.3.3

Feature	See the Following Documentation	Introduced in Release
<ul style="list-style-type: none"> SR-PCE: Single PCE scale enhancement SR-PCE: Stateful North-Bound API for Tree-SID 	Release Notes for Cisco IOS XRv 9000 Routers, IOS XR Release 7.5.1	Release 7.5.1
ORR Support for FlexAlgo	Cisco IOS XRv 9000 Router Installation and Configuration Guide	Release 7.5.1
gNMI Bundling of Telemetry Updates	Cisco IOS XRv 9000 Router Installation and Configuration Guide	Release 7.8.1
Auto-Save and Copy Router Configuration Using Public Key Authentication	General Administration on Cisco ASR 9000 Series Routers	Release 7.10.1
Smart Licensing Using Policy	Cisco IOS XR Smart Licensing Using Policy	Release 24.1.1
Multi-Factor Authentication for SSH	System Security Configuration Guide for Cisco ASR 9000 Series Routers	Release 24.1.1

Caveats

Table 6: Cisco XRv 9000 Series Router Specific Bugs

Bug ID	Headline
CSCwm41974	Improper label programming during microloop avoidance activation causes a traffic drop.

There are no caveats in this release.

Other Important Information

- For the XRv 9000 platform, minimum transmission period supported for the Link Aggregation Control Protocol (LACP) is 200 milliseconds.

Upgrading Cisco IOS XR Software

Cisco IOS XR Software is installed and activated from modular packages, allowing specific features or software patches to be installed, upgraded, or downgraded without affecting unrelated processes. Software packages can be upgraded or downgraded on all supported card types, or on a single card (node).



Note The FPD related commands are not supported on IOS XRv 9000 Appliance. That includes **fpd auto-upgrade** command.

Cisco IOS XR Error messages

To view, search, compare, and download Cisco IOS XR Error Messages, refer to the [Cisco IOS XR Error messages](#) tool.

Cisco IOS XR MIBs

To determine the MIBs supported by platform and release, refer to the [Cisco IOS XR MIBs](#) tool.

Related Documentation

The most current Cisco XRV 9000 router documentation is located at the following URL:

<https://www.cisco.com/c/en/us/td/docs/iosxr/ios-xrv-9000-router.html>

Full Cisco Trademarks with Software License

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)



Americas Headquarters
Cisco Systems, Inc.
San Jose, CA 95134-1706
USA

Asia Pacific Headquarters
CiscoSystems(USA)Pte.Ltd.
Singapore

Europe Headquarters
CiscoSystemsInternationalBV
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.