



# Preface

---

**Published: January 15, 2014, OL-30790-01**

This guide describes how to install appliances that support Cisco IPS 7.3. It includes a glossary that contains expanded acronyms and pertinent IPS terms. It is part of the documentation set for Cisco Intrusion Prevention System 7.3. Use this guide in conjunction with the documents listed in [Related Documentation](#), page xiii.

This preface contains the following topics:

- [Audience](#), page xi
- [Organization](#), page xi
- [Conventions](#), page xii
- [Related Documentation](#), page xiii
- [Where to Find Safety and Warning Information](#), page xiii
- [Obtaining Documentation, Using the Cisco Bug Search Tool, and Submitting a Service Request](#), page xiii

## Audience

This guide is for experienced network security administrators who install and maintain Cisco IPS sensors, including the supported IPS appliances.

## Organization

This guide includes the following sections:

Section	Title	Description
1	<a href="#">“Introducing the Sensor”</a>	Describes IPS appliances.
2	<a href="#">“Preparing the Appliance for Installation”</a>	Describes how to prepare the sensor for installation.
3	<a href="#">“Installing the IPS 4345 and IPS 4360”</a>	Describes how to install the IPS 4345 and the IPS 4360.
4	<a href="#">“Installing the IPS 4510 and IPS 4520”</a>	Describes how to install the IPS 4510 and the IPS 4520.

Section	Title	Description
A	“Logging In to the Sensor”	Describes how to log in to the sensor.
B	“Initializing the Sensor”	Describes how to use the <b>setup</b> command to initialize the sensor.
C	“Obtaining Software”	Describes where to go to get the latest IPS software and describes the naming conventions.
D	“Upgrading, Downgrading, and Installing System Images”	Describes how to upgrade the sensor and reimage the sensor.
E	“Troubleshooting”	Contains troubleshooting tips for IPS hardware and software.
F	“Cable Pinouts”	Describes the pinouts for the sensor.
	“Glossary”	Contains IPS acronyms and terms.

## Conventions

This document uses the following conventions:

Convention	Indication
<b>bold font</b>	Commands and keywords and user-entered text appear in <b>bold font</b> .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[ ]	Elements in square brackets are optional.
{ x   y   z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



**Note**

Means *reader take note*.



**Tip**

Means *the following information will help you solve a problem*.



**Caution**

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



**Timesaver**

Means *the described action saves time*. You can save time by performing the action described in the paragraph.



**Warning**

**Means *reader be warned*. In this situation, you might perform an action that could result in bodily injury.**

## Related Documentation

For a complete list of the Cisco IPS 7.3 documentation and where to find it, refer to the following URL:

[http://www.cisco.com/en/US/docs/security/ips/7.3/roadmap/roadmap7\\_3.html](http://www.cisco.com/en/US/docs/security/ips/7.3/roadmap/roadmap7_3.html)

## Where to Find Safety and Warning Information

Before installing IPS sensors, read the regulatory compliance and safety information documents. These documents contain important safety information, such as the international agency compliance and safety information for the sensor. It also includes translations of the safety warnings. The following documents apply to the sensors in this document:

- *Regulatory Compliance and Safety Information for the Cisco ASA 5500-X Series Appliances and the Intrusion Prevention System 4300 Series Appliances*
- *Regulatory Compliance and Safety Information for the Cisco Intrusion Prevention System 4500 Series Appliance Sensor*

## Obtaining Documentation, Using the Cisco Bug Search Tool, and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at: <http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.

