



# Preface

---

## Overview

This document, *Cisco Video Surveillance 6000 Series IP Camera Configuration Guide*, provides information about installing and deploying the Cisco Video Surveillance 6000 Series IP Cameras.

See the [Release Notes for Cisco Video Surveillance IP Cameras](#) for the supported camera models and other important information in this release.

## Organization

This manual is organized as follows:

<a href="#">Chapter 1, “Overview”</a>	Provides information about the IP camera features, instructions for accessing the user interface, and information about the user interface.
<a href="#">Chapter 2, “Performing the Initial Setup of the IP Camera”</a>	Provides information and instructions about performing the initial setup of the IP Camera
<a href="#">Chapter 3, “Viewing Live Video”</a>	Provides information and instructions about viewing live video.
<a href="#">Chapter 4, “Feature Setup”</a>	Provides information and instructions for configuring IP camera features, such as streaming, camera capabilities, video overlay, I/O ports, and events.
<a href="#">Chapter 5, “Events”</a>	Provides information and instructions for configuring event notification and history settings, and for viewing event logs.
<a href="#">Chapter 6, “Local Storage”</a>	Provides information about enabling and configuring local storage, which allows you to store video on a local SD or MicroSD card.
<a href="#">Chapter 7, “Network Setup”</a>	Provides information and instructions for configuring network settings, such as IP addressing, time, discovery, IP filtering, and quality of service (QoS).
<a href="#">Chapter 8, “Application Manager”</a>	Provides information and instructions about using apps with the IP camera

<a href="#">Chapter 9, “Administration”</a>	Provides information and instructions for performing administrative tasks, such as IP camera initialization, user management, maintenance, firmware upgrade, device processes management, and password complexity.
<a href="#">Chapter 10, “Log Configuration”</a>	Provides information and instructions for configuring and viewing logs.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What’s New in Cisco Product Documentation* at: <http://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html>.

Subscribe to *What’s New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation as an RSS feed and delivers content directly to your desktop using a reader application. The RSS feeds are a free service.