



## U Commands

---

- [ui-idle-timeout-seconds](#), on page 2
- [unicast](#), on page 3
- [update-source ethernet](#), on page 4
- [update-source loopback](#), on page 5
- [update-source vlan](#), on page 6
- [usage](#), on page 7
- [use-bia](#), on page 8
- [use-keyring](#), on page 9
- [use-vrf](#), on page 10
- [user](#), on page 11
- [username](#), on page 12

# ui-idle-timeout-seconds

**ui-idle-timeout-seconds** <NUMBER>

**Description:** Set maximum GUI idle duration before requiring login refresh

**Syntax:**

<60-65525>	Set maximum GUI idle duration before requiring login refresh. Number range from=60 to=65525
------------	---

**Command Mode:** crypto webtoken : The cryptographic data used for generating and verifying web tokens.

**Command Path:**

```
# configure [['terminal', 't']]
(config)# crypto webtoken
(config-webtoken)# ui-idle-timeout-seconds <NUMBER>
```

# unicast

## unicast routing

**Description:** Instruct the fabric to route based on IP

**Syntax:**

routing	Unicast routing setting
---------	-------------------------

**Command Mode:** bridge-domain : Configuration for bridge-domain

**Command Path:**

```
# configure [['terminal', 't']]
(config)# tenant <WORD>
(config-tenant)# bridge-domain <WORD>
(config-tenant-bd)# unicast routing
```

# update-source ethernet

## update-source ethernet <interfaceRange>

**Description:** Source Ethernet Interface

**Syntax:**

<interfaceRange>	<interfaceRange>
------------------	------------------

**Command Mode:** neighbor : Configure a BGP neighbor

**Command Path:**

```
# configure [['terminal', 't']]
(config)# leaf <101-4000>
(config-leaf)# router bgp <fabric-ASN>
(config-leaf-bgp)# vrf member tenant <WORD> vrf <WORD>
(config-leaf-bgp-vrf)# neighbor A.B.C.D|A.B.C.D/LEN|A:B::C:D|A:B::C:D/LEN [evpn] [l3out
<WORD>]
(config-leaf-bgp-vrf-neighbor)# update-source ethernet <interfaceRange>
```

## update-source ethernet <interfaceRange>

**Description:** Source Ethernet Interface

**Syntax:**

<interfaceRange>	<interfaceRange>
------------------	------------------

**Command Mode:** neighbor : Configure a BGP neighbor

**Command Path:**

```
# configure [['terminal', 't']]
(config)# spine <101-4000>
(config-spine)# router bgp <fabric-ASN>
(config-leaf-bgp)# vrf member tenant <WORD> vrf <WORD>
(config-leaf-bgp-vrf)# neighbor A.B.C.D|A.B.C.D/LEN|A:B::C:D|A:B::C:D/LEN [evpn] [l3out
<WORD>]
(config-leaf-bgp-vrf-neighbor)# update-source ethernet <interfaceRange>
```

# update-source loopback

## update-source loopback <A.B.C.D>

**Description:** Source Loopback Interface

**Syntax:**

<i>A.B.C.D</i>	IPv4 or IPv6 Address without mask
----------------	-----------------------------------

**Command Mode:** neighbor : Configure a BGP neighbor

**Command Path:**

```
# configure [['terminal', 't']]
(config)# leaf <101-4000>
(config-leaf)# router bgp <fabric-ASN>
(config-leaf-bgp)# vrf member tenant <WORD> vrf <WORD>
(config-leaf-bgp-vrf)# neighbor A.B.C.D|A.B.C.D/LEN|A:B::C:D|A:B::C:D/LEN [evpn] [l3out
<WORD>]
(config-leaf-bgp-vrf-neighbor)# update-source loopback <A.B.C.D>
```

## update-source loopback <A.B.C.D>

**Description:** Source Loopback Interface

**Syntax:**

<i>A.B.C.D</i>	IPv4 or IPv6 Address without mask
----------------	-----------------------------------

**Command Mode:** neighbor : Configure a BGP neighbor

**Command Path:**

```
# configure [['terminal', 't']]
(config)# spine <101-4000>
(config-spine)# router bgp <fabric-ASN>
(config-leaf-bgp)# vrf member tenant <WORD> vrf <WORD>
(config-leaf-bgp-vrf)# neighbor A.B.C.D|A.B.C.D/LEN|A:B::C:D|A:B::C:D/LEN [evpn] [l3out
<WORD>]
(config-leaf-bgp-vrf-neighbor)# update-source loopback <A.B.C.D>
```

# update-source vlan

## update-source vlan <vlan>

**Description:** Source Vlan Interface

**Syntax:**

<vlan>	Vlan ID
--------	---------

**Command Mode:** neighbor : Configure a BGP neighbor

**Command Path:**

```
# configure [['terminal', 't']]
(config)# leaf <101-4000>
(config-leaf)# router bgp <fabric-ASN>
(config-leaf-bgp)# vrf member tenant <WORD> vrf <WORD>
(config-leaf-bgp-vrf)# neighbor A.B.C.D|A.B.C.D/LEN|A:B::C:D|A:B::C:D/LEN [evpn] [l3out
<WORD>]
(config-leaf-bgp-vrf-neighbor)# update-source vlan <vlan>
```

## update-source vlan <vlan>

**Description:** Source Vlan Interface

**Syntax:**

<vlan>	Vlan ID
--------	---------

**Command Mode:** neighbor : Configure a BGP neighbor

**Command Path:**

```
# configure [['terminal', 't']]
(config)# spine <101-4000>
(config-spine)# router bgp <fabric-ASN>
(config-leaf-bgp)# vrf member tenant <WORD> vrf <WORD>
(config-leaf-bgp-vrf)# neighbor A.B.C.D|A.B.C.D/LEN|A:B::C:D|A:B::C:D/LEN [evpn] [l3out
<WORD>]
(config-leaf-bgp-vrf-neighbor)# update-source vlan <vlan>
```

# usage

**usage** <resource-type>

**Description:** Show deployment usage

**Syntax:**

<i>resource-type</i>	Resource type consuming the policy
----------------------	------------------------------------

**Command Mode:** configure : Configuration Mode

**Command Path:**

```
# configure [['terminal', 't']]
(config)# usage <resource-type>
```

# use-bia

## use-bia

**Description:** HSRP uses interfaces burned in address

**Command Mode:** template hsrp interface-policy : Configure HSRP Interface policy templates

**Command Path:**

```
# configure [['terminal', 't']]
(config)# leaf <101-4000>
(config-leaf)# template hsrp interface-policy <WORD> tenant <WORD>
(config-template-hsrp-if-pol)# use-bia
```

## use-bia

**Description:** HSRP uses interfaces burned in address

**Command Mode:** template hsrp interface-policy : Configure HSRP Interface policy templates

**Command Path:**

```
# configure [['terminal', 't']]
(config)# spine <101-4000>
(config-spine)# template hsrp interface-policy <WORD> tenant <WORD>
(config-template-hsrp-if-pol)# use-bia
```



# use-keyring

**use-keyring** <keyring-name>

**Description:** Use specified keyring for the HTTPS Server SSL certificate

**Syntax:**

<i>keyring-name</i>	Keyring name (Max Size 64)
---------------------	----------------------------

**Command Mode:** https : HTTPS communication policy group

**Command Path:**

```
# configure [['terminal', 't']]
(config)# comm-policy <WORD>
(config-comm-policy)# https
(config-https)# use-keyring <keyring-name>
```

# use-vrf

**use-vrf <arg>**

**Description:** Configure the management vrf for dns servers

**Syntax:**

<i>arg</i>	Configure management vrf
------------	--------------------------

**Command Mode:** dns : Configure default dns policy

**Command Path:**

```
# configure [['terminal', 't']]
(config)# dns
(config-dns)# use-vrf <>
```

# user

**user <WORD>**

**Description:** Set the remote path user name and password

**Syntax:**

<i>WORD</i>	User name
-------------	-----------

**Command Mode:** remote : Remote path configuration mode

**Command Path:**

```
# configure [['terminal', 't']]
(config)# remote path <WORD>
(config-remote)# user <WORD>
```

**user <user-name>**

**Description:** User Name

**Syntax:**

<i>user-name</i>	User Name
------------------	-----------

**Command Mode:** external-switch-node : External Switch Node

**Command Path:**

```
# configure [['terminal', 't']]
(config)# system external-switch-group <group-name>
(config-external-switch-group)# external-switch-node <node-name>
(config-external-switch-node)# user <user-name>
```

# username

## username <WORD>

**Description:** Create a locally-authenticated user account

**Syntax:**

<i>WORD</i>	User name (Max Size 32)
-------------	-------------------------

**Command Mode:** configure : Configuration Mode

**Command Path:**

```
# configure [['terminal', 't']]
(config)# username <WORD>
```

## username <WORD>

**Description:** Configure a user account for the vCenter

**Syntax:**

<i>WORD</i>	Username for the account
-------------	--------------------------

**Command Mode:** vcenter : Configure a vCenter in the VMware domain

**Command Path:**

```
# configure [['terminal', 't']]
(config)# vmware-domain <WORD> [delimiter <WORD>] [access-mode <access-mode>]
(config-vmware)# vcenter <> datacenter <WORD> [dvs-version <>]
(config-vmware-vc)# username <WORD>
```

## username <WORD>

**Description:** Configure a user account for the RHEV controller

**Syntax:**

<i>WORD</i>	Username for the account
-------------	--------------------------

**Command Mode:** rhev : Configure an RHEV controller in the Redhat domain

**Command Path:**

```
# configure [['terminal', 't']]
(config)# rhev-domain <WORD> [delimiter <WORD>]
(config-redhat)# rhev <> datacenter <WORD>
(config-redhat-rhev)# username <WORD>
```