



## Preface

---

This preface describes the audience, organization, and conventions of the *Cisco Nexus 2000 Series Fabric Extender Software Configuration Guide*. It also provides information on how to obtain related documentation.

- [Audience, page i](#)
- [Document Organization, page i](#)
- [Document Conventions, page ii](#)
- [Related Documentation, page iii](#)
- [Obtaining Documentation and Submitting a Service Request, page iii](#)

## Audience

This guide is for experienced network administrators who are responsible for configuring and maintaining the Cisco Nexus 2000 Series Fabric Extender.

## Document Organization

This document is organized into the following chapters:

Chapter	Description
<a href="#">New and Changed Information for the Cisco Nexus 2000 Series</a>	Lists the new and changed information in this document.
<a href="#">Fabric Extender Architectural Overview</a>	Provides an overview of the Cisco Nexus 2000 Series Fabric Extender including details of the supported features.
<a href="#">Configuring the Fabric Extender</a>	Provides the instructions of how to configure the Cisco Nexus 2000 Series Fabric Extender.

# Document Conventions

Command descriptions use the following conventions:

Convention	Description
<b>bold</b>	Bold text indicates the commands and keywords that you enter literally as shown.
<i>Italic</i>	Italic text indicates arguments for which the user supplies the values.
[x]	Square brackets enclose an optional element(keyword or argument).
[x   y]	Square brackets enclosing keywords or arguments separated by a vertical bar indicate an optional choice.
{x   y}	Braces enclosing keywords or arguments separated by a vertical bar indicate a required choice.
[x {y   z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
variable	Indicates a variable for which you supply values, in context where italics cannot be used.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use the following conventions:

Convention	Description
screen font	Terminal sessions and information the switch displays are in screen font.
<b>boldface screen font</b>	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
<>	Nonprinting characters, such as passwords, are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

## Related Documentation

Documentation for the Cisco Nexus 2000 Series Fabric Extender is available at the following URL:

[http://www.cisco.com/en/US/products/ps10110/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps10110/tsd_products_support_series_home.html)

The following are related documents for the Cisco Nexus 2000 Series Fabric Extender:

- *Cisco Nexus 2000 Series Fabric Extender NX-OS Software Configuration Guide*
- *Cisco Nexus 2000 Series Fabric Extender Hardware Installation Guide*
- *Cisco NX-OS Licensing Configuration Guide*

Documentation for Cisco Nexus 5000 Series switches is available at the following URL:

[http://www.cisco.com/en/us/products/ps9670/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/us/products/ps9670/tsd_products_support_series_home.html)

The following are related documents for the Cisco Nexus 5000 Series:

- *Cisco Nexus 5000 Series Command Reference*
- *Cisco Nexus 5000 Series Hardware Installation Guide*
- *Cisco Nexus 5000 Series System Messages Reference*
- *Cisco MDS 9000 and Nexus 5000 Series Fabric Manager Software Configuration Guide*

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at <http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>.

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

