



A Commands

This chapter describes the Cisco NX-OS Enhanced Interior Gateway Routing Protocol (EIGRP) commands that begin with A.

address-family (EIGRP)

To configure an address family for the Enhanced Interior Gateway Routing Protocol (EIGRP), use the **address-family** command. To remove an address family, use the **no** form of this command.

address-family ipv4 unicast

no address-family ipv4 unicast

Syntax Description	Command	Description
	ipv4	Specifies the IPv4 address family.
	unicast	Specifies unicast address support.

Command Default	None
-----------------	------

Command Modes	Router configuration mode Address family configuration mode
---------------	--

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
------------------	--

Examples	This example shows how to set the IPv4 unicast address family for an EIGRP instance:
	<pre>switch(config)# router eigrp 201 switch(config-router)# address-family ipv4 unicast switch(config-router)#</pre>

Related Commands	Command	Description
	default-information	Controls the distribution of a default route.
	default-metric	Configures the default metric for routes redistributed into EIGRP.
	distance	Configures the administrative distance.
	maximum-paths	Configures the maximum number of equal-cost paths.
	redistribute	Configures route redistribution for EIGRP.
	router-id	Configures the router ID.
	show ip eigrp	Displays EIGRP information.
	timers	Configures the EIGRP timers.

authentication key-chain (EIGRP)

To enable authentication for the Enhanced Interior Gateway Routing Protocol (EIGRP) packets and to specify the set of keys that can be used on an interface, use the **authentication key-chain** command. To prevent authentication, use the **no** form of this command.

authentication key-chain *name-of-chain*

no authentication key-chain *name-of-chain*

Syntax Description	<i>name-of-chain</i>	Group of keys that are valid.
---------------------------	----------------------	-------------------------------

Command Default	No authentication is provided for EIGRP packets.
------------------------	--

Command Modes	Router configuration mode Address family configuration mode VRF configuration mode
----------------------	--

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines Set the authentication mode using the **authentication mode** command in VRF configuration mode. You must separately configure a key chain using the **key-chain** command to complete the authentication configuration for an interface.

This command requires the LAN Base Services license.

Examples This example shows how to configure the interface to accept and send any key that belongs to the key-chain trees:

```
switch(config)# router eigrp 209
switch(config-router)# vrf red
switch(config-router-vrf)# authentication key-chain trees
```

Related Commands	Command	Description
	authentication mode (EIGRP)	Sets the authentication mode for EIGRP in a VRF.
	ip authentication key-chain eigrp	Enables authentication for EIGRP and specifies the set of keys that can be used on an interface.
	key-chain	Creates a set of keys that can be used by an authentication method.
	show ip eigrp	Displays EIGRP information.

authentication mode (EIGRP)

To specify the type of authentication used in the Enhanced Interior Gateway Routing Protocol (EIGRP) packets, use the **authentication mode** command. To remove authentication, use the **no** form of this command.

authentication mode md5

no authentication mode md5

Syntax Description	md5	Specifies Message Digest 5 (MD5) authentication.
---------------------------	------------	--

Command Default	None
------------------------	------

Command Modes	Router configuration mode Address family configuration mode VRF configuration mode
----------------------	--

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
-------------------------	--

Examples	This example shows how to configure the interface to use MD5 authentication:
-----------------	--

```
switch(config)# router eigrp 209
switch(config-router)# vrf red
switch(config-router-vrf)# authentication mode md5
switch(config-router-vrf)#
```

Related Commands	Command	Description
	authentication key-chain eigrp	Enables authentication for EIGRP and specifies the set of keys that can be used on an interface.
	ip authentication mode eigrp	Configures the authentication mode for EIGRP on an interface.
	key chain	Creates a set of keys that can be used by an authentication method.
	show ip eigrp	Displays EIGRP information.

autonomous-system

To configure the autonomous system (AS) number for an Enhanced Interior Gateway Routing Protocol (EIGRP) address family, use the **autonomous-system** command. To revert to default, use the **no** form of this command.

autonomous-system *as-number*

no autonomous-system [*as-number*]

Syntax Description	<i>as-number</i>	Autonomous system number. The range is from 1 to 65535.				
Command Default	None					
Command Modes	Address family configuration mode					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>5.2(1)N1(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	5.2(1)N1(1)	This command was introduced.	
Release	Modification					
5.2(1)N1(1)	This command was introduced.					
Usage Guidelines	<p>Use the autonomous-system command to set a common AS number for all EIGRP instances in an address family.</p> <p>This command requires the LAN Base Services license.</p>					
Examples	<p>This example shows how to set an AS number for EIGRP for IPv4 unicast:</p> <pre>switch(config)# router eigrp 201 switch(config-router)# address-family ipv4 unicast switch(config-router-af)# autonomous-system 64496 switch(config-router-af)#</pre>					
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>address-family (EIGRP)</td> <td>Enters the address family configuration mode for EIGRP.</td> </tr> </tbody> </table>	Command	Description	address-family (EIGRP)	Enters the address family configuration mode for EIGRP.	
Command	Description					
address-family (EIGRP)	Enters the address family configuration mode for EIGRP.					

