



## W Commands

---

This chapter describes the Cisco NX-OS Fibre Channel, virtual Fibre Channel, and Fibre Channel over Ethernet (FCoE) commands that begin with W.

## wwn secondary-mac

To allocate a secondary MAC address to a SAN node, use the **wwn secondary-mac** command.

**wwn secondary-mac** *wwn-id* **range** *address-range*

<b>Syntax Description</b>	<i>wwn-id</i>	Secondary MAC address with the format <i>hh:hh:hh:hh:hh:hh</i> .
	<b>range</b> <i>address-range</i>	Specifies the range for the specified WWN. The only valid value is 64.

**Command Modes** Global configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.0(2)N1(1)	This command was introduced.

**Usage Guidelines** This command cannot be undone.

Changes to the worldwide names are only performed as required. They should not be changed on a daily basis. These changes should be made by an administrator or individual who is completely familiar with switch operations.

**Examples** This example shows how to allocate a secondary range of MAC addresses:

```
switch(config)# wwn secondary-mac 00:99:55:77:55:55 range 64
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show wwn</b>	Displays the status of the WWN configuration.

## wwn vsan

To configure a WWN for a suspended Virtual SAN (VSAN) that has interop mode 4 enabled, use the **wwn vsan** command. To discard the configuration, use the **no** form of this command.

```
wwn vsan vsan-id vsan-wwn wwn
```

```
no wwn vsan vsan-id vsan-wwn wwn
```

Syntax Description	
<i>vsan-id</i>	VSAN ID. The range is from 1 to 4093.
<b>vsan-wwn</b> <i>wwn</i>	Specifies the WWN for the VSAN. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> .

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

**Usage Guidelines** This command can succeed only if the following conditions are satisfied:

- The VSAN must be suspended.
- The VSAN must have interop mode 4 enabled before you can specify the switch WWN for it.
- The switch WWN must be unique throughout the entire fabric.
- The configured switch WWN must have McData OUI [08:00:88].

**Examples** This example shows how to assign a WWN to a VSAN:

```
switch(config)# wwn vsan 100 vsan-wwn 20:64:08:00:88:0d:5f:81
switch(config)# vsan database
switch(config-vsan-db)# vsan 100 suspend
switch(config-vsan-db)# exit
switch(config)# wwn vsan 100 vsan-wwn 20:64:08:00:88:0d:5f:81
```

Related Commands	Command	Description
	<b>vsan database</b>	Creates multiple fabrics sharing the same physical infrastructure, assigns ports to a VSAN, turns on or off interop mode, load balances either per originator exchange or source-destination ID, and creates VSAN membership.

