



# QoS Configuration Examples

---

This chapter contains the following sections:

- [QoS Example 1 , on page 1](#)
- [QoS Example 2 , on page 2](#)
- [QoS Example 3 , on page 4](#)

## QoS Example 1

This example shows how to configure traffic in the entire system matching an access control list to have the frame CoS fields rewritten to the value 5.

### Procedure

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Set up the ingress classification policy (the access control list was defined previously).	<pre>(config)# class-map type qos cmap-qos-acl (config-cmap-qos) # match access-group ACL-CoS  (config-cmap-qos) # exit  (config)# policy-map type qos pmap-qos-acl  (config-pmap-qos) # class cmap-qos-acl (config-pmap-c-qos) # set qos-group 4 (config-pmap-c-qos) # exit (config-pmap-qos) # exit</pre>
<b>Step 2</b>	Attach the classification policy to the system.	<pre>(config)# system qos  (config-sys-qos) # service-policy type qos input pmap-qos-acl  (config-sys-qos) # exit</pre>
<b>Step 3</b>	Set up the system class allocation and rewrite policy. Allocate the system class for qos-group 4 and define the rewrite action.	<pre>(config)# class-map type network-qos cmap-nq-acl  (config-cmap-nq) # match qos-group 4</pre>

## QoS Example 2

	<b>Command or Action</b>	<b>Purpose</b>
		<pre>(config-cmap-nq) # exit (config) # policy-map type network-qos pmap-nq-acl (config-pmap-nq) # class type network-qos cmap-nq-acl (config-pmap-c-nq) # set cos 5 (config-pmap-c-nq) # exit (config-pmap-nq) # exit</pre>
<b>Step 4</b>	Attach the allocation and rewrite policy to the system.	<pre>(config) # system qos (config-sys-qos) # service-policy type network-qos pmap-nq-acl (config-sys-qos) # exit</pre>

## QoS Example 2

This example shows how to use an access control list to apply 50% bandwidth to traffic on Ethernet interface 1/3 that matches traffic on Ethernet interface 1/1.

### Procedure

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Set up the ingress classification policy.	<pre>(config) # class-map type qos cmap-qos-bandwidth (config-cmap-qos) # match access-group ACL-bandwidth (config-cmap-qos) # exit (config) # policy-map type qos pmap-qos-eth1-1 (config-pmap-qos) # class cmap-qos-bandwidth (config-pmap-c-qos) # set qos-group 2 (config-pmap-c-qos) # exit (config-pmap-qos) # exit</pre>
<b>Step 2</b>	Attach the classification policy to the interface Ethernet 1/1.	<pre>(config) # interface ethernet 1/1 (config-if) # service-policy type qos input pmap-qos-eth1-1 (config-if) # exit</pre>

	Command or Action	Purpose
<b>Step 3</b>	Set up the system-wide definition of the qos-group first.	(config) # <b>class-map type queuing cmap-que-bandwidth</b> (config-cmap-que) # <b>match qos-group 2</b> (config-cmap-que) # <b>exit</b>
<b>Step 4</b>	Set up the egress bandwidth policy.	<b>Note</b> Before you can successfully allocate bandwidth to the user-defined class cmap-que-bandwidth, you must first reduce the default bandwidth configuration on class-default and class-fcoe.  (config) # <b>policy-map type queuing pmap-que-eth1-2</b> (config-pmap-que) # <b>class type queuing class-default</b> (config-pmap-c-que) # <b>bandwidth percent 10</b> (config-pmap-c-que) # <b>exit</b> (config-pmap-que) # <b>class type queuing class-fcoe</b> (config-pmap-c-que) # <b>bandwidth percent 40</b> (config-pmap-c-que) # <b>exit</b> (config-pmap-que) # <b>class type queuing cmap-que-bandwidth</b> (config-pmap-c-que) # <b>bandwidth percent 50</b> (config-pmap-c-que) # <b>exit</b> (config-pmap-que) # <b>exit</b>
<b>Step 5</b>	Attach the bandwidth policy to the egress interface.	(config) # <b>interface ethernet 1/3</b> (config-if) # <b>service-policy type queuing output pmap-que-eth1-2</b> (config-if) # <b>exit</b>
<b>Step 6</b>	Allocate the system class for qos-group 2.	(config) # <b>class-map type network-qos cmap-nq-bandwidth</b> (config-cmap-nq) # <b>match qos-group 2</b> (config-cmap-nq) # <b>exit</b>
<b>Step 7</b>	Set up the network-qos policy.	(config) # <b>policy-map type network-qos pmap-nq-bandwidth</b>

## QoS Example 3

	<b>Command or Action</b>	<b>Purpose</b>
		<pre>(config-pmap-nq) # class type network-qos cmap-nq-bandwidth (config-pmap-c-nq) # exit (config-pmap-nq) # exit</pre>
<b>Step 8</b>	Attach the network-qos policy to the system.	<pre>(config) # system qos (config-sys-qos) # service-policy type network-qos pmap-nq-bandwidth (config-sys-qos) # exit</pre>

## QoS Example 3

This example shows how to attach a 802.1p tag with a CoS value of 3 to incoming untagged packets, and force priority-flow-control negotiation on Ethernet interface 1/15.

### Procedure

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Set up the ingress classification policy (the access control list was defined previously).	<pre>(config) # interface Ethernet 1/15 (config-if) # untagged cos 3 (config-if) # priority-flow-control mode on (config-if) # exit</pre>