



N Commands

- [show nbm controller, on page 3](#)
- [show nbm flows, on page 4](#)
- [show nbm flows bandwidth, on page 5](#)
- [show nbm flows statistics, on page 6](#)
- [show ngoam interface statistics, on page 7](#)
- [show ngoam probe, on page 8](#)
- [show ngoam role, on page 10](#)
- [show npv external-interface-usage, on page 11](#)
- [show npv flogi-table, on page 12](#)
- [show npv status, on page 13](#)
- [show npv traffic-map, on page 14](#)
- [show npv traffic-usage, on page 15](#)
- [show ntp access-groups, on page 16](#)
- [show ntp authentication-keys, on page 17](#)
- [show ntp authentication-status, on page 18](#)
- [show ntp logging-status, on page 19](#)
- [show ntp peer-status, on page 20](#)
- [show ntp peers, on page 21](#)
- [show ntp rts-update, on page 22](#)
- [show ntp session status, on page 23](#)
- [show ntp source-interface, on page 24](#)
- [show ntp source, on page 25](#)
- [show ntp statistics, on page 26](#)
- [show ntp status, on page 29](#)
- [show ntp trusted-keys, on page 30](#)
- [show nve bfd neighbors, on page 31](#)
- [show nve interface, on page 32](#)
- [show nve peers, on page 33](#)
- [show nve peers interface counters, on page 35](#)
- [show nve peers vni interface counters, on page 36](#)
- [show nve replication-servers, on page 37](#)
- [show nve vni, on page 38](#)
- [show nve vni counters, on page 40](#)

- [show nve vni ingress-replication](#), on page 41
- [show nve vni peer-vtep](#), on page 42
- [show nve vrf](#), on page 43
- [show nve vxlan-params](#), on page 44
- [show nxapi-server logs](#), on page 45
- [show nxapi](#), on page 46
- [show nxapi retries](#), on page 47

show nbm controller

show nbm controller

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
controller	Controller mode information

Command Mode

- /exec

show nbm flows

show nbm flows [active | all | group-based | m-group <group-ip-id>] [interface <if-name>]

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
flows	NBM flows
active	(Optional) Active flows
all	(Optional) Both active and deleted flows
group-based	(Optional) Multicast group based (*,G) flows to IGMP receivers
m-group	(Optional) Multicast group
<i>group-ip-id</i>	(Optional) Multicast group address
interface	(Optional) Ingress port
<i>if-name</i>	(Optional) Interface name

Command Mode

- /exec

show nbm flows bandwidth

show nbm flows bandwidth

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
flows	NBM flows
bandwidth	Per Flow Bandwidth in Mbps

Command Mode

- /exec

show nbm flows statistics

show nbm flows statistics [group-based | m-group <group-ip-id>] [interface <if-name>]

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
flows	NBM flows
statistics	Flow statistics
group-based	(Optional) Multicast group based (*,G) flows to IGMP receivers
m-group	(Optional) Multicast group
<i>group-ip-id</i>	(Optional) Multicast group address
interface	(Optional) Ingress port
<i>if-name</i>	(Optional) Interface name

Command Mode

- /exec

show ngoam interface statistics

```
show ngoam interface statistics [ __readonly__ [ TABLE_stats { <interface-name> <tx> <rx> } <statistics-end> ] ]
```

Syntax Description

TABLE_stats	(Optional) interface statistics table
<i>interface-name</i>	(Optional) interface namestring
<i>tx</i>	(Optional) ngoam probe transmit on the interface
<i>rx</i>	(Optional) ngoam probe receive on the interface
show	Show running system information
ngoam	ngoam
interface	probe packet interface
statistics	ngoam probe interface statistics
__readonly__	(Optional) Read Only
<i>statistics-end</i>	(Optional) statistics table end marker

Command Mode

- /exec

show ngoam probe

```
show ngoam probe { { statistics { summary | { session { <handle> | all } } } } [ __readonly__ [ TABLE_stats
{ <sender-handle> <transaction-id> <dst-vip> <vni> <oam-type> <flow-str> <last-clear-stats> <req-sent>
<req-not-sent> } <statistics-end> ] [ TABLE_summary { <last-clear-summary-stats> <tx> <rx> <timeout>
<unsent> <resp-tx> <resp-rx> <resp-unsent> } ] ]
```

Syntax Description

show	Show running system information
ngoam	ngoam
probe	ngoam probe
statistics	ngoam probe statistics
summary	ngoam probe statistics summary
session	ngoam probe session
<i>handle</i>	ngoam probe session handle
all	Display results for all probe sessions
TABLE_stats	(Optional) statistics table
<i>sender-handle</i>	(Optional) sender handle
<i>transaction-id</i>	(Optional) Transaction Identifier
<i>dst-vip</i>	(Optional) Destination Vtep ip address
<i>vni</i>	(Optional) vxlan header vni
<i>oam-type</i>	(Optional) draft pang oam type
<i>flow-str</i>	(Optional) 128 byte flow string.
<i>last-clear-stats</i>	(Optional) last clear time for statistics
<i>req-sent</i>	(Optional) request sent
<i>req-not-sent</i>	(Optional) request not sent or failed
<i>statistics-end</i>	(Optional) statistics table end marker
TABLE_summary	(Optional) statistics summary table
<i>last-clear-summary-stats</i>	(Optional) last clear time for summary statistics
<i>tx</i>	(Optional) summary request sent
<i>rx</i>	(Optional) summary reply received

<i>timeout</i>	(Optional) summary timeout
<i>unsent</i>	(Optional) summary unsent
<i>resp-tx</i>	(Optional) summary resp tx
<i>resp-rx</i>	(Optional) summary resp rx
<i>resp-unsent</i>	(Optional) summary resp unsent
<i>__readonly__</i>	(Optional) Read Only

Command Mode

- /exec

show ngoam role

show ngoam role

Syntax Description

show	Show running system information
ngoam	ngoam information
role	show draft pang derived role info

Command Mode

- /exec

show npv external-interface-usage

show npv external-interface-usage [server-interface <if0>]

Syntax Description

show	Show running system information
npv	Show information about NPV
external-interface-usage	Show external interface usage by server interfaces
server-interface	(Optional) Show external interface usage by a server interface
<i>if0</i>	(Optional)

Command Mode

- /exec

show npv flogi-table

```
show npv flogi-table [ { interface <if0> | vsan <i0> } ]
```

Syntax Description

show	Show running system information
npv	Show information about NPV
flogi-table	Show information about FLOGI sessions
interface	(Optional) Show information about FLOGI sessions for a server interface
<i>if0</i>	(Optional)
vsan	(Optional) Show information about FLOGI sessions for a VSAN
<i>i0</i>	(Optional)

Command Mode

- /exec

show npv status

show npv status [vsan <i0>]

Syntax Description

show	Show running system information
npv	Show information about NPV
status	Show NPV status
vsan	(Optional) Show NPV status for a specific VSAN
<i>i0</i>	(Optional)

Command Mode

- /exec

show npv traffic-map

show npv traffic-map [server-interface <if0>]

Syntax Description

show	Show running system information
npv	Show information about NPV
traffic-map	Show information about Traffic Map
server-interface	(Optional) Show information about Traffic map for a server interface
<i>if0</i>	(Optional)

Command Mode

- /exec

show npv traffic-usage

show npv traffic-usage [server-interface <if0>]

Syntax Description

show	Show running system information
npv	Show information about NPV
traffic-usage	Show information about Traffic Usage
server-interface	(Optional) Show Traffic usage for a server interface
<i>if0</i>	(Optional)

Command Mode

- /exec

show ntp access-groups

```
show ntp access-groups [ __readonly__ [ { TABLE_accessgroups <accesslist> [ <type> } ] ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
access-groups	Display NTP access groups
__readonly__	(Optional)
TABLE_accessgroups	(Optional) accessgroups
<i>accesslist</i>	(Optional) accesslist
<i>type</i>	(Optional) type

Command Mode

- /exec

show ntp authentication-keys

```
show ntp authentication-keys [ __readonly__ [ { TABLE_authkeys <Authkey> [ <MD5String> } ] ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
authentication-keys	Display authentication keys
__readonly__	(Optional)
TABLE_authkeys	(Optional) authentication keys
<i>Authkey</i>	(Optional) authentication key
<i>MD5String</i>	(Optional) password

Command Mode

- /exec

show ntp authentication-status

```
show ntp authentication-status [ __readonly__ [ <authentication> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
authentication-status	NTP Authentication Status
<i>__readonly__</i>	(Optional)
<i>authentication</i>	(Optional) authentication enabled/disabled

Command Mode

- /exec

show ntp logging-status

```
show ntp logging-status [ __readonly__ [ <loggingstatus> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
logging-status	Display NTP logging status
__readonly__	(Optional)
<i>loggingstatus</i>	(Optional) logging enabled/disabled

Command Mode

- /exec

show ntp peer-status

```
show ntp peer-status [ __readonly__ [ <totalpeers> ] [ { TABLE_peersstatus <syncmode> <remote> <local>
<st> <poll> <reach> <delay> [ <vrf> ] } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
peer-status	Show the status for all the server/peers
<i>__readonly__</i>	(Optional)
<i>totalpeers</i>	(Optional) totalpeers
TABLE_peersstatus	(Optional) peersstatus
<i>syncmode</i>	(Optional) peermode
<i>remote</i>	(Optional) remote addr
<i>local</i>	(Optional) local addr
<i>st</i>	(Optional) stratum
<i>poll</i>	(Optional) ntp poll
<i>reach</i>	(Optional) reach
<i>delay</i>	(Optional) delay
<i>vrf</i>	(Optional) vrf name

Command Mode

- /exec

show ntp peers

```
show ntp peers [ __readonly__ [ { TABLE_peers <PeerIPAddress> <serv_peer> <conf_flag> } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
peers	Show all the peers.
__readonly__	(Optional)
TABLE_peers	(Optional) peers
<i>PeerIPAddress</i>	(Optional) peer Ip addr
<i>serv_peer</i>	(Optional) server or peer
<i>conf_flag</i>	(Optional) configured or dynamic

Command Mode

- /exec

show ntp rts-update

```
show ntp rts-update [ __readonly__ [ <rtsupdate> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
rts-update	Show if the RTS update is enabled
__readonly__	(Optional)
<i>rtsupdate</i>	(Optional) rts update enabled/disabled

Command Mode

- /exec

show ntp session status

```
show ntp session status [ __readonly__ [ <session_status> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
session	Show the session information
status	Show the session status
<i>__readonly__</i>	(Optional)
<i>session_status</i>	(Optional) last session status

Command Mode

- /exec

show ntp source-interface

```
show ntp source-interface [ __readonly__ [ <sourceinterface> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
source-interface	Source interface configured
__readonly__	(Optional)
<i>sourceinterface</i>	(Optional) source interface

Command Mode

- /exec

show ntp source

```
show ntp source [ __readonly__ [ <sourceip> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
source	Source IP address configured
__readonly__	(Optional)
<i>sourceip</i>	(Optional) source ip addr

Command Mode

- /exec

show ntp statistics

```
show ntp statistics { [ io ] | [ local ] | [ memory ] | peer { ipaddr { <ipv4_0> | <ipv6_1> } | name <s0> } } [
__readonly__ [ { <iotimesincereset> <ioreceivebuffers> <iofreereceivebuffers> <iousedreceivebuffers>
<iolowwaterrefills> <iodroppedpackets> <ioignoredpackets> <ioreceivedpackets> <iopacketsent>
<iopacketsnotsent> <iointerruptshandled> <ioreceivedbyint> } ] [ { <localsystemuptime> <localtimesincereset>
<localoldversionpackets> <localnewversionpackets> <localunknownversionnumber> <localbadpacketformat>
<localpacketsprocessed> <localbadauthentication> [ <localpacketsrejected> ] } ] [ { <memtimesincereset>
<memtotalpeermemory> <memfreepeermemory> <memcallstofindpeer> <memnewpeerallocations>
<mempeerdemobilizations> <memhashtablecounts> } ] [ { <peeripremotehost> <peeriplocalinterface>
<peeriptimelastreceived> <peeriptimeuntilnextsend> <peeripreachabilitychange> <peerippacketsent>
<peerippacketsreceived> <peeripbadauthentication> <peeripbogusorigin> <peeripduplicate>
<peeripbaddispersion> <peeripbadreferencetime> <peeripcandidateorder> } ] [ { <peernameremotehost>
<peernamelocalinterface> <peernametimelastreceived> <peernametimeuntilnextsend>
<peernamereachabilitychange> <peernamepacketsent> <peernamepacketsreceived>
<peernamebadauthentication> <peernamebogusorigin> <peernameduplicate> <peernameduplicate>
<peernamebaddispersion> <peernamebadreferencetime> <peernamecandidateorder> } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
statistics	Show the NTP statistics
io	(Optional) Show the input-output statistics.
local	(Optional) Show the counters maintained by the local NTP.
memory	(Optional) Show the statistics counters related to memory code.
peer	Show the per-peer statistics counter of a peer.
ipaddr	Peer's IP address
<i>ipv4_0</i>	
name	Peer's Name
<i>s0</i>	
<i>__readonly__</i>	(Optional)
<i>iotimesincereset</i>	(Optional) time since reset
<i>ioreceivebuffers</i>	(Optional) receive buffers
<i>iofreereceivebuffers</i>	(Optional) free receive buffers
<i>iousedreceivebuffers</i>	(Optional) used receive buffers
<i>iolowwaterrefills</i>	(Optional) low water refills

<i>iodroppedpackets</i>	(Optional) dropped packets
<i>ioignoredpackets</i>	(Optional) ignored packets
<i>ioreceivedpackets</i>	(Optional) received packets
<i>iopacketsent</i>	(Optional) packets sent
<i>iopacketsnotsent</i>	(Optional) packets not sent
<i>iointerruptshandled</i>	(Optional) interrupts handled
<i>ioreceivedbyint</i>	(Optional) received by int
<i>localsystemuptime</i>	(Optional) system up time
<i>localtimesincereset</i>	(Optional) time since reset
<i>localoldversionpackets</i>	(Optional) old version packets
<i>localnewversionpackets</i>	(Optional) new version packets
<i>localunknownversionnumber</i>	(Optional) unknown version number
<i>localbadpacketformat</i>	(Optional) bad packet format
<i>localpacketsprocessed</i>	(Optional) packets processed
<i>localbadauthentication</i>	(Optional) bad authentication
<i>localpacketsrejected</i>	(Optional) packets rejected
<i>memtimesincereset</i>	(Optional) time since reset
<i>memtotalpeermemory</i>	(Optional) total peer memory
<i>memfreepeermemory</i>	(Optional) free peer memory
<i>memcallstofindpeer</i>	(Optional) calls to find peer
<i>memnewpeerallocations</i>	(Optional) new peer allocations
<i>mempeerdemobilizations</i>	(Optional) peer demobilizations
<i>memhashtablecounts</i>	(Optional) hash table counts
<i>peeripremotehost</i>	(Optional) peeripremotehost
<i>peeriplocalinterface</i>	(Optional) peeriplocalinterface
<i>peeriptimelastreceived</i>	(Optional) peeriptimelastreceived
<i>peeriptimeuntilnextsend</i>	(Optional) peeriptimeuntilnextsend
<i>peeripreachabilitychange</i>	(Optional) peeripreachabilitychange
<i>peerippacketsent</i>	(Optional) peerippacketsent

<i>peerippacketsreceived</i>	(Optional) peerippacketsreceived
<i>peeripbadauthentication</i>	(Optional) peeripbadauthentication
<i>peeripbogusorigin</i>	(Optional) peeripbogusorigin
<i>peeripduplicate</i>	(Optional) peeripduplicate
<i>peeripbaddispersion</i>	(Optional) peeripbaddispersion
<i>peeripbadreferencetime</i>	(Optional) peeripbadreferencetime
<i>peeripcandidateorder</i>	(Optional) peeripcandidateorder
<i>peername remotehost</i>	(Optional) peername remotehost
<i>peername localinterface</i>	(Optional) peername localinterface
<i>peername timelastreceived</i>	(Optional) peername timelastreceived
<i>peername timeuntilnextsend</i>	(Optional) peername timeuntilnextsend
<i>peername reachabilitychange</i>	(Optional) peername reachabilitychange
<i>peername packets sent</i>	(Optional) peername packets sent
<i>peername packets received</i>	(Optional) peername packets received
<i>peername badauthentication</i>	(Optional) peername badauthentication
<i>peername bogusorigin</i>	(Optional) peername bogusorigin
<i>peername duplicate</i>	(Optional) peername duplicate
<i>peername baddispersion</i>	(Optional) peername baddispersion
<i>peername badreferencetime</i>	(Optional) peername badreferencetime
<i>peername candidateorder</i>	(Optional) peername candidateorder

Command Mode

- /exec

show ntp status

```
show ntp status [ __readonly__ [ <distribution> ] [ <operational_state> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
status	Show the NTP distribution status
<i>__readonly__</i>	(Optional)
<i>distribution</i>	(Optional) distribution enabled/disabled
<i>operational_state</i>	(Optional) last operation status

Command Mode

- /exec

show ntp trusted-keys

```
show ntp trusted-keys [ __readonly__ [ { TABLE_trustkeys <key> } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
trusted-keys	Display trusted keys
__readonly__	(Optional)
TABLE_trustkeys	(Optional) trusted keys
<i>key</i>	(Optional) trusted key

Command Mode

- /exec

show nve bfd neighbors

```
show nve bfd neighbors [ __readonly__ [ TABLE_nve_bfd_neighbors <if-name> [ { <neighbor-vtep-ip>
<neighbor-inner-ip> <neighbor-inner-mac> <neighbor-cc-state> } ] ] ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
bfd	BFD
neighbors	neighbors
<i>__readonly__</i>	(Optional)
<i>TABLE_nve_bfd_neighbors</i>	(Optional) BFD neighbors schema
<i>if-name</i>	(Optional) if-name
<i>neighbor-vtep-ip</i>	(Optional) Remote VTEP IP address
<i>neighbor-inner-ip</i>	(Optional) Remote VTEP Inner IP address
<i>neighbor-inner-mac</i>	(Optional) Remote VTEP Inner MAC address
<i>neighbor-cc-state</i>	(Optional) Remote VTEP vPC consistency check state

Command Mode

- /exec

show nve peers

```
show nve peers [ [ interface <nve-if> | peer-ip <user-peer-ip> | control-plane | data-plane ] [ detail ] ] [ [ control-plane-vni [ vni <vni-id> | peer-ip <user-peer-ip> ] ] [ controller ] ] [ __readonly__ TABLE_nve_peers [ [ <if-name> ] [ <peer-ip> ] [ <peer-state> ] [ <learn-type> ] [ <uptime> ] [ <router-mac> ] [ { <first-vni> <create-ts> <config-vnis> <provision-state> <route-update> <peer-flags> <cp-vni> <peer-ifindex-resp> } ] [ { <vni> <learn-src> <vni-gw-mac> } ] ] ] ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
peers	Show peers
interface	(Optional) Interface
<i>nve-if</i>	(Optional) NVE interface
detail	(Optional) Detailed information
peer-ip	(Optional) Show a specific peer
<i>user-peer-ip</i>	(Optional) Remote Peer IP address
control-plane	(Optional) Show peers learned via control plane
data-plane	(Optional) Show peers learned via data plane
control-plane-vni	(Optional) Show details of control plane vnis
vni	(Optional) VNI ID
<i>vni-id</i>	(Optional) Virtual Network Identifier
controller	(Optional) Show peers configured by controller
__readonly__	(Optional)
TABLE_nve_peers	(Optional) schema peer
<i>if-name</i>	(Optional) if-name
<i>peer-ip</i>	(Optional) peer-ip
<i>peer-state</i>	(Optional) peer-state
<i>learn-type</i>	(Optional) learn-type
<i>uptime</i>	(Optional) uptime
<i>first-vni</i>	(Optional) first-vni
<i>config-vnis</i>	(Optional) config-vnis

<i>provision-state</i>	(Optional) provision-state
<i>route-update</i>	(Optional) route-update
<i>peer-flags</i>	(Optional) peer-flags
<i>cp-vni</i>	(Optional) cp-vni
<i>peer-ifindex-resp</i>	(Optional) peer-ifindex-resp
<i>create-ts</i>	(Optional) create-timestamp
<i>router-mac</i>	(Optional) router-mac
<i>vni</i>	(Optional) vni value
<i>learn-src</i>	(Optional) learn source
<i>vni-gw-mac</i>	(Optional) vni gateway mac

Command Mode

- /exec

show nve peers interface counters

```
show nve peers <addr> interface <nve-if> counters [ __readonly__ <peer-ip> <tx_ucastpkts> <tx_ucastbytes>
<tx_mcastpkts> <tx_mcastbytes> <rx_ucastpkts> <rx_ucastbytes> <rx_mcastpkts> <rx_mcastbytes> ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
peers	NVE Peer
<i>addr</i>	Remote Peer IP Address
interface	Interface
<i>__readonly__</i>	(Optional)
<i>peer-ip</i>	(Optional)
<i>tx_ucastpkts</i>	(Optional)
<i>tx_ucastbytes</i>	(Optional)
<i>tx_mcastpkts</i>	(Optional)
<i>tx_mcastbytes</i>	(Optional)
<i>rx_ucastpkts</i>	(Optional)
<i>rx_ucastbytes</i>	(Optional)
<i>rx_mcastpkts</i>	(Optional)
<i>rx_mcastbytes</i>	(Optional)

Command Mode

- /exec

show nve peers vni interface counters

```
show nve peers { <addr> | all } vni { <vni-id> | all } interface <nve-if>counters [ __readonly__
TABLE_nve_peer_vni_counters <peer-ip> <vni> <tx_ucastpkts> <tx_ucastbytes> <tx_mcastpkts>
<tx_mcastbytes> <rx_ucastpkts> <rx_ucastbytes> <rx_mcastpkts> <rx_mcastbytes> ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
peers	NVE Peer
<i>addr</i>	Remote Peer IP Address
all	Show counters for all peers/VNIs
vni	Virtual Network Identifier
<i>vni-id</i>	Virtual Network Identifier
interface	Interface
__readonly__	(Optional)
TABLE_nve_peer_vni_counters	(Optional)
<i>peer-ip</i>	(Optional)
<i>vni</i>	(Optional)
<i>tx_ucastpkts</i>	(Optional)
<i>tx_ucastbytes</i>	(Optional)
<i>tx_mcastpkts</i>	(Optional)
<i>tx_mcastbytes</i>	(Optional)
<i>rx_ucastpkts</i>	(Optional)
<i>rx_ucastbytes</i>	(Optional)
<i>rx_mcastpkts</i>	(Optional)
<i>rx_mcastbytes</i>	(Optional)

Command Mode

- /exec

show nve replication-servers

```
show nve replication-servers [ __readonly__ [ TABLE_nve_replication_servers <if-name> [ { <server-ip>
<server-state> <server-ready> } ] ] ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
replication-servers	replication-servers
<i>__readonly__</i>	(Optional)
<i>TABLE_nve_replication_servers</i>	(Optional) replication servers schema
<i>if-name</i>	(Optional) if-name
<i>server-ip</i>	(Optional) Server IP address
<i>server-state</i>	(Optional) Server reachability state
<i>server-ready</i>	(Optional) Server ready state

Command Mode

- /exec

show nve vni

```
show nve vni [ { { interface <nve-if> | <vni-id> } [ detail ] } | control-plane | data-plane | summary | controller
] [ __readonly__ [ TABLE_nve_vni [ <if-name> <vni> <mcast> <vni-state> <mode> <type> <flags> [ {
<prvsn-state> <vlan-bd> <svi-state> <cp-submode> } ] ] [ { <cp-vni-count> <cp-vni-up> <cp-vni-down>
<dp-vni-count> <dp-vni-up> <dp-vni-down> } ] ] ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
vni	Virtual Network Identifier
<i>vni-id</i>	(Optional) Virtual Network Identifier
interface	(Optional) Interface
<i>nve-if</i>	(Optional) NVE interface
detail	(Optional) Detailed information
control-plane	(Optional) show vni learned via BGP
data-plane	(Optional) show vni learned via data plane
summary	(Optional) show vni summary
controller	(Optional) show vni configured by controller
__readonly__	(Optional)
TABLE_nve_vni	(Optional) vni schema
<i>if-name</i>	(Optional) if-name
<i>vni</i>	(Optional) vni
<i>mcast</i>	(Optional) mcast
<i>vni-state</i>	(Optional) vni-state
<i>mode</i>	(Optional) vni-mode
<i>type</i>	(Optional) vni-type
<i>flags</i>	(Optional) vni-flags
<i>prvsn-state</i>	(Optional) provision-state
<i>vlan-bd</i>	(Optional) vlan-bd
<i>svi-state</i>	(Optional) svi-state

<i>cp-submode</i>	(Optional) CP-submode
<i>cp-vni-count</i>	(Optional) CP vni count
<i>cp-vni-up</i>	(Optional) CP vni up count
<i>cp-vni-down</i>	(Optional) CP vni down count
<i>dp-vni-count</i>	(Optional) DP vni count
<i>dp-vni-up</i>	(Optional) DP vni up count
<i>dp-vni-down</i>	(Optional) DP vni down count

Command Mode

- /exec

show nve vni counters

```
show nve vni <vni-id> counters [ __readonly__ <vni> <tx_ucastpkts> <tx_ucastbytes> <tx_mcastpkts>
<tx_mcastbytes> <rx_ucastpkts> <rx_ucastbytes> <rx_mcastpkts> <rx_mcastbytes> ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
vni	Virtual Network Identifier
<i>vni-id</i>	Virtual Network Identifier
counters	Counters
<i>__readonly__</i>	(Optional)
<i>vni</i>	(Optional)
<i>tx_ucastpkts</i>	(Optional)
<i>tx_ucastbytes</i>	(Optional)
<i>tx_mcastpkts</i>	(Optional)
<i>tx_mcastbytes</i>	(Optional)
<i>rx_ucastpkts</i>	(Optional)
<i>rx_ucastbytes</i>	(Optional)
<i>rx_mcastpkts</i>	(Optional)
<i>rx_mcastbytes</i>	(Optional)

Command Mode

- /exec

show nve vni ingress-replication

```
show nve vni ingress-replication [ { interface <nve-if> | <vni-id> } ] [ __readonly__ [
TABLE_nve_vni_ingr_repl <if-name> <vni> [ { <repl-ip> <source> <up-time> } ] ] ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
vni	Virtual Network Identifier
ingress-replication	ingress-replication
<i>vni-id</i>	(Optional) Virtual Network Identifier
interface	(Optional) Interface
<i>nve-if</i>	(Optional) NVE interface
<i>__readonly__</i>	(Optional)
TABLE_nve_vni_ingr_repl	(Optional) vni ingress repl schema
<i>if-name</i>	(Optional) if-name
<i>vni</i>	(Optional) vni
<i>repl-ip</i>	(Optional) Replication List
<i>source</i>	(Optional) Source
<i>up-time</i>	(Optional) Up Time

Command Mode

- /exec

show nve vni peer-vtep

```
show nve vni peer-vtep [ { interface <nve-if> | <vni-id> } ] [ __readonly__ [ TABLE_nve_vni_peer_vtep
<if-name> <vni> [ { <vtep-ip> <source> <up-time> } ] ] ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
vni	Virtual Network Identifier
peer-vtep	Show static peer-vtep configured per vni
<i>vni-id</i>	(Optional) Virtual Network Identifier
interface	(Optional) Interface
<i>nve-if</i>	(Optional) NVE interface
<i>__readonly__</i>	(Optional)
TABLE_nve_vni_peer_vtep	(Optional) vni peer vtep schema
<i>if-name</i>	(Optional) if-name
<i>vni</i>	(Optional) vni
<i>vtep-ip</i>	(Optional) VTEP List
<i>source</i>	(Optional) Source
<i>up-time</i>	(Optional) Up Time

Command Mode

- /exec

show nve vrf

```
show nve vrf [ vrf-name ] [ __readonly__ [ TABLE_nve_vrf <vrf-name> <vni> <if-name> <gateway-mac>
[ { <ipv4-tblid> <ipv6-tblid> <vni-sw-bd> <flags> } ] ] ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
vrf	VRF name
<i>vrf-name</i>	(Optional) vrf name
<i>__readonly__</i>	(Optional)
TABLE_nve_vrf	(Optional) vrf schema
<i>vrf-name</i>	(Optional) vrf-name
<i>vni</i>	(Optional) vni
<i>if-name</i>	(Optional) if-name
<i>gateway-mac</i>	(Optional) gateway-mac
<i>ipv4-tblid</i>	(Optional) ipv4-table-id
<i>ipv6-tblid</i>	(Optional) ipv6-table-id
<i>vni-sw-bd</i>	(Optional) vni-sw-bd
<i>flags</i>	(Optional) flags

Command Mode

- /exec

show nve vxlan-params

```
show nve vxlan-params [ __readonly__ <vxlan-port> ]
```

Syntax Description

show	Display NVE information
nve	Configure NVE information
vxlan-params	VxLAN Parameters
__readonly__	(Optional)
<i>vxlan-port</i>	(Optional) vxlan-params

Command Mode

- /exec

show nxapi-server logs

show nxapi-server logs

Syntax Description

show	Show running system information
nxapi-server	Show NX-API Server
logs	Show NX-API Server logs

Command Mode

- /exec

show nxapi

```
show nxapi [ __readonly__ { operation_status <o_status> } [ configuration_error <c_error> ] {
TABLE_listen_on_port <l_port> } ]
```

Syntax Description

show	Show running system information
nxapi	Show nxapi status
<i>__readonly__</i>	(Optional)
operation_status	(Optional) run-time information about nxapi
<i>o_status</i>	(Optional) enabled or not
configuration_error	(Optional) config syntax error
<i>c_error</i>	(Optional) config syntax error
TABLE_listen_on_port	(Optional) listen on port table
<i>l_port</i>	(Optional) listen on port

Command Mode

- /exec

show nxapi retries

show nxapi retries

Syntax Description

show	Show running system information
nxapi	Show nxapi status
retries	Show retry entries from svc_ifc_confelem.log

Command Mode

- /exec

show nxapi retries