



---

## Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-10](#)
- \* matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- \_ matches a comma (,), left brace ({}), left parenthesis [1-7](#)
- “ [1-10](#)

---

## Numerics

- 10-Gigabit Ethernet uplink
  - selecting [2-125](#)
  - showing the mode [2-340](#)
- 802.1Q trunk ports and native VLANs [2-598](#)
- 802.1Q tunnel ports
  - configuring [2-553](#)
- 802.1S Multiple Spanning Tree
  - see MST
- 802.1X
  - disabling port control [2-92](#)
  - enabling port control [2-92](#)
- 802.1X Critical Authentication
  - disabling on a port [2-93](#)
  - disabling on a VLAN [2-96](#)
- EAPOL
  - disabling send success packets [2-94](#)
  - enabling send success packets [2-94](#)

- enabling on a port [2-93](#)
- enabling on a VLAN [2-96](#)
- returning delay time to default setting [2-95](#)
- setting delay time on a port [2-95](#)
- 802.1X Port Based Authentication
  - allowing multiple hosts on a port [2-103](#)
  - debugging 802.1X Port Based Authentication [2-56](#)
  - displaying port based authentication [2-326](#)
  - enabling accounting for authentication sessions [2-3](#)
  - enabling authentication on the system [2-108](#)
  - enabling guest VLAN [2-97](#)
  - enabling guest VLAN supplicant [2-90, 2-98](#)
  - enabling manual control of auth state [2-104](#)
  - enabling periodic re-authentication of the client [2-107](#)
  - initializing re-authentication of dot1x ports [2-106](#)
  - initializing state machines [2-99](#)
  - receive session termination message upon reboot [2-4](#)
  - setting maximum number for EAP requests [2-102](#)
  - setting the reauthentication timer [2-109](#)

---

## A

- abbreviating commands
  - context-sensitive help [1-1](#)
- Access Gateway Module
  - connecting to a module [2-12](#)
  - connecting to a remote module [2-283](#)
  - connecting to a specific remote module [2-293](#)
- access-group
  - displaying mac interface [2-412](#)
  - show mode interface [2-297](#)
- access groups
  - IP [2-5](#)

- access lists
    - clearing an access template [2-28](#)
    - defining ARP [2-11](#)
    - displaying ARP information [2-300](#)
    - See also ACLs, MAC ACLs, and VACLs
  - access maps
    - applying with VLAN filter [2-599](#)
  - ACLs
    - access-group mode [2-5](#)
    - balancing hardware regions [2-8](#)
    - determining ACL hardware programming [2-6](#)
    - displaying mac access-group interface [2-412](#)
    - using ACL naming conventions for MAC ACLs [2-198](#)
  - action clause
    - specifying drop or forward action in a VACL [2-9](#)
  - addresses, configuring a maximum [2-254](#)
  - adjacency
    - debugging the adjacency table [2-50](#)
    - disabling the debug facility [2-50](#)
    - displaying information about the adjacency table [2-298](#)
    - displaying IPC table entries [2-50](#)
  - aggregate policer
    - displaying information [2-458](#)
  - aging time
    - displaying MAC address aging time [2-415](#)
    - MAC address table [2-201](#)
  - alarms
    - displaying operational status [2-329](#)
  - alternation
    - description [1-9](#)
  - anchoring
    - description [1-10](#)
  - ARP
    - access list, displaying detailed information [2-300](#)
    - defining access-lists [2-11](#)
  - ARP inspection
    - enforce certain types of checking [2-142](#)
  - ARP packet
    - deny based on DHCP bindings [2-86](#)
    - permit based on DHCP bindings [2-240](#)
  - authentication
    - setting username [2-589](#)
    - using an MD5-type encryption method [2-589](#)
    - verifying MD5 signature [2-590](#)
    - verifying the checksum for Flash memory [2-590](#)
  - auth fail VLAN
    - enable on a port [2-91](#)
    - set max number of attempts [2-90](#)
  - authorization state
    - enabling manual control [2-104](#)
  - authorization state of a controlled port [2-104](#)
  - automatic installation
    - displaying status [2-301](#)
  - auto-negotiate interface speed
    - example [2-544](#)
  - auto-QoS
    - configuring for VoIP [2-13](#)
    - displaying configuration [2-302](#)
- 
- B**
  - baby giants
    - displaying the system MTU setting [2-483](#)
    - setting the maximum Layer 2 payload size [2-572](#)
  - BackboneFast
    - displaying debugging messages [2-75](#)
    - displaying spanning tree status [2-474](#)
    - enabling debugging [2-75](#)
  - bindings
    - store for DHCP snooping [2-151](#)
  - BOOT environment variable
    - displaying information [2-306](#)
  - bootflash
    - displaying information [2-304](#)
  - BPDU
    - debugging spanning tree activities [2-74](#)
  - bridge protocol data units
    - See BPDUs

broadcast suppression level

configuring [2-545, 2-547](#)

enabling [2-545, 2-547](#)

## C

cable diagnostics

TDR

displaying test results [2-307](#)

testing conditions of copper cables [2-573](#)

Catalyst 4507R [2-250](#)

power redundancy mode [2-255](#)

CDP

configuring tunneling encapsulation rate [2-188](#)

displaying

neighbor information [2-309](#)

enabling protocol tunneling for [2-184](#)

set drop threshold for [2-186](#)

CEF

displaying next-hop information [2-373](#)

displaying VLAN configuration information [2-373](#)

cisco-desktop

macro apply [2-209](#)

Cisco Express Forwarding

See CEF

cisco-phone

macro apply [2-211](#)

cisco-router

macro apply [2-213](#)

cisco-switch

macro apply [2-215](#)

clear commands

clearing Gigabit Ethernet interfaces [2-26](#)

clearing IGMP group cache entries [2-33](#)

clearing interface counters [2-23](#)

clearing IP access lists [2-28, 2-29](#)

clearing IP ARP inspection statistics VLAN [2-30](#)

clearing IP DHCP snooping database [2-31](#)

clearing IP DHCP snooping database statistics [2-32](#)

clearing MFIB counters and routes [2-36](#)

clearing MFIB fastdrop entries [2-37](#)

clearing PAgP channel information [2-42](#)

clearing QoS aggregate counters [2-45](#)

clearing VLAN interfaces [2-27](#)

CLI string search

anchoring [1-10](#)

expressions [1-7](#)

filtering [1-6](#)

multiple-character patterns [1-8](#)

multipliers [1-9](#)

parentheses for recall [1-10](#)

searching outputs [1-6](#)

single-character patterns [1-7](#)

using [1-6](#)

command modes

accessing privileged EXEC mode [1-4](#)

exiting [1-4](#)

understanding user EXEC and configuration modes [1-4](#)

condition interface

debugging interface-related activities [2-52](#)

condition vlan

debugging VLAN output [2-55](#)

configuration, saving [1-11](#)

configuring

root as secondary [2-528](#)

configuring a SPAN session to monitor

limit SPAN source traffic [2-229](#)

configuring forward delay [2-524](#)

configuring root as primary [2-528](#)

CoPP

attaching

policy map to control plane [2-291](#)

displaying

policy-map class information [2-438](#)

entering configuration mode [2-48](#)

removing

service policy from control plane [2-291](#)

- CoS
    - assigning to Layer 2 protocol packets [2-185](#)
  - CoS QoS default
    - defining value on an interface [2-268](#)
  - Cost of Service
    - See QoS CoS
  - counters
    - clearing interface counters [2-23](#)
- 
- D**
- DAI
    - clear statistics [2-30](#)
  - DBL
    - displaying qos dbl [2-459](#)
    - enabling DBL globally on the switch [2-269](#)
  - debug commands
    - debugging backup events [2-51](#)
    - debugging DHCP snooping events [2-61](#)
    - debugging DHCP snooping messages [2-62](#)
    - debugging EtherChannel/PAgP/shim [2-57](#)
    - debugging IPC activity [2-60](#)
    - debugging IP DHCP snooping security messages [2-63](#)
    - debugging NVRAM activities [2-66](#)
    - debugging PAgP activities [2-67](#)
    - debugging port manager activities [2-70](#)
    - debugging software MAC filter updates [2-73](#)
    - debugging spanning tree activities [2-74](#)
    - debugging spanning tree backbonefast [2-75](#)
    - debugging spanning tree UplinkFast [2-78](#)
    - debugging supervisor redundancy [2-72](#)
    - debugging VLAN manager activities [2-79](#)
    - displaying monitor activity [2-65](#)
    - displaying the adjacency table [2-50](#)
    - enabling debug dot1x [2-56](#)
    - enabling debugging messages for ISL VLAN IDs [2-81](#)
    - enabling debugging messages for VTP [2-82](#)
    - enabling debugging of UDLD activity [2-83](#)
    - enabling switch shim debugging [2-76](#)
    - enabling VLAN manager file system error tests [2-80](#)
    - limiting debugging output for VLANs [2-55](#)
    - limiting interface debugging output [2-52](#)
    - limiting output for debugging standby state changes [2-53](#)
    - shortcut to the debug condition interface [2-59](#)
  - debugging
    - activity monitoring [2-65](#)
    - DHCP snooping events [2-61](#)
    - DHCP snooping packets [2-62](#)
    - IPC activities [2-60](#)
    - IP DHCP snooping security packets [2-63](#)
    - NVRAM activities [2-66](#)
    - PAgP activities [2-67](#)
    - PAgP shim [2-57](#)
    - PM activities [2-70](#)
    - SMF address insertions and deletions [2-73](#)
    - spanning tree BackboneFast events [2-75](#)
    - spanning tree switch shim [2-76](#)
    - spanning tree UplinkFast events [2-78](#)
    - VLAN manager activities [2-79](#)
    - VLAN manager IOS file system error tests [2-80](#)
    - VTP protocol debug messages [2-82](#)
  - debug spanning tree switch [2-76](#)
  - debug sw-vlan vtp [2-82](#)
  - default CoS value [2-268](#)
  - default form of a command, using [1-6](#)
  - defining egress DSCP-to-CoS mapping [2-273](#)
  - DHCP
    - clearing database statistics [2-32](#)
  - DHCP bindings
    - configuring bindings [2-150](#)
    - deny ARP packet based on matches [2-86](#)
    - permit ARP packet based on matches [2-240](#)
  - DHCP snooping
    - clearing database [2-31](#)
    - displaying binding table [2-375](#)
    - displaying configuration information [2-374](#)
    - displaying status of DHCP database [2-378](#)

- displaying status of error detection [2-332](#)
- enabling DHCP globally [2-149](#)
- enabling IP source guard [2-182](#)
- enabling on a VLAN [2-157](#)
- enabling option 82 [2-153, 2-154](#)
- enabling rate limiting on an interface [2-155](#)
- enabling trust on an interface [2-156](#)
- establishing binding configuration [2-150](#)
- renew binding database [2-285](#)
- store generated bindings [2-151](#)
- diagnostic test
  - bootup packet memory [2-320](#)
  - displaying attributes [2-314](#)
  - display module-based results [2-316](#)
  - running [2-89](#)
  - show results for TDR [2-307](#)
  - testing conditions of copper cables [2-573](#)
- displaying error disable recovery [2-333](#)
- displaying inline power status [2-450](#)
- displaying monitoring activity [2-65](#)
- displaying SEEPROM information
  - GBIC [2-341](#)
- displaying SPAN session information [2-482, 2-546](#)
- document conventions [xvi](#)
- document organization [xv](#)
- DoS
  - CoPP
    - attaching policy map to control plane [2-291](#)
    - displaying policy-map class information [2-438](#)
    - entering configuration mode [2-48](#)
    - removing service policy from control plane [2-291](#)
  - entering
    - CoPP configuration mode [2-48](#)
- DOS attack
  - protecting system's resources [2-137](#)
- drop threshold, Layer 2 protocol tunneling [2-186](#)
- DSCP rewrite for IP packets
  - enable [2-276](#)

- dual-capable port
  - selecting a connector [2-226](#)
- duplex mode
  - configuring autonegotiation on an interface [2-111](#)
  - configuring full duplex on an interface [2-111](#)
  - configuring half duplex on an interface [2-111](#)
- dynamic ARP inspection
  - preventing [2-137](#)
- Dynamic Buffer Limiting
  - See DBL
- Dynamic Host Configuration Protocol
  - See DHCP

---

## E

- EAP
  - restarting authentication process [2-102](#)
- EIGRP (Enhanced IGRP)
  - filters
    - routing updates, preventing [2-237](#)
  - enabling
    - debugging for UDLD [2-83](#)
    - voice VLANs [2-548](#)
- environmental
  - alarms [2-329](#)
  - displaying information [2-329](#)
  - status [2-329](#)
  - temperature [2-329](#)
- erase a file [2-113](#)
- error disable detection
  - enabling error disable detection [2-116](#)
- error-disabled state
  - displaying [2-359](#)
- error disable recovery
  - configuring recovery mechanism variables [2-118](#)
  - displaying recovery timer information [2-333](#)
  - enabling ARP inspection timeout [2-118](#)
  - specifying recovery cause [2-118](#)

## EtherChannel

- assigning interfaces to EtherChannel groups [2-17](#)
- debugging EtherChannel [2-57](#)
- debugging PAgP shim [2-57](#)
- debugging spanning tree activities [2-74](#)
- displaying information for a channel [2-334](#)
- removing interfaces from EtherChannel groups [2-17](#)

## EtherChannel guard

- detecting STP misconfiguration [2-515](#)

## Explicit Host Tracking

- clearing the database [2-35](#)
- enabling per-VLAN [2-169](#)

## expressions

- matching multiple expression occurrences [1-9](#)
- multiple-character patterns [1-8](#)
- multiplying pattern occurrence [1-10](#)
- single-character patterns [1-7](#)

## Extensible Authentication Protocol

- See EAP

**F**

## field replaceable unit (FRU)

- displaying status information [2-329](#)

## filters

## EIGRP

- routing updates, preventing [2-237](#)

## Flash memory file system

- displaying file system information [2-304](#)
- verifying checksum [2-590](#)

## flow control

- configuring a gigabit interface for pause frames [2-121](#)
- displaying per-interface statistics for flow control [2-338](#)

**G**

## GBIC

- displaying SEEPROM information [2-341](#)

## Gigabit Ethernet interface

- clearing the hardware logic [2-26](#)

## Gigabit Ethernet uplink

- selecting [2-125](#)
- showing the mode [2-340](#)

## global configuration mode

- using [1-5](#)

**H**

## hardware module

- resetting a module by toggling the power [2-124](#)

## hardware uplink

- selecting the mode [2-125](#)
- showing the mode [2-340](#)

helper addresses, IP [2-391](#)

## hot standby protocol

- debugging [2-53](#)
- disabling debugging [2-53](#)
- limiting output [2-53](#)

**I**

## IDPROMs

## displaying SEEPROM information

- chassis [2-341](#)
- clock module [2-341](#)
- fan trays [2-341](#)
- module [2-341](#)
- mux buffer [2-341](#)
- power supplies [2-341](#)
- supervisor engine [2-341](#)

## ifIndex persistence

- clearing SNMP ifIndex commands [2-503](#)
- compress SNMP ifIndex table format [2-508](#)
- disabling globally [2-507](#)
- disabling on an interface [2-504](#)
- enabling globally [2-507](#)

- enabling on an interface [2-504](#)
- IGMP
  - applying filters for host joining on Layer 2 interfaces [2-159](#)
  - clearing IGMP group cache entries [2-33](#)
  - configuring frequency for IGMP host-query messages [2-162](#)
  - creating an IGMP profile [2-161](#)
  - displaying IGMP interface configuration information [2-380](#)
  - displaying profiles [2-381](#)
  - setting maximum group numbers [2-160](#)
- IGMP profiles
  - displaying [2-381](#)
- IGMP snooping
  - clearing the EHT database [2-35](#)
  - configuring a Layer 2 interface as a group member [2-173](#)
  - configuring a Layer 2 interface as a multicast router [2-171](#)
  - configuring a static VLAN interface [2-173](#)
  - displaying multicast information [2-388](#)
  - displaying VLAN information [2-382, 2-386, 2-389](#)
  - enabling [2-164](#)
  - enabling immediate-leave processing [2-170](#)
  - enabling on a VLAN [2-168](#)
  - enabling per-VLAN Explicit Host Tracking [2-169](#)
- informs
  - enabling [2-505](#)
- inline power
  - displaying inline power status [2-450](#)
- inspection log
  - clearing log buffer [2-29](#)
- interface
  - displaying suppressed multicast bytes [2-353](#)
- interface capabilities
  - displaying [2-350](#)
- interface configuration mode
  - summary [1-5](#)
- interface link
  - display cable disconnect time [2-356](#)
- interfaces
  - configuring dot1q tunnel ports [2-553](#)
  - creating an interface-range macro [2-85](#)
  - debugging output of interface related activities [2-52](#)
  - displaying description [2-355](#)
  - displaying error-disabled state [2-359](#)
  - displaying information when tunneling is enabled [2-406](#)
  - displaying status [2-355](#)
  - displaying traffic for a specific interface [2-347](#)
  - entering interface configuration mode [2-129](#)
  - executing a command on multiple ports in a range [2-132](#)
  - selecting an interface to configure [2-129](#)
  - setting a CoS value for Layer 2 packets [2-185](#)
  - setting drop threshold for Layer 2 packets [2-186](#)
  - setting the interface type [2-553](#)
- interface speed
  - configuring interface speed [2-542](#)
- interface transceiver
  - displaying diagnostic data [2-362](#)
- internal VLAN allocation
  - configuring [2-600](#)
  - default setting [2-600](#)
  - displaying allocation information [2-494](#)
- Internet Group Management Protocol
  - See IGMP
- IP ARP
  - applying ARP ACL to VLAN [2-135](#)
  - clearing inspection statistics [2-30](#)
  - clearing status of log buffer [2-29](#)
  - controlling packet logging [2-145](#)
  - enabling dynamic inspection [2-144](#)
  - limit rate of incoming requests [2-137](#)
  - set per-port config trust state [2-141](#)
  - showing status of dynamic ARP inspection [2-369](#)
  - showing status of log buffer [2-372](#)

**IPC**

debugging IPC activities [2-60](#)

**IP DHCP Snooping**

See DHCP snooping

**IP header validation**

disabling [2-181](#)

enabling [2-181](#)

**IP interfaces**

displaying usability status [2-390](#)

**IP multicast**

displaying multicast routing table information [2-396](#)

**IP packets**

enable DSCP rewrite [2-276](#)

**IP phone and standard desktop**

enabling Cisco-recommended features [2-211](#)

**IP source binding**

adding or deleting [2-178](#)

displaying bindingstaggering [2-401](#)

**IP source guard**

debugging messages [2-63](#)

displaying configuration and filters [2-402](#)

enabling on DHCP snooping [2-182](#)

specifying a trunking VLAN interface [2-553](#)

**Layer 2 protocol ports**

displaying [2-406](#)

**Layer 2 protocol tunneling error recovery** [2-188](#)**Layer 2 switching**

enabling voice VLANs [2-548](#)

modifying switching characteristics [2-548](#)

**Layer 2 traceroute**

IP addresses [2-578](#)

**Layer 3 switching**

displaying information about an adjacency table [2-298](#)

displaying port status [2-360](#)

displaying status of native VLAN tagging [2-360](#)

**link-status event messages**

disabling

globally [2-192, 2-195](#)

on an interface [2-193, 2-196](#)

enabling

globally [2-192, 2-195](#)

on an interface [2-193, 2-196](#)

**log buffer**

show status [2-372](#)

**logging**

controlling IP ARP packets [2-145](#)

**J****Jumbo frames**

enabling jumbo frames [2-233](#)

**L****LACP**

deselecting channeling protocol [2-19](#)

enabling LACP on an interface [2-19](#)

setting channeling protocol [2-19](#)

**Layer 2**

displaying ACL configuration [2-412](#)

**Layer 2 interface type**

specifying a nontrunking, nontagged single VLAN interface [2-553](#)

**M****MAC Access Control Lists**

See MAC ACLs

**MAC ACLs**

defining extended MAC access list [2-198](#)

displaying MAC ACL information [2-491](#)

naming an ACL [2-198](#)

**MAC address filtering**

configuring [2-207](#)

disabling [2-207](#)

enabling [2-207](#)

**MAC address table**

adding static entries [2-220](#)



- clearing dynamic entries [2-39, 2-41](#)
  - configuring aging time [2-201](#)
  - displaying dynamic table entry information [2-417](#)
  - displaying entry count [2-416](#)
  - displaying information [2-413](#)
  - displaying interface-based information [2-419](#)
  - displaying multicast information [2-421](#)
  - displaying notification information [2-423](#)
  - displaying protocol-based information [2-425](#)
  - displaying static table entry information [2-427](#)
  - displaying the MAC address aging time [2-415](#)
  - displaying VLAN-based information [2-429](#)
  - enabling authentication bypass [2-100](#)
  - enabling notifications [2-205](#)
  - learning in the protocol buckets [2-202](#)
  - removing static entries [2-220](#)
- MAC address tables
- adding static entries [2-207](#)
  - deleting secure or specific addresses [2-43](#)
  - disabling IGMP snooping on static MAC addresses [2-207](#)
  - removing static entries [2-207](#)
- mac-address-table static [2-207](#)
- MAC address unicast filtering
- dropping unicast traffic [2-207](#)
- macro global description command [2-219](#)
- macro keywords
- help strings [2-2](#)
- macros
- adding a global description [2-219](#)
  - cisco global [2-217](#)
  - system-cpp [2-218](#)
- mapping secondary VLANs to MST instance [2-260](#)
- mapping VLAN(s) to an MST instance [2-127](#)
- match subcommand
- accessing [2-21](#)
- maximum transmission unit (MTU)
- displaying the system MTU setting [2-483](#)
  - setting the maximum Layer 2 payload size [2-572](#)
- MD5
- verifying MD5 signature [2-590](#)
- message digest 5
- See MD5
- MFIB
- clearing ip mfib counters [2-36](#)
  - clearing ip mfib fastdrop [2-37](#)
  - displaying all active MFIB routes [2-393](#)
  - displaying MFIB fastdrop table entries [2-395](#)
  - enabling IP MFIB fastdrops [2-175](#)
- modes
- access-group [2-5](#)
  - show access-group interface [2-297](#)
  - switching between PVST+, MST, and Rapid PVST [2-520](#)
  - See also command modes
- module password clearing [2-25](#)
- module reset
- resetting a module by toggling the power [2-124](#)
- More-- prompt
- filter [1-6](#)
  - search [1-7](#)
- MST
- designating the primary and secondary root [2-528](#)
  - displaying MST protocol information [2-478](#)
  - displaying region configuration information [2-478](#)
  - displaying spanning tree information [2-478](#)
  - entering MST configuration submode [2-522](#)
  - setting configuration revision number [2-287](#)
  - setting path cost and port priority for instances [2-521](#)
  - setting the forward delay timer for all instances [2-524](#)
  - setting the hello-time delay timer for all instances [2-525](#)
  - setting the max-age timer for all instances [2-526](#)
  - setting the MST region name [2-234](#)
  - specifying the maximum number of hops [2-527](#)
  - switching between PVST+ and Rapid PVST [2-520](#)
  - using the MST configuration submode revision command [2-287](#)
  - using the submode name command [2-234](#)

**M**

- MTU
  - displaying global MTU settings [2-483](#)
- multicast
  - enabling storm control [2-547](#)
- multicast/unicast packets
  - prevent forwarding [2-552](#)
- Multicast Forwarding Information Base
  - See MFIB
- multiple-character patterns [1-8](#)
- multiple hosts on authorized port [2-103](#)
- Multiple Spanning Tree
  - See MST

**N**

- native VLAN
  - controlling tagging of traffic [2-567](#)
  - displaying ports eligible for native tagging [2-493](#)
  - displaying ports eligible for tagging [2-493](#)
  - enabling tagging on 802.1Q trunk ports [2-598](#)
  - specifying the tagging of traffic [2-568](#)
- NetFlow
  - enabling NetFlow statistics [2-176](#)
  - including infer fields in routing statistics [2-176](#)
- next-hop
  - displaying CEF VLAN information [2-373](#)
- no form of a command, using [1-6](#)
- NVRAM
  - debugging NVRAM activities [2-66](#)

**O**

- output
  - pattern searches [1-7](#)

**P**

- packet forwarding
  - prevent unknown packets [2-552](#)
- packet memory failure
  - direct switch action upon detection [2-88](#)
- packet memory test
  - bootup, displaying results [2-320, 2-322](#)
  - ongoing, displaying results [2-324](#)
- PACL
  - access-group mode [2-5](#)
- paging prompt
  - see --More-- prompt
- PAgP
  - clearing port channel information [2-42](#)
  - debugging PAgP activity [2-67](#)
  - deselecting channeling protocol [2-19](#)
  - displaying port channel information [2-435](#)
  - hot standby mode
    - returning to defaults [2-236](#)
    - selecting ports [2-236](#)
  - input interface of incoming packets
    - learning [2-235](#)
    - returning to defaults [2-235](#)
  - setting channeling protocol [2-19](#)
- parentheses [1-10](#)
- password
  - clearing on an intelligent line module [2-25](#)
  - establishing enhanced password security [2-589](#)
  - setting username [2-589](#)
- PBR
  - displaying route maps [xvi](#)
  - redistributing route maps [xvi](#)
- PM activities
  - debugging [2-70](#)
  - disabling debugging [2-70](#)
- Policy Based Routing
  - See PBR

- port, dual-capable
  - selecting the connector [2-226](#)
- Port Aggregation Protocol
  - See PAgP
- port-based authentication
  - displaying debug messages [2-56](#)
  - displaying statistics and status [2-326](#)
  - enabling 802.1X [2-104](#)
  - manual control of authorization state [2-104](#)
  - multiple hosts on authorized port [2-103](#)
  - periodic re-authentication
    - enabling [2-107](#)
  - re-authenticating 802.1X-enabled ports [2-106](#)
  - switch-to-client frame-retransmission number [2-102](#)
- port channel
  - accessing [2-131](#)
  - creating [2-131](#)
  - displaying information [2-435](#)
  - load distribution method
    - resetting to defaults [2-244](#)
  - setting [2-244](#)
- port range
  - executing [2-132](#)
- port security
  - debugging ports security [2-71](#)
  - deleting secure or specific addresses [2-43](#)
  - displaying settings for an interface or switch [2-445](#)
  - enabling [2-555](#)
  - filter source IP and MAC addresses [2-182](#)
  - setting action upon security violation [2-555](#)
  - setting the rate limit for bad packets [2-555](#)
  - sticky port [2-555](#)
- Port Trust Device
  - displaying [2-460](#)
- power status
  - displaying inline power [2-450](#)
  - displaying power status [2-450](#)
- power supply
  - configuring combined and redundant power on the Catalyst 4507R [2-250](#)
  - configuring inline power [2-247](#)
  - configuring power consumption [2-249](#)
  - configuring power redundancy on the Catalyst 4507R [2-255](#)
  - displaying the SEEPROM [2-341](#)
  - setting inline power state [2-246](#)
- Private VLAN
  - See PVLANS
- privileged EXEC mode, summary [1-5](#)
- prompts
  - system [1-5](#)
- protocol tunneling
  - configuring encapsulation rate [2-188](#)
  - disabling [2-184](#)
  - displaying port information [2-406](#)
  - enabling [2-184](#)
  - setting a CoS value for Layer 2 packets [2-185](#)
  - setting a drop threshold for Layer 2 packets [2-186](#)
- PVLANS
  - configuring isolated, primary, and community PVLANS [2-256](#)
  - controlling tagging of native VLAN traffic [2-567](#)
  - disabling sticky-ARP [2-179](#)
  - displaying map information for VLAN SVIs [2-358](#)
  - displaying PVLAN information [2-496](#)
  - enabling interface configuration mode [2-553](#)
  - enabling sticky-ARP [2-179](#)
  - mapping VLANs to the same SVI [2-258](#)
  - specifying host ports [2-553](#)
  - specifying promiscuous ports [2-553](#)
- PVST+
  - switching between PVST and MST [2-520](#)

**Q**

## QoS

- account Layer 2 encapsulation [2-263](#)
  - attaching a policy-map to an interface [2-288](#)
  - automatic configuration [2-13](#)
  - clearing aggregate counters [2-45](#)
  - configuring a QoS policy map [2-242](#)
  - configuring auto [2-13](#)
  - defining a named aggregate policer [2-265](#)
  - defining default CoS value [2-268](#)
  - defining ingress CoS-to-DSCP mapping [2-272](#)
  - displaying aggregate policer information [2-458](#)
  - displaying auto configuration [2-302](#)
  - displaying class maps information [2-312](#)
  - displaying configuration information [2-302](#)
  - displaying configurations of policies [2-441](#)
  - displaying policy map information [2-437, 2-444](#)
  - displaying QoS information [2-457](#)
  - displaying QoS map information [2-461](#)
  - enabling global configuration mode [2-261](#)
  - enabling per-VLAN QoS for a Layer 2 interface [2-279](#)
  - enabling QoS on an interface [2-262](#)
  - mapping DSCP values to transmit queues [2-273](#)
  - mapping egress DSCP-to-CoS [2-273](#)
  - mapping the DSCP-to-CoS value [2-273](#)
  - setting the mapping of policed DSCP values [2-275](#)
  - setting the trust state [2-277](#)
  - specifying flow-based match criteria [2-222](#)
- QoS CoS
- configuring for tunneled Layer 2 protocol packets [2-185](#)
  - defining default CoS value [2-268](#)
- qos dbl [2-269](#)
- question command [1-1](#)
- queueing information
- displaying [2-460](#)

**R**

## Rapid PVST

- switching between PVST and MST [2-520](#)
- re-authenticating 802.1X-enabled ports [2-106](#)
- re-authentication
- periodic [2-107](#)
  - set the time [2-109](#)
- reboots
- restoring bindings across [2-150](#)
- redundancy
- accessing the main CPU [2-280](#)
  - changing from active to standby supervisor engine [2-281](#)
  - displaying information [2-463](#)
  - displaying redundancy facility information [2-463](#)
  - displaying RF client list [2-463](#)
  - displaying RF operational counters [2-463](#)
  - displaying RF states [2-463](#)
  - enabling automatic synchronization [2-16](#)
  - forcing switchover to standby supervisor engine [2-281](#)
  - set the mode [2-227](#)
  - synchronizing the route processor configurations [2-220](#)
- related documentation [xv](#)
- remote SPAN
- See RSPAN
- renew commands
- ip dhcp snooping database [2-285](#)
- resetting PVLAN trunk
- setting switchover to trunk [2-553](#)
- rj45 connector, selecting the connector [2-226](#)
- ROM monitor mode
- summary [1-6](#)
- Route Processor Redundancy
- See redundancy
- RPR
- set the redundancy mode [2-227](#)

## RSPAN

- converting VLAN to RSPAN VLAN [2-284](#)
- displaying list [2-498](#)

**S**

saving configuration changes [1-11](#)

secure address, configuring [2-252](#)

secure ports, limitations [2-556](#)

set the redundancy mode [2-227](#)

sfp connector, selecting the connector [2-226](#)

show commands

- filtering parameters [1-7](#)

- searching and filtering [1-6](#)

- show platform commands [1-11](#)

Simple Network Management Protocol

- See SNMP

single-character patterns

- special characters [1-7](#)

slaveslot0

- displaying information on the standby supervisor [2-470](#)

slot0

- displaying information about the system [2-472](#)

SMF

- debugging address insertions and deletions [2-73](#)

SNMP

- debugging spanning tree activities [2-74](#)

ifIndex persistence

- clearing SNMP ifIndex commands [2-503](#)

- compress SNMP ifIndex table format [2-508](#)

- disabling globally [2-507](#)

- disabling on an interface [2-504](#)

- enabling globally [2-507](#)

- enabling on an interface [2-504](#)

informs

- disabling [2-505](#)

- enabling [2-505](#)

traps

- configuring to send when storm occurs [2-545](#)

- disabling [2-505](#)

- enabling [2-505](#)

- mac-notification

- adding [2-509](#)

- removing [2-509](#)

software MAC filter

- See SMF

SPAN commands

- configuring a SPAN session to monitor [2-229](#)

- displaying SPAN session information [2-482, 2-546](#)

SPAN enhancements

- displaying status [2-433](#)

Spanning Tree Protocol

- See STP

SPAN session

- displaying session information [2-433](#)

- filter ACLs [2-229](#)

- specify encap type [2-229](#)

- turn off host learning based on ingress packets [2-229](#)

special characters

- anchoring, table [1-10](#)

SSO [2-227](#)

standard desktop

- enabling Cisco-recommended features [2-209](#)

standard desktop and Cisco IP phone

- enabling Cisco-recommended features [2-211](#)

sticky address, configuring [2-253](#)

sticky-ARP

- disabling on PVLANS [2-179](#)

- enabling on PVLANS [2-179](#)

sticky port

- deleting [2-43](#)

- enabling security [2-555](#)

storm control

- configuring for action when storm occurs [2-545](#)

- disabling suppression mode [2-332](#)

- displaying settings [2-481](#)

- enabling [2-545](#)
- enabling broadcast [2-545, 2-547](#)
- enabling multicast [2-545, 2-547](#)
- enabling suppression mode [2-332](#)
- enabling timer to recover from error disable [2-118](#)
- enabling unicast [2-545, 2-547](#)
- multicast, enabling [2-547](#)
- setting high and low levels [2-545](#)
- setting suppression level [2-332](#)

## STP

- configuring link type for a port [2-518](#)
- configuring tunneling encapsulation rate [2-188](#)
- debugging all activities [2-74](#)
- debugging spanning tree activities [2-74](#)
- debugging spanning tree BackboneFast events [2-75](#)
- debugging spanning tree UplinkFast [2-78](#)
- detecting misconfiguration [2-515](#)
- displaying active interfaces only [2-474](#)
- displaying BackboneFast status [2-474](#)
- displaying bridge status and configuration [2-474](#)
- displaying spanning tree debug messages [2-74](#)
- displaying summary of interface information [2-474](#)
- enabling BPDU filtering by default on all PortFast ports [2-533](#)
- enabling BPDU filtering on an interface [2-511](#)
- enabling BPDU guard by default on all PortFast ports [2-535](#)
- enabling BPDU guard on an interface [2-513](#)
- enabling extended system ID [2-516](#)
- enabling loop guard as a default on all ports [2-519](#)
- enabling PortFast by default on all access ports [2-536](#)
- enabling PortFast mode [2-531](#)
- enabling protocol tunneling for [2-184](#)
- enabling root guard [2-517](#)
- enabling spanning tree BackboneFast [2-510](#)
- enabling spanning tree on a per VLAN basis [2-540](#)
- enabling spanning tree UplinkFast [2-538](#)
- setting an interface priority [2-537](#)
- setting drop threshold for [2-186](#)

- setting pathcost [2-514](#)
- setting the default pathcost calculation method [2-530](#)
- subinterface configuration mode, summary [1-6](#)
- SVI
  - creating a Layer 3 interface on a VLAN [2-134](#)
- switchport [2-568](#)
- switchport interfaces
  - displaying status of Layer 3 port [2-360](#)
  - displaying status of native VLAN tagging [2-360](#)
- switch shim
  - debugging [2-76](#)
  - disabling debugging [2-76](#)
- switch to router connection
  - enabling Cisco-recommended features [2-213](#)
- switch to switch connection
  - enabling Cisco-recommended features [2-215](#)
- switch virtual interface
  - See SVI
- sw-vlan [2-79](#)
- system prompts [1-5](#)

---

## T

- Tab key
  - command completion [1-1](#)
- tables
  - characters with special meaning [1-7](#)
  - mac access-list extended subcommands [2-198](#)
  - match syntax description [2-22](#)
  - multipliers [1-9](#)
  - relationship between duplex and speed
    - commands [2-543](#)
  - show cable-diagnostics tdr command output
    - fields [2-308](#)
  - show cdp neighbors detail field descriptions [2-311](#)
  - show cdp neighbors field descriptions [2-310](#)
  - show ip interface field descriptions [2-391](#)
  - show policy-map control-plane field descriptions [2-440](#)
  - show vlan command output fields [2-497](#)

- show vtp command output fields [2-501](#)
- special characters [1-9](#)
- special characters used for anchoring [1-10](#)
- speed command options [2-222, 2-542](#)
- valid interface types [2-129](#)

TAC

- displaying information useful to TAC [2-484](#)

TCAM

- debugging spanning tree activities [2-74](#)

TDR

- displaying cable diagnostic test results [2-307](#)
- test condition of copper cables [2-573](#)

temperature readings

- displaying information [2-329](#)

timer information [2-333](#)

traffic shaping

- enable on an interface [2-295](#)

traps, enabling [2-505](#)

trunk encapsulation

- setting format [2-568](#)

trunk interfaces

- displaying trunk interfaces information [2-367](#)

trust state

- setting [2-141](#)

tunnel ports

- displaying information about Layer 2 protocol [2-406](#)

TX queues

- allocating bandwidth [2-581](#)
- returning to default values [2-581](#)
- setting priority to high [2-581](#)
- specifying burst size [2-581](#)
- specifying traffic rate [2-581](#)

---

## U

UDLD

- displaying administrative and operational status [2-486](#)
- enabling by default on all fiber interfaces [2-583](#)
- enabling on an individual interface [2-585](#)

- preventing a fiber interface from being enabled [2-585](#)
- resetting all shutdown ports [2-587](#)
- setting the message timer [2-583](#)

Unidirectional Link Detection

- See UDLD

unknown multicast traffic, preventing [2-552](#)

unknown unicast traffic, preventing [2-552](#)

user EXEC mode, summary [1-5](#)

username

- setting password and privilege level [2-589](#)

---

## V

VACLs

- access-group mode [2-5](#)
- applying VLAN access maps [2-599](#)
- displaying VLAN access map information [2-491](#)
- specifying an action in a VLAN access map [2-9](#)
- specifying the match clause for a VLAN access-map sequence [2-221](#)
- using a VLAN filter [2-599](#)

VLAN

- applying an ARP ACL [2-135](#)
- configuring [2-592](#)
- converting to RSPAN VLAN [2-284](#)
- displaying CEF information [2-373](#)
- displaying CEF next-hop information [2-373](#)
- displaying information on switch interfaces [2-382, 2-386](#)
- displaying information on VLAN switch interfaces [2-389](#)
- displaying information sorted by group IP address [2-382, 2-386](#)
- displaying IP address and version information [2-382, 2-386](#)
- displaying Layer 2 VLAN information [2-488](#)
- displaying statistical information [2-431](#)
- displaying VLAN information [2-490](#)
- enabling dynamic ARP inspection [2-144](#)
- enabling Explicit Host Tracking [2-169](#)
- enabling guest per-port [2-97](#)

- enabling guest VLAN supplicant [2-90, 2-98](#)
- entering VLAN configuration mode [2-596](#)
- native frames
  - enabling tagging on all 802.1Q trunk ports [2-598](#)
  - pruning the list for VTP [2-568](#)
  - setting the list of allowed [2-568](#)
- VLAN Access Control Lists
  - See VACLs
- VLAN access map
  - See VACLs
- VLAN database
  - resetting [2-286](#)
- VLAN debugging
  - limiting output [2-55](#)
- VLAN manager
  - debugging [2-79](#)
  - disabling debugging [2-79](#)
  - IOS file system error tests
    - debugging [2-80](#)
    - disabling debugging [2-80](#)
- VLAN Query Protocol
  - See VQP
- VLAN query protocol (VQPC)
  - debugging [2-84](#)
- VLANs
  - clearing
    - counters [2-46](#)
  - clearing hardware logic [2-27](#)
  - configuring
    - internal allocation scheme [2-600](#)
  - displaying
    - internal VLAN allocation information [2-494](#)
    - RSPAN VLANs [2-498](#)
  - entering VLAN configuration mode [2-596](#)
- VMPS
  - configuring servers [2-604](#)
  - reconfirming dynamic VLAN assignments [2-602](#)
- voice VLANs
  - enabling [2-548](#)
- VoIP
  - configuring auto-QoS [2-13](#)
- VQP
  - per-server retry count [2-603](#)
  - reconfirming dynamic VLAN assignments [2-602](#)
- VTP
  - configuring the administrative domain name [2-608](#)
  - configuring the device in VTP client mode [2-607](#)
  - configuring the device in VTP server mode [2-611](#)
  - configuring the device in VTP transparent mode [2-612](#)
  - configuring tunnel encapsulation rate [2-188](#)
  - creating a VTP domain password [2-609](#)
  - displaying domain information [2-500](#)
  - displaying statistics information [2-500](#)
  - enabling protocol tunneling for [2-184](#)
  - enabling pruning in the VLAN database [2-610](#)
  - enabling VTP version 2 mode [2-613](#)
  - modifying the VTP configuration storage file name [2-606](#)
  - set drop threshold for [2-186](#)
- VTP protocol code
  - activating debug messages [2-82](#)
  - deactivating debug messages [2-82](#)