



Release Notes for Cisco Catalyst 9300 Series Switches, Cisco IOS XE Dublin 17.11.x

First Published: 2023-03-28

Last Modified: 2023-06-29

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

CHAPTER 1

Introduction 1

Supported Hardware 1

Cisco Catalyst 9300 Series Switches—Model Numbers 1

Network Modules 7

Optics Modules 8

CHAPTER 2

Whats New in Cisco IOS XE Dublin 17.11.x 9

Hardware Features in Cisco IOS XE Dublin 17.11.99SW 9

Software Features in Cisco IOS XE Dublin 17.11.99SW 9

Hardware and Software Behavior Changes in Cisco IOS XE Dublin 17.11.99SW 10

Hardware Features in Cisco IOS XE Dublin 17.11.1 10

Software Features in Cisco IOS XE Dublin 17.11.1 10

Hardware and Software Behavior Changes in Cisco IOS XE Dublin 17.11.1 13

CHAPTER 3

Important Notes 15

Important Notes 15

CHAPTER 4

Compatibility Matrix and Web UI System Requirements 17

Compatibility Matrix 17

Web UI System Requirements 17

CHAPTER 5

Licensing and Scaling Guidelines 19

Licensing 19

Available Licensing Models and Configuration Information 19

Scaling Guidelines 19

CHAPTER 6 **Limitations and Restrictions 21**

Limitations and Restrictions 21

CHAPTER 7 **ROMMON Versions 25**

ROMMON Versions 25

CHAPTER 8 **Upgrading the Switch Software 27**

Finding the Software Version 27

Software Images 27

Upgrading the ROMMON 28

Software Installation Commands 28

Upgrading in Install Mode 29

Downgrading in Install Mode 36

Field-Programmable Gate Array Version Upgrade 41

CHAPTER 9 **Caveats 43**

Cisco Bug Search Tool 43

Open Caveats in Cisco IOS XE Dublin 17.11.x 43

Resolved Caveats in Cisco IOS XE Dublin 17.11.99SW 43

Resolved Caveats in Cisco IOS XE Dublin 17.11.1 43

CHAPTER 10 **Additional Information 45**

Troubleshooting 45

Related Documentation 45

Communications, Services, and Additional Information 45



CHAPTER 1

Introduction

Cisco Catalyst 9300 Series Switches are Cisco's lead stackable access platforms for the next-generation enterprise and have been purpose-built to address emerging trends of Security, IoT, Mobility, and Cloud.

They deliver complete convergence with the rest of the Cisco Catalyst 9000 Series Switches in terms of ASIC architecture with a Unified Access Data Plane (UADP) 2.0. The platform runs an Open Cisco IOS XE that supports model driven programmability, has the capacity to host containers, and run 3rd party applications and scripts natively within the switch (by virtue of x86 CPU architecture, local storage, and a higher memory footprint). This series forms the foundational building block for SD-Access, which is Cisco's lead enterprise architecture.

- [Supported Hardware, on page 1](#)

Supported Hardware

Cisco Catalyst 9300 Series Switches—Model Numbers

The following table lists the supported hardware models and the default license levels they are delivered with. For information about the available license levels, see section *License Levels*.

Table 1: Cisco Catalyst 9300 Series Switches

Switch Model	Default License Level	Description
C9300-24H-A	Network Advantage	Stackable 24 10/100/1000 Mbps UPOE+ ports; PoE budget of 830 W with 1100 WAC power supply; supports StackWise-480 and StackPower
C9300-24H-E	Network Essentials	
C9300-24P-A	Network Advantage	Stackable 24 10/100/1000 PoE+ ports; PoE budget of 437W; 715 WAC power supply; supports StackWise-480 and StackPower
C9300-24P-E	Network Essentials	

Switch Model	Default License Level	Description
C9300-24S-A	Network Advantage	Stackable 24 1G SFP ports; two power supply slots with 715 WAC power supply installed by default; supports StackWise-480 and StackPower.
C9300-24S-E	Network Essentials	
C9300-24T-A	Network Advantage	Stackable 24 10/100/1000 Ethernet ports; 350 WAC power supply; supports StackWise-480 and StackPower
C9300-24T-E	Network Essentials	
C9300-24U-A	Network Advantage	Stackable 24 10/100/1000 UPoE ports; PoE budget of 830W; 1100 WAC power supply; supports StackWise-480 and StackPower
C9300-24U-E	Network Essentials	
C9300-24UB-A	Network Advantage	Stackable 24 10/100/1000 Mbps UPOE ports that provide deep buffers and higher scale; PoE budget of 830W with 1100 WAC power supply; supports StackWise-480 and StackPower
C9300-24UB-E	Network Essentials	
C9300-24UX-A	Network Advantage	Stackable 24 Multigigabit Ethernet 100/1000/2500/5000/10000 UPoE ports; PoE budget of 490 W with 1100 WAC power supply; supports StackWise-480 and StackPower
C9300-24UX-E	Network Essentials	
C9300-24UXB-A	Network Advantage	Stackable 24 Multigigabit Ethernet (100 Mbps or 1/2.5/5/10 Gbps) UPOE ports that provide deep buffers and higher scale; PoE budget of 560 W with 1100 WAC power supply; supports StackWise-480 and StackPower
C9300-24UXB-E	Network Essentials	
C9300-48H-A	Network Advantage	Stackable 48 10/100/1000 Mbps UPOE+ ports; PoE budget of 822 W with 1100 WAC power supply; supports StackWise-480 and StackPower
C9300-48H-E	Network Essentials	
C9300-48T-A	Network Advantage	Stackable 48 10/100/1000 Ethernet ports; 350 WAC power supply; supports StackWise-480 and StackPower
C9300-48T-E	Network Essentials	

Switch Model	Default License Level	Description
C9300-48P-A	Network Advantage	Stackable 48 10/100/1000 PoE+ ports; PoE budget of 437W; 715 WAC power supply; supports StackWise-480 and StackPower
C9300-48P-E	Network Essentials	
C9300-48S-A	Network Advantage	Stackable 48 1G SFP ports; two power supply slots with 715 WAC power supply installed by default; supports StackWise-480 and StackPower.
C9300-48S-E	Network Essentials	
C9300-48T-A	Network Advantage	Stackable 48 10/100/1000 Ethernet ports; 350 WAC power supply; supports StackWise-480 and StackPower
C9300-48T-E	Network Essentials	
C9300-48U-A	Network Advantage	Stackable 48 10/100/1000 UPoE ports; PoE budget of 822 W; 1100 WAC power supply; supports StackWise-480 and StackPower
C9300-48U-E	Network Essentials	
C9300-48UB-A	Network Advantage	Stackable 48 10/100/1000 Mbps UPOE ports that provide deep buffers and higher scale; PoE budget of 822 W with 1100 WAC power supply; supports StackWise-480 and StackPower
C9300-48UB-E	Network Essentials	
C9300-48UN-A	Network Advantage	Stackable 48 Multigigabit Ethernet (100 Mbps or 1/2.5/5 Gbps) UPoE ports; PoE budget of 610 W with 1100 WAC power supply; supports StackWise-480 and StackPower
C9300-48UN-E	Network Essentials	
C9300-48UXM-A	Network Advantage	Stackable 48 (36 2.5G Multigigabit Ethernet and 12 10G Multigigabit Ethernet Universal Power Over Ethernet (UPOE) ports)
C9300-48UXM-E	Network Essentials	

Table 2: Cisco Catalyst 9300L Series Switches

Switch Model	Default License Level	Description
C9300L-24T-4G-A	Network Advantage	Stackable 24x10/100/1000M Ethernet ports; 4x1G SFP fixed uplink ports; 350 WAC power supply; supports StackWise-320.
C9300L-24T-4G-E	Network Essentials	
C9300L-24P-4G-A	Network Advantage	Stackable 24x10/100/1000M PoE+ ports; 4x1G SFP fixed uplink ports; PoE budget of 505W with 715 WAC power supply; supports StackWise-320.
C9300L-24P-4G-E	Network Essentials	
C9300L-24T-4X-A	Network Advantage	Stackable 24x10/100/1000M Ethernet ports; 4x10G SFP+ fixed uplink ports; 350 WAC power supply; supports StackWise-320.
C9300L-24T-4X-E	Network Essentials	
C9300L-24P-4X-A	Network Advantage	Stackable 24x10/100/1000M PoE+ ports; 4x10G SFP+ fixed uplink ports; PoE budget of 505W with 715 WAC power supply; supports StackWise-320.
C9300L-24P-4X-E	Network Essentials	
C9300L-48T-4G-A	Network Advantage	Stackable 48x10/100/1000M Ethernet ports; 4x1G SFP fixed uplink ports; 350 WAC power supply; supports StackWise-320.
C9300L-48T-4G-E	Network Essentials	
C9300L-48P-4G-A	Network Advantage	Stackable 48x10/100/1000M PoE+ ports; 4x1G SFP fixed uplink ports; PoE budget of 505W with 715 WAC power supply; supports StackWise-320.
C9300L-48P-4G-E	Network Essentials	
C9300L-48T-4X-A	Network Advantage	Stackable 48x10/100/1000M Ethernet ports; 4x10G SFP+ fixed uplink ports; 350 WAC power supply; supports StackWise-320.
C9300L-48T-4X-E	Network Essentials	
C9300L-48P-4X-A	Network Advantage	Stackable 48x10/100/1000M PoE+ ports; 4x10G SFP+ fixed uplink ports; PoE budget of 505W with 715 WAC power supply; supports StackWise-320.
C9300L-48P-4X-E	Network Essentials	

Switch Model	Default License Level	Description
C9300L-48PF-4G-A	Network Advantage	Stackable 48 10/100/1000 Mbps PoE+ ports; 4x1G SFP+ fixed uplink ports; PoE budget of 890 W with 1100 WAC power supply; supports StackWise-320.
C9300L-48PF-4G-E	Network Essentials	
C9300L-48PF-4X-A	Network Advantage	Stackable 48 10/100/1000 Mbps PoE+ ports; 4x10G SFP+ fixed uplink ports; PoE budget of 890 W with 1100 WAC power supply; supports StackWise-320.
C9300L-48PF-4X-E	Network Essentials	
C9300L-24UXG-4X-A	Network Advantage	Stackable 16 10/100/1000 Mbps and 8 Multigigabit Ethernet (100 Mbps or 1/2.5/5/10 Gbps) UPOE ports; 4x10G SFP+ fixed uplink ports; PoE budget of 880 W with 1100 WAC power supply; supports StackWise-320.
C9300L-24UXG-4X-E	Network Essentials	
C9300L-24UXG-2Q-A	Network Advantage	Stackable 16 10/100/1000 Mbps and 8 Multigigabit Ethernet (100 Mbps or 1/2.5/5/10 Gbps) UPOE ports; 2x40G QSFP+ fixed uplink ports; PoE budget of 722 W with 1100 WAC power supply; supports StackWise-320.
C9300L-24UXG-2Q-E	Network Essentials	
C9300L-48UXG-4X-A	Network Advantage	Stackable 36 10/100/1000 Mbps and 12 Multigigabit Ethernet (100 Mbps or 1/2.5/5/10 Gbps) UPOE ports; 4x10G SFP+ fixed uplink ports; PoE budget of 675 W with 1100 WAC power supply; supports StackWise-320.
C9300L-48UXG-4X-E	Network Essentials	
C9300L-48UXG-2Q-A	Network Advantage	Stackable 36 10/100/1000 Mbps and 12 Multigigabit Ethernet (100 Mbps or 1/2.5/5/10 Gbps) UPOE ports; 2x40G QSFP+ fixed uplink ports; PoE budget of 675 W with 1100 WAC power supply; supports StackWise-320.
C9300L-48UXG-2Q-E	Network Essentials	

Table 3: Cisco Catalyst 9300LM Series Switches

Switch Model	Default License Level	Description
C9300LM-48T-4Y-A	Network Advantage	Stackable 48 x 10/100/1000 M Ethernet ports; 4 x 25 GE SFP28 fixed uplink ports; 600 WAC power supply and fixed fans; supports StackWise-320.
C9300LM-48T-4Y-E	Network Essentials	

Switch Model	Default License Level	Description
C9300LM-24U-4Y-A	Network Advantage	Stackable 24 x 10/100/1000 M UPOE ports; 4 x 25 GE SFP28 fixed uplink ports; PoE budget of 420 W with a single default 600 WAC power supply; supports StackWise-320.
C9300LM-24U-4Y-E	Network Essentials	
C9300LM-48U-4Y-A	Network Advantage	Stackable 48 x 10/100/1000 M UPOE ports; 4 x 25 GE SFP28 fixed uplink ports; PoE budget of 790 W with a single default 1000 WAC power supply; supports StackWise-320.
C9300LM-48U-4Y-E	Network Essentials	
C9300LM-48UX-4Y-A	Network Advantage	Stackable 40 x 10/100/1000 M and 8 Multigigabit Ethernet (100M/1000M/2.5GE/5GE/10GE) UPOE ports; 4 x 25 GE SFP28 fixed uplink ports; PoE budget of 790 W with a single default 1000 WAC power supply; supports StackWise-320.
C9300LM-48UX-4Y-E	Network Essentials	

Table 4: Cisco Catalyst 9300X Series Switches

Switch Model	Default License Level	Description
C9300X-12Y-A	Network Advantage	Stackable 12 1/10/25 GE SFP28 downlink ports; 715 WAC power supply; supports StackPower+, StackWise-1T and C9300X-NM network modules.
C9300X-12Y-E	Network Essentials	
C9300X-24Y-A	Network Advantage	Stackable 24 1/10/25 GE SFP28 downlink ports; 715 WAC power supply; supports StackPower+, StackWise-1 and C9300X-NM network modules.
C9300X-24Y-E	Network Essentials	
C9300X-24HX-A	Network Advantage	Stackable 24 Multigigabit Ethernet (100 Mbps or 1/2.5/5/10 Gbps) UPOE+ ports; PoE budget of 735W with 1100WAC power supply; supports StackPower+, StackWise-1T and C9300X-NM network modules.
C9300X-24HX-E	Network Essentials	
C9300X-48HX-A	Network Advantage	Stackable 48 Multigigabit Ethernet (100 Mbps or 1/2.5/5/10 Gbps) UPOE+ports; PoE budget of 590W with 1100 WAC power supply; supports StackPower+, StackWise-1T and C9300X-NM network modules.
C9300X-48HX-E	Network Essentials	
C9300X-48TX-A	Network Advantage	Stackable 48 Multigigabit Ethernet (100 Mbps or 1/2.5/5/10 Gbps) ports; 715WAC powersupply; supports StackPower+, StackWise-1T and C9300X-NM network modules.
C9300X-48TX-E	Network Essentials	
C9300X-48HXN-A	Network Advantage	Stackable 40 x 100/1000 M or 2.5/5 GE Multigigabit Ethernet and 8 x 100/1000 M or 2.5/5/10 GE Multigigabit Ethernet UPOE+ ports; PoE budget of 690W with 1100WAC power supply; supports StackPower+, StackWise-1T and C9300X-NM network modules
C9300X-48HXN-E	Network Essentials	

Network Modules

The following table lists the optional uplink network modules with 1-Gigabit, 10-Gigabit, 25-Gigabit, and 40-Gigabit slots. You should only operate the switch with either a network module or a blank module installed.

Network Module	Description
C3850-NM-4-1G ¹	Four 1 Gigabit Ethernet SFP module slots
C3850-NM-2-10G ¹	Two 10 Gigabit Ethernet SFP module slots
C3850-NM-4-10G ¹	Four 10 Gigabit Ethernet SFP module slots
C3850-NM-8-10G ¹	Eight 10 Gigabit Ethernet SFP module slots
C3850-NM-2-40G ¹	Two 40 Gigabit Ethernet SFP module slots
C9300-NM-4G ²	Four 1 Gigabit Ethernet SFP module slots
C9300-NM-4M ²	Four MultiGigabit Ethernet slots
C9300-NM-8X ²	Eight 10 Gigabit Ethernet SFP+ module slots
C9300-NM-2Q ²	Two 40 Gigabit Ethernet QSFP+ module slots
C9300-NM-2Y ²	Two 25 Gigabit Ethernet SFP28 module slots
C9300X-NM-2C ³	Two 40 Gigabit Ethernet/100 Gigabit Ethernet QSFP+ module slots
C9300X-NM-4C ³	Four 40 Gigabit Ethernet/100 Gigabit Ethernet slots with a QSFP+ connector in each slot.
C9300X-NM-8M ³	Eight Multigigabit Ethernet slots
C9300X-NM-8Y ³	Eight 25 Gigabit Ethernet/10 Gigabit Ethernet/1 Gigabit Ethernet SFP+ module slots


Note

1. These network modules are supported only on the C3850 and C9300 SKUs of the Cisco Catalyst 3850 Series Switches and Cisco Catalyst 9300 Series Switches respectively.
2. These network modules are supported only on the C9300 SKUs of the Cisco Catalyst 9300 Series Switches.
3. These network modules are supported only on the C9300X SKUs of the Cisco Catalyst 9300 Series Switches.

The following table lists the network modules that are supported on the Cisco Catalyst 9300X-HXN Series Switches and the ports that are usable on each of these network module:

Table 5: Network Modules Supported on Catalyst 9300X-HXN Series Switches

Network Module	Cisco IOS XE Cupertino 17.7.1 and Previous Releases	Cisco IOS XE Cupertino 17.8.1 and Later Releases
C9300X-NM-8Y (8x25G)	Ports 1 to 4 usable.	Ports 1 to 6 usable. Ports 7 and 8 are permanently disabled.
C9300X-NM-8M (8xmGig)	Ports 1 to 4 usable.	Ports 1 to 6 usable. Ports 7 and 8 are permanently disabled.
C9300X-NM-2C (2x100G/2x40G)	Ports 1 to 2 usable. No breakout cable support.	Ports 1 and 2 usable. Breakout cable supported only on port 1. No support for breakout cable on port 2.

Optics Modules

Cisco Catalyst Series Switches support a wide range of optics and the list of supported optics is updated on a regular basis. Use the [Transceiver Module Group \(TMG\) Compatibility Matrix](#) tool, or consult the tables at this URL for the latest transceiver module compatibility information: https://www.cisco.com/en/US/products/hw/modules/ps5455/products_device_support_tables_list.html



CHAPTER 2

Whats New in Cisco IOS XE Dublin 17.11.x

- [Hardware Features in Cisco IOS XE Dublin 17.11.99SW, on page 9](#)
- [Software Features in Cisco IOS XE Dublin 17.11.99SW, on page 9](#)
- [Hardware and Software Behavior Changes in Cisco IOS XE Dublin 17.11.99SW, on page 10](#)
- [Hardware Features in Cisco IOS XE Dublin 17.11.1, on page 10](#)
- [Software Features in Cisco IOS XE Dublin 17.11.1, on page 10](#)
- [Hardware and Software Behavior Changes in Cisco IOS XE Dublin 17.11.1, on page 13](#)

Hardware Features in Cisco IOS XE Dublin 17.11.99SW

There are no new hardware features in this release.

Software Features in Cisco IOS XE Dublin 17.11.99SW

Feature Name	Description
Tenant Routed Multicast over BGP EVPN VXLANv6	<p>Tenant Routed Multicast over BGP EVPN VXLANv6 enables the delivery of IPv4 and IPv6 multicast host traffic in BGP EVPN overlay multi-tenant fabric in an efficient and resilient manner. The new software capability enables IPv4 and IPv6 multicast in overlay with underlay network infrastructure natively running single-stack IPv6. The Tenant Routed Multicast over BGP EVPN VXLANv6 is supported over IPv6 Default MDT group.</p> <p>For more information, see Configuring Tenant Routed Multicast over BGP EVPN VXLANv6.</p>

New on the WebUI

There are no new WebUI features in this release.

Hardware and Software Behavior Changes in Cisco IOS XE Dublin 17.11.99SW

There are no behavior changes in this release.

Hardware Features in Cisco IOS XE Dublin 17.11.1

Feature Name	Description
Cisco 100GBASE QSFP-100G Modules on Cisco Catalyst 9300X Series Switches	<p>Supported transceiver module product numbers:</p> <ul style="list-style-type: none"> • QSFP-100G-FR-S <p>For information about the module, see Cisco 100GBASE QSFP-100G Modules. For information about device compatibility, see the Transceiver Module Group (TMG) Compatibility Matrix.</p>

Software Features in Cisco IOS XE Dublin 17.11.1

Feature Name	Description
<p>BGP EVPN VXLAN</p> <ul style="list-style-type: none"> • Dynamic BGP Peering for EVPN • EVPN Microsegmentation • EVPN Route Map Support • Multi-Homing in a BGP EVPN VXLAN Fabric 	<p>The following BGP EVPN VXLAN features are introduced in this release:</p> <ul style="list-style-type: none"> • Dynamic BGP Peering for EVPN: Introduces support for BGP dynamic neighbor sessions to the L2VPN EVPN address family. (Network Advantage) • EVPN Microsegmentation: BGP EVPN VXLAN integrates Cisco TrustSec to provide microsegmentation and end-to-end access control with the propagation of the security group tag (SGT). Using security group-based access control lists (SGACLs), you can control the operations that a user can perform, based on the security group assignments and destination resources in a VXLAN campus fabric. • EVPN Route Map Support: The Leaf, Spine, and Border nodes of a BGP EVPN fabric now support route map for the L2VPN address-family. With route map support, the BGP attributes and their values can be modified to customize the routing policy based on the requirement. The routing policy can be applied for both inbound and outbound EVPN routes. • Multi-Homing in a BGP EVPN VXLAN Fabric: BGP EVPN is enhanced to restrict the ethernet segment operations to the EVPN-controlled VLANs on the trunk port. This allows traditional Layer 2 domains to co-exist with Layer 2 VNI-enabled VLANs at access layer. It also allows selective VLAN migration to overlay VXLAN segmentation.

Feature Name	Description
Default Limits for redistributed routes and LSA in OSPF	Default values have been assigned to the number of redistributed routes and LSAs in OSPF to prevent the device being flooded with routes. The default values for redistributed routes is 10240 routes. The default value for LSAs is 50,000 LSAs. You can customize the default values.
Deprecation of Weak Ciphers	The minimum RSA key pair size must be 2048 bits. The compliance shield on the device must be disabled using the crypto engine compliance shield disable command to use the weak RSA key.
Device Telemetry	<p>Important: Cisco is constantly striving to advance our products and services. Knowing how you use our products is key to accomplishing this goal. To that end, Cisco will collect device and licensing systems information through Cisco Smart Software Manager (CSSM) for product and customer experience improvement, analytics, and adoption. Cisco processes your data in accordance with the Cisco End User License Agreement, the Cisco Privacy Statement and any other applicable agreement with Cisco. To modify your organization's preferences for device and licensing systems information, use the paec command. See Network Management Commands → paec.</p> <p>Introduces the support for device telemetry. This feature allows for the collection of non-personal usage device systems information for Cisco products, which helps in continuous product improvements. This feature is enabled by default. Use the no form of the paec command to disable this feature.</p> <p>Note Turning off Smart Licensing Device Systems Information does not impact other systems information collection from Cisco DNA Center or vManage.</p> <p>The following commands are introduced as part of this feature:</p> <ul style="list-style-type: none"> • paec • show product-analytics kpi • show product-analytics report • show product-analytics stats
GRE over IPsec	<p>Introduces support for GRE over IPsec tunnel on Cisco Catalyst 9300X Series Switches. This feature allows a GRE encapsulated payload to be transferred securely over an IPsec tunnel.</p> <p>(DNA Advantage)</p>
LAN MACsec over MPLS	Introduces support for MACsec with MPLS. This feature allows MPLS packets to be encrypted with a MACsec tag.
NETCONF support for PTPv2	Introduces support for configuring PTPv2 with NETCONF. NETCONF provides a mechanism to install, manipulate, and delete the configuration of network devices.

Feature Name	Description
Programmability <ul style="list-style-type: none"> • gNMI Dial-Out Telemetry • Multicast Routing Support on the AppGigabitEthernet Port • PROTO Encoding • Secure Zero-Touch Provisioning • YANG Data Models 	<p>The following programmability features are introduced in this release:</p> <ul style="list-style-type: none"> • gNMI Dial-Out Telemetry: This feature introduces a tunnel service for gNMI dial-out connections. Using this feature, you can use the device (that acts as a tunnel client) to dial out to a collector (that acts as a tunnel server). The tunnel server forwards requests from gNMI or gNOI clients. This feature is supported only on Cisco Catalyst 9300, Catalyst 9300L, and Catalyst 9300X Series Switches. (Network Essentials) • Multicast Routing Support on the AppGigabitEthernet Port: Multicast traffic forwarding is supported on the AppGigabitEthernet interface. Applications can select the networks that allow multicast traffic. This feature is supported only on Cisco Catalyst 9300, Catalyst 9300L, and Catalyst 9300X Series Switches. • PROTO Encoding: gNMI protocol supports PROTO encoding. The gnmi.proto file represents the blueprint for generating a complete set of client and server-side procedures that instantiate the framework for the gNMI protocol. This feature is supported only on Cisco Catalyst 9300, Catalyst 9300L, and Catalyst 9300X Series Switches. • Secure Zero-Touch Provisioning: Secure ZTP is a technique to securely provision a device, while it is booting in a factory-default state. The provisioning updates the boot image, commits an initial configuration, and executes customer-specific scripts. The provisioned device can establish secure connections with other systems. This feature is supported only on Cisco Catalyst 9300, Catalyst 9300L, and Catalyst 9300X Series Switches. (Network Essentials) • YANG Data Models: For the list of Cisco IOS XE YANG models available with this release, navigate to: https://github.com/YangModels/yang/tree/master/vendor/cisco/xe/17111. (Network Advantage)
show aaa dead-criteria radius enhancement command	The show aaa dead-criteria radius enhancement command allows you to use the configured radius server name as the input to identify the unique server in the server group and print the server dead criteria configuration.
show access-session command	The info keyword was introduced for the show access-session command.

Feature Name	Description
Silent Host Handling	<p>The silent-host-detection keyword was introduced for the following commands:</p> <ul style="list-style-type: none"> • database-mapping • show lisp instance-id ipv4 database • show lisp instance-id ipv6 database • show lisp instance-id ipv4 server • show lisp instance-id ipv6 server
TCN Flood	<p>The no ip igmp snooping tcn flood command was introduced to disable the flooding of multicast traffic during a spanning-tree Topology Change Notification (TCN) event on STP non-edge ports. STP Edge Ports do not flood multicast traffic during a spanning-tree Topology Change Notification (TCN) event.</p>

New on the WebUI

There are no new WebUI features in this release.

Hardware and Software Behavior Changes in Cisco IOS XE Dublin 17.11.1

Behavior Change	Description
Deprecation of snmp-server enable traps license global configuration command	The command was deprecated. The associated MIB, CISCO-LICENSE-MGMT-MIB, is also no longer supported. In place of the deprecated command and unsupported MIB, use CISCO-SMART-LIC-MIB.
New flag for the IPv6 SGACL monitor mode	A new flag has been introduced for the IPv6 SGACL monitor mode. This was introduced to address hardware limitation of a single counter shared for IPv4 and IPv6 traffic. The HW_Monitor counter gets incremented irrespective of the type of traffic, which in turn updates the monitor mode flag. With a separate flag for IPv6 and IPv4 SGACL monitor mode, only the corresponding protocol flag is updated depending on the type of traffic.
show power and show power detail command output	The show power and show power detail command outputs are modified to display the correct power information of the standby switch.



CHAPTER 3

Important Notes

- [Important Notes, on page 15](#)

Important Notes

- [Unsupported Features](#)
- [Complete List of Supported Features](#)
- [Accessing Hidden Commands](#)
- [Default Behaviour](#)

Unsupported Features

- **Cisco TrustSec**
 - Cisco TrustSec Network Device Admission Control (NDAC) on Uplinks
- **Security**
 - MACsec switch-to-host connections in an overlay network.
 - Virtual Routing and Forwarding (VRF)-Aware web authentication
- **System Management**
 - Performance Monitoring (PerfMon)
- Converged Access for Branch Deployments
- Network Load Balancing (NLB)

Complete List of Supported Features

For the complete list of features supported on a platform, see the [Cisco Feature Navigator](#).

Accessing Hidden Commands

Starting with Cisco IOS XE Fuji 16.8.1a, as an improved security measure, the way in which hidden commands can be accessed has changed.

Hidden commands have always been present in Cisco IOS XE, but were not equipped with CLI help. That is, entering a question mark (?) at the system prompt did not display the list of available commands. These commands were only meant to assist Cisco TAC in advanced troubleshooting and were not documented either.

Starting with Cisco IOS XE Fuji 16.8.1a, hidden commands are available under:

- Category 1—Hidden commands in privileged or User EXEC mode. Begin by entering the **service internal** command to access these commands.
- Category 2—Hidden commands in one of the configuration modes (global, interface and so on). These commands do not require the **service internal** command.

Further, the following applies to hidden commands under Category 1 and 2:

- The commands have CLI help. Enter a question mark (?) at the system prompt to display the list of available commands.

Note: For Category 1, enter the **service internal** command before you enter the question mark; you do not have to do this for Category 2.

- The system generates a %PARSER-5-HIDDEN syslog message when a hidden command is used. For example:

```
*Feb 14 10:44:37.917: %PARSER-5-HIDDEN: Warning!!! 'show processes memory old-header '
is a hidden command.
Use of this command is not recommended/supported and will be removed in future.
```

Apart from category 1 and 2, there remain internal commands displayed on the CLI, for which the system does NOT generate the %PARSER-5-HIDDEN syslog message.



Important

We recommend that you use any hidden command only under TAC supervision.

If you find that you are using a hidden command, open a TAC case for help with finding another way of collecting the same information as the hidden command (for a hidden EXEC mode command), or to configure the same functionality (for a hidden configuration mode command) using non-hidden commands.

Default Behaviour

Beginning from Cisco IOS XE Gibraltar 16.12.5 and later, do not fragment bit (DF bit) in the IP packet is always set to 0 for all outgoing RADIUS packets (packets that originate from the device towards the RADIUS server).



CHAPTER 4

Compatibility Matrix and Web UI System Requirements

- [Compatibility Matrix](#), on page 17
- [Web UI System Requirements](#), on page 17

Compatibility Matrix

To view the software compatibility information between Cisco Catalyst 9300 Series Switches, Cisco Identity Services Engine, and Cisco Prime Infrastructure, go to [Cisco Catalyst 9000 Series Switches Software Version Compatibility Matrix](#).

Web UI System Requirements

The following subsections list the hardware and software required to access the Web UI:

Minimum Hardware Requirements

Processor Speed	DRAM	Number of Colors	Resolution	Font Size
233 MHz minimum ¹	512 MB ²	256	1280 x 800 or higher	Small

¹ We recommend 1 GHz

² We recommend 1 GB DRAM

Software Requirements

Operating Systems

- Windows 10 or later
- Mac OS X 10.9.5 or later

Browsers

- Google Chrome—Version 59 or later (On Windows and Mac)

- Microsoft Edge
- Mozilla Firefox—Version 54 or later (On Windows and Mac)
- Safari—Version 10 or later (On Mac)



CHAPTER 5

Licensing and Scaling Guidelines

- [Licensing, on page 19](#)
- [Scaling Guidelines, on page 19](#)

Licensing

For information about licenses required for the features available on Cisco Catalyst 9000 Series Switches, see [Configuring Licenses on Cisco Catalyst 9000 Series Switches](#).

All licensing information relating to Cisco Catalyst 9000 Series Switches are available on this collection page: [Cisco Catalyst 9000 Switching Family Licensing](#).

Available Licensing Models and Configuration Information

- Cisco IOS XE Fuji 16.8.x and earlier: RTU Licensing is the default and the only supported method to manage licenses.
- Cisco IOS XE Fuji 16.9.1 to Cisco IOS XE Amsterdam 17.3.1: Smart Licensing is the default and the only supported method to manage licenses.
- Cisco IOS XE Amsterdam 17.3.2a and later: Smart Licensing Using Policy, which is an enhanced version of Smart Licensing, is the default and the only supported method to manage licenses.

Scaling Guidelines

For information about feature scaling guidelines, see the Cisco Catalyst 9300 Series Switches datasheet at:

<http://www.cisco.com/c/en/us/products/collateral/switches/catalyst-9300-series-switches/datasheet-c78-738977.html>



CHAPTER 6

Limitations and Restrictions

- [Limitations and Restrictions](#), on page 21

Limitations and Restrictions

- ISSU between any Cisco IOS XE software version and Cisco IOS XE Dublin 17.11.99SW software version is not supported.
Cisco IOS XE Dublin 17.11.99SW software version is limited to Catalyst 9000 Series Switches only.
Cisco IOS XE Dublin 17.11.99SW software version does not support No Payload Encryption (NPE) software.
- Control Plane Policing (CoPP)—The **show run** command does not display information about classes configured under `system-cpp policy`, when they are left at default values. Use the **show policy-map system-cpp-policy** or the **show policy-map control-plane** commands in privileged EXEC mode instead.
- Cisco TrustSec restrictions—Cisco TrustSec can be configured only on physical interfaces, not on logical interfaces.
- Flexible NetFlow limitations
 - You cannot configure NetFlow export using the Ethernet Management port (GigabitEthernet0/0).
 - You can not configure a flow monitor on logical interfaces, such as layer 2 port-channels, loopback, tunnels.
 - You can not configure multiple flow monitors of same type (ipv4, ipv6 or datalink) on the same interface for same direction.
- Hardware Limitations—Optics:
 - SFP-10G-T-X supports 100Mbps/1G/10G speeds based on auto negotiation with the peer device. 10Mbps speed is not supported and you cannot force speed settings from the transceiver.
 - PHY Loopback test is not supported on SFP-10G-T-X.
- QoS restrictions
 - When configuring QoS queuing policy, the sum of the queuing buffer should not exceed 100%.
 - Policing and marking policy on sub interfaces is supported.

- Marking policy on switched virtual interfaces (SVI) is supported.
- QoS policies are not supported for port-channel interfaces, tunnel interfaces, and other logical interfaces.
- Stack Queuing and Scheduling (SQS) drops CPU bound packets exceeding 1.4 Gbps.
- Secure Shell (SSH)
 - Use SSH Version 2. SSH Version 1 is not supported.
 - When the device is running SCP and SSH cryptographic operations, expect high CPU until the SCP read process is completed. SCP supports file transfers between hosts on a network and uses SSH for the transfer.

Since SCP and SSH operations are currently not supported on the hardware crypto engine, running encryption and decryption process in software causes high CPU. The SCP and SSH processes can show as much as 40 or 50 percent CPU usage, but they do not cause the device to shutdown.

- Smart Licensing Using Policy: Starting with Cisco IOS XE Amsterdam 17.3.2a, with the introduction of Smart Licensing Using Policy, even if you configure a hostname for a product instance or device, only the Unique Device Identifier (UDI) is displayed. This change in the display can be observed in all licensing utilities and user interfaces where the hostname was displayed in earlier releases. It does not affect any licensing functionality. There is no workaround for this limitation.

The licensing utilities and user interfaces that are affected by this limitation include only the following: Cisco Smart Software Manager (CSSM), Cisco Smart License Utility (CSLU), and Smart Software Manager On-Prem (SSM On-Prem).

This limitation is removed from Cisco IOS XE Cupertino 17.9.1. If you configure a hostname and disable hostname privacy (**no license smart privacy hostname** global configuration command), hostname information is sent from the product instance and displayed on the applicable user interfaces (CSSM, CSLU, SSM On-Prem). For more information, see the command reference for this release.

- Stacking:
 - A switch stack supports up to eight stack members.
 - Only homogenous stacking is supported, mixed stacking is not.

C9300 SKUs can be stacked only with other C9300 SKUs. Similarly C9300L SKUs can be stacked only with other C9300L SKUs.

The following additional restriction applies to the C9300-24UB, C9300-24UXB, and C9300-48UB models of the series: These models can be stacked only with each other. They cannot be stacked with other C9300 SKUs.
 - Auto upgrade for a new member switch is supported only in the install mode.
- TACACS legacy command: Do not configure the legacy **tacacs-server host** command; this command is deprecated. If the software version running on your device is Cisco IOS XE Gibraltar 16.12.2 or a later release, using the legacy command can cause authentication failures. Use the **tacacs server** command in global configuration mode.
- USB Authentication—When you connect a Cisco USB drive to the switch, the switch tries to authenticate the drive against an existing encrypted preshared key. Since the USB drive does not send a key for

authentication, the following message is displayed on the console when you enter **password encryption aes** command:

```
Device(config)# password encryption aes  
Master key change notification called without new or old key
```

- MACsec is not supported on Software-Defined Access deployments.
- VLAN Restriction—It is advisable to have well-defined segregation while defining data and voice domain during switch configuration and to maintain a data VLAN different from voice VLAN across the switch stack. If the same VLAN is configured for data and voice domains on an interface, the resulting high CPU utilization might affect the device.
- Wired Application Visibility and Control limitations:
 - NBAR2 (QoS and Protocol-discovery) configuration is allowed only on wired physical ports. It is not supported on virtual interfaces, for example, VLAN, port channel nor other logical interfaces.
 - NBAR2 based match criteria ‘match protocol’ is allowed only with marking or policing actions. NBAR2 match criteria will not be allowed in a policy that has queuing features configured.
 - ‘Match Protocol’: up to 256 concurrent different protocols in all policies.
 - NBAR2 and Legacy NetFlow cannot be configured together at the same time on the same interface. However, NBAR2 and wired AVC Flexible NetFlow can be configured together on the same interface.
 - Only IPv4 unicast (TCP/UDP) is supported.
 - AVC is not supported on management port (Gig 0/0)
 - NBAR2 attachment should be done only on physical access ports. Uplink can be attached as long as it is a single uplink and is not part of a port channel.
 - Performance—Each switch member is able to handle 2000 connections per second (CPS) at less than 50% CPU utilization. Above this rate, AVC service is not guaranteed.
 - Scale—Able to handle up to 20000 bi-directional flows per 24 access ports and per 48 access ports.
- YANG data modeling limitation—A maximum of 20 simultaneous NETCONF sessions are supported.
- Embedded Event Manager—Identity event detector is not supported on Embedded Event Manager.
- The File System Check (fsck) utility is not supported in install mode.
- Switch Web UI allows configuration of data VLANs only and not voice VLANs. If you remove a voice VLAN configured to an interface using the Web UI, then all data VLANs associated with the interface are also removed by default.



CHAPTER 7

ROMMON Versions

- [ROMMON Versions](#), on page 25

ROMMON Versions

ROMMON, also known as the boot loader, is firmware that runs when the device is powered up or reset. It initializes the processor hardware and boots the operating system software (Cisco IOS XE software image). The ROMMON is stored on the following Serial Peripheral Interface (SPI) flash devices on your switch:

- **Primary:** The ROMMON stored here is the one the system boots every time the device is powered-on or reset.
- **Golden:** The ROMMON stored here is a backup copy. If the one in the primary is corrupted, the system automatically boots the ROMMON in the golden SPI flash device.

ROMMON upgrades may be required to resolve firmware defects, or to support new features, but there may not be new versions with every release.

Release	ROMMON Version (C9300 Models)	ROMMON Version (C9300L Models)	ROMMON Version (C9300X Models)	ROMMON Version (C9300LM Models)
Dublin 17.11.1	17.11.1r[FC1]	17.10.1r[FC1]	17.11.1r	17.10.1r
Dublin 17.10.1	17.10.1r[FC1]	17.10.1r[FC1]	17.9.1r	17.10.1r
Cupertino 17.9.6	17.9.2r	17.9.2r	17.9.4r	17.9.1r[FC1]
Cupertino 17.9.5	17.9.2r	17.9.2r	17.9.4r	17.9.1r[FC1]
Cupertino 17.9.4	17.9.2r	17.9.1r	17.9.1r	17.9.1r[FC1]
Cupertino 17.9.3	17.9.2r	17.9.1r	17.9.1r	17.9.1r[FC1]
Cupertino 17.9.2	17.9.1r	17.9.1r	17.9.1r	17.9.1r
Cupertino 17.9.1	17.9.1r	17.9.1r	17.9.1r	17.9.1r
Cupertino 17.8.1	17.8.1r[FC2]	17.8.1r[FC2]	17.5.1r	17.8.1r
Cupertino 17.7.1	17.6.1r[FC2]	17.6.1r[FC2]	17.5.1r	-

Release	ROMMON Version (C9300 Models)	ROMMON Version (C9300L Models)	ROMMON Version (C9300X Models)	ROMMON Version (C9300LM Models)
Bengaluru 17.6.8	17.6.6r	17.6.1r[FC2]	17.5.1r	-
Bengaluru 17.6.7	17.6.6r	17.6.1r[FC2]	17.5.1r	-
Bengaluru 17.6.6a	17.6.6r	17.6.1r[FC2]	17.5.1r	-
Bengaluru 17.6.6	17.6.6r	17.6.1r[FC2]	17.5.1r	-
Bengaluru 17.6.5	17.6.6r	17.6.1r[FC2]	17.5.1r	-
Bengaluru 17.6.4	17.6.1r[FC2]	17.6.1r[FC2]	17.5.1r	-
Bengaluru 17.6.3	17.6.1r[FC2]	17.6.1r[FC2]	17.5.1r	-
Bengaluru 17.6.2	17.6.1r[FC2]	17.6.1r[FC2]	17.5.1r	-
Bengaluru 17.6.1	17.6.1r[FC2]	17.6.1r[FC2]	17.5.1r	-
Bengaluru 17.5.1	17.5.2r	17.4.1r[FC2]	17.5.1r	-
Bengaluru 17.4.1	17.4.1r	17.4.1r[FC2]	-	-
Amsterdam 17.3.8a	17.3.8r	17.8.1r[FC2]	-	-
Amsterdam 17.3.8	17.3.8r	17.8.1r[FC2]	-	-
Amsterdam 17.3.7	17.3.2r	17.8.1r[FC2]	-	-
Amsterdam 17.3.6	17.3.2r	17.8.1r[FC2]	-	-
Amsterdam 17.3.5	17.3.2r	17.8.1r[FC2]	-	-
Amsterdam 17.3.4	17.3.2r	17.3.2r	-	-
Amsterdam 17.3.3	17.3.2r	17.3.2r	-	-
Amsterdam 17.3.2a	17.3.2r	17.3.2r	-	-
Amsterdam 17.3.1	17.3.1r[FC2]	17.1.1r [FC1]	-	-
Amsterdam 17.2.1	17.2.1r[FC1]	17.1.1r[FC1]	-	-
Amsterdam 17.1.1	17.1.1r [FC1]	17.1.1r [FC1]	-	-



CHAPTER 8

Upgrading the Switch Software

- [Finding the Software Version, on page 27](#)
- [Software Images, on page 27](#)
- [Upgrading the ROMMON, on page 28](#)
- [Software Installation Commands, on page 28](#)
- [Upgrading in Install Mode, on page 29](#)
- [Downgrading in Install Mode, on page 36](#)
- [Field-Programmable Gate Array Version Upgrade, on page 41](#)

Finding the Software Version

The package files for the Cisco IOS XE software are stored on the system board flash device (flash:).

You can use the **show version** privileged EXEC command to see the software version that is running on your switch.



Note Although the **show version** output always shows the software image running on the switch, the model name shown at the end of this display is the factory configuration and does not change if you upgrade the software license.

You can also use the **dir filesystem:** privileged EXEC command to see the directory names of other software images that you might have stored in flash memory.

Software Images

Release	Image Type	File Name
Cisco IOS XE Dublin 17.11.99SW ³	CAT9K_IOSXE	cat9k_iosxe.17.11.99sw.SPA.bin
Cisco IOS XE Dublin 17.11.1	CAT9K_IOSXE	cat9k_iosxe.17.11.01.SPA.bin
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.11.01.SPA.bin

³ • Targeted for limited deployments

- Cisco Technical Assistant (TAC) supported
- Consult your Cisco Sales team prior considering for network deployment

Upgrading the ROMMON

To know the ROMMON or bootloader version that applies to every major and maintenance release, see [ROMMON Versions, on page 25](#).

You can upgrade the ROMMON before, or, after upgrading the software version. If a new ROMMON version is available for the software version you are upgrading to, proceed as follows:

- Upgrading the ROMMON in the primary SPI flash device

This ROMMON is upgraded automatically. When you upgrade from an existing release on your switch to a later or newer release for the first time, and there is a new ROMMON version in the new release, the system automatically upgrades the ROMMON in the primary SPI flash device, based on the hardware version of the switch.

- Upgrading the ROMMON in the golden SPI flash device

You must manually upgrade this ROMMON. Enter the **upgrade rom-monitor capsule golden switch** command in privileged EXEC mode.



Note

- In case of a switch stack, perform the upgrade on the active switch and all members of the stack.

After the ROMMON is upgraded, it will take effect on the next reload. If you go back to an older release after this, the ROMMON is not downgraded. The updated ROMMON supports all previous releases.

Software Installation Commands

Summary of Software Installation Commands	
Supported starting from Cisco IOS XE Everest 16.6.2 and later releases	
To install and activate the specified file, and to commit changes to be persistent across reloads: install add file <i>filename</i> [activate commit]	
To separately install, activate, commit, cancel, or remove the installation file: install ?	
add file tftp: <i>filename</i>	Copies the install file package from a remote location to the device and performs a compatibility check for the platform and image versions.
activate [auto-abort-timer]	Activates the file, and reloads the device. The auto-abort-timer keyword automatically rolls back image activation.
commit	Makes changes persistent over reloads.

Summary of Software Installation Commands**Supported starting from Cisco IOS XE Everest 16.6.2 and later releases**

rollback to committed	Rolls back the update to the last committed version.
abort	Cancels file activation, and rolls back to the version that was running before the current installation procedure started.
remove	Deletes all unused and inactive software installation files.



Note The **request platform software** commands are deprecated starting from Cisco IOS XE Gibraltar 16.10.1. The commands are visible on the CLI in this release and you can configure them, but we recommend that you use the **install** commands to upgrade or downgrade.

Summary of request platform software CommandsDevice# **request platform software package ?**

clean	Cleans unnecessary package files from media
copy	Copies package to media
describe	Describes package content
expand	Expands all-in-one package to media
install	Installs the package
uninstall	Uninstalls the package
verify	Verifies In Service Software Upgrade (ISSU) software package compatibility

Upgrading in Install Mode

Follow these instructions to upgrade from one release to another, in install mode. To perform a software image upgrade, you must be booted into IOS through **boot flash:packages.conf**.

Before you begin

Note that you can use this procedure for the following upgrade scenarios:

When upgrading from ...	Use these commands...	To upgrade to...
Cisco IOS XE Everest 16.5.1a or Cisco IOS XE Everest 16.6.1	Only request platform software commands	Cisco IOS XE Dublin 17.11.x
Cisco IOS XE Everest 16.6.2 and all later releases	Either install commands or request platform software commands ⁴ .	

- ⁴ The **request platform software** commands are deprecated. So although they are still visible on the CLI, we recommend that you use **install** commands.

The sample output in this section displays upgrade from Cisco IOS XE Dublin 17.10.1 to Cisco IOS XE Dublin 17.11.1 using **install** commands only.

Procedure

Step 1 Clean-up **install remove inactive**

Use this command to clean-up old installation files in case of insufficient space and to ensure that you have at least 1GB of space in flash, to expand a new image.

The following sample output displays the cleaning up of unused files, by using the **install remove inactive** command:

```
Switch# install remove inactive

install_remove: START Wed Mar 22 10:02:31 PDT 2023
install_remove: Removing IMG
Cleaning up unnecessary package files
No path specified, will use booted path /flash/packages.conf

Cleaning /flash
Scanning boot directory for packages ... done.
Preparing packages list to delete ...
[R0]: /flash/packages.conf File is in use, will not delete.
[R1]: /flash/packages.conf File is in use, will not delete.
[R0]: /flash/cat9k-cc_srdriver.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-cc_srdriver.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-espbase.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-espbase.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-guestshell.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-guestshell.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-lni.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-lni.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-rpbase.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-rpbase.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-sipbase.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-sipbase.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-sipspa.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-sipspa.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-srdriver.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-srdriver.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-webui.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-webui.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-wlc.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-wlc.17.10.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k_iosxe.17.10.01.SPA.conf File is in use, will not delete.
[R1]: /flash/cat9k_iosxe.17.10.01.SPA.conf File is in use, will not delete.
[R0]: /flash/cat9k-rpboot.17.10.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-rpboot.17.10.01.SPA.pkg File is in use, will not delete.

The following files will be deleted:
[R0]: /flash/cat9k_iosxe.17.10.01.SPA.bin
[R1]: /flash/cat9k_iosxe.17.10.01.SPA.bin
[R0]: /flash/cat9k-cc_srdriver.17.09.02.SPA.pkg
[R1]: /flash/cat9k-cc_srdriver.17.09.02.SPA.pkg
[R0]: /flash/cat9k-espbase.17.09.02.SPA.pkg
```

```
[R1]: /flash/cat9k-espbases.17.09.02.SPA.pkg
[R0]: /flash/cat9k-guestshell.17.09.02.SPA.pkg
[R1]: /flash/cat9k-guestshell.17.09.02.SPA.pkg
[R0]: /flash/cat9k-lni.17.09.02.SPA.pkg
[R1]: /flash/cat9k-lni.17.09.02.SPA.pkg
[R0]: /flash/cat9k-rpbases.17.09.02.SPA.pkg
[R1]: /flash/cat9k-rpbases.17.09.02.SPA.pkg
[R0]: /flash/cat9k-sipbase.17.09.02.SPA.pkg
[R1]: /flash/cat9k-sipbase.17.09.02.SPA.pkg
[R0]: /flash/cat9k-sipspace.17.09.02.SPA.pkg
[R1]: /flash/cat9k-sipspace.17.09.02.SPA.pkg
[R0]: /flash/cat9k-srdriver.17.09.02.SPA.pkg
[R1]: /flash/cat9k-srdriver.17.09.02.SPA.pkg
[R0]: /flash/cat9k-webui.17.09.02.SPA.pkg
[R1]: /flash/cat9k-webui.17.09.02.SPA.pkg
[R0]: /flash/cat9k-wlc.17.09.02.SPA.pkg
[R1]: /flash/cat9k-wlc.17.09.02.SPA.pkg
[R0]: /flash/cat9k_iosxe.17.09.02.SPA.conf
[R1]: /flash/cat9k_iosxe.17.09.02.SPA.conf
[R0]: /flash/cat9k-rpboot.17.09.02.SPA.pkg
[R1]: /flash/cat9k-rpboot.17.09.02.SPA.pkg
```

Do you want to remove the above files? [y/n]y

```
Deleting file /flash/cat9k_iosxe.17.10.01.SPA.bin ... done.
Deleting file /flash/cat9k-cc_srdriver.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-espbases.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-guestshell.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-lni.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-rpbases.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-sipbase.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-sipspace.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-srdriver.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-webui.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-wlc.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k_iosxe.17.09.02.SPA.conf ... done.
Deleting file /flash/cat9k-rpboot.17.09.02.SPA.pkg ... done.
Deleting /flash/.images/17.10.01.0.1444.1669767962 ... done.
SUCCESS: Files deleted.
```

```
--- Starting Post_Remove_Cleanup ---
Performing REMOVE_POSTCHECK on all members
Finished Post_Remove_Cleanup
SUCCESS: install_remove Wed Mar 22 10:02:36 PDT 2023
Switch#
<output truncated>
```

Step 2

Copy new image to flash

a) **copy tftp:[//location/]directory[/filename]flash:**

Use this command to copy the new image from a TFTP server to flash memory. The location is either an IP address or a host name. The filename is specified relative to the directory used for file transfers. Skip this step if you want to use the new image from a TFTP server.

```
Switch# copy tftp://10.8.0.6/image/cat9k_iosxe.17.11.01.SPA.bin flash:
```

```
destination filename [cat9k_iosxe.17.11.01.SPA.bin]?
Accessing tftp://10.8.0.6/image/cat9k_iosxe.17.11.01.SPA.bin...
Loading /cat9k_iosxe.17.11.01.SPA.bin from 10.8.0.6 (via GigabitEthernet0/0):
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
[OK - 601216545 bytes]
```

```
601216545 bytes copied in 50.649 secs (11870255 bytes/sec)
```

b) **dir flash:**

Use this command to confirm that the image has been successfully copied to flash.

```
Switch# dir flash:*.bin

Directory of flash:/*.bin

Directory of flash:/

434184 -rw- 601216545   Mar 27 2023 10:18:11 -07:00 cat9k_iosxe.17.11.01.SPA.bin
11353194496 bytes total (8976625664 bytes free)
```

Step 3 Set boot variablea) **no boot system**

Use this command to reset the boot variable. This command removes the startup system image specification. Otherwise, the switch may boot a previously configured boot image.

```
Switch(config)# no boot system
```

b) **boot system flash:packages.conf**

Use this command to set the boot variable to **flash:packages.conf**.

```
Switch(config)# boot system flash:packages.conf
```

c) **no boot manual**

Use this command to configure the switch to auto-boot.

```
Switch(config)# no boot manual
Switch(config)# exit
```

d) **write memory**

Use this command to save boot settings.

```
Switch# write memory
```

e) **show boot**

Use this command to verify the boot variable (packages.conf) and manual boot setting (no):

```
Switch# show boot
Current Boot Variables:
BOOT variable = flash:packages.conf;

Boot Variables on next reload:
BOOT variable = flash:packages.conf;
Manual Boot = no
Enable Break = yes
Boot Mode = DEVICE
iPXE Timeout = 0
```

Step 4 Install image to flash**install add file activate commit**

Use this command to install the image.

We recommend that you point to the source image on your TFTP server or the flash drive of the *active* switch, if you have copied the image to flash memory. If you point to an image on the flash or USB drive of a member switch (instead of the active), you must specify the exact flash or USB drive - otherwise installation fails. For example, if the image is on the flash drive of member switch 3 (flash-3): Switch# **install add file flash-3:cat9k_iosxe.17.11.01.SPA.bin activate commit.**

The following sample output displays installation of the Cisco IOS XE Dublin 17.11.1 software image in the flash memory:

```
Switch# install add file flash:cat9k_iosxe.17.11.01.SPA.bin activate commit
```

```
install_add_activate_commit: START Wed Mar 22 10:15:02 PDT 2023
install_add: START Wed Mar 22 10:15:02 PDT 2023
install_add: Adding IMG
--- Starting initial file syncing ---
Copying flash:cat9k_iosxe.17.11.01.SPA.bin from Switch 1 to Switch 1 2
Info: Finished copying to the selected Switch
Finished initial file syncing
```

```
--- Starting Add ---
Performing Add on all members
[1] Finished Add package(s) on Switch 1
[2] Finished Add package(s) on Switch 2
Checking status of Add on [1 2]
Add: Passed on [1 2]
Finished Add
```

```
Image added. Version: 17.11.01.0
```

```
Warning: ISSU compatibility check failed for 17.11.01.0
install_activate: START Wed Mar 22 10:17:34 PDT 2023
install_activate: Activating IMG
Following packages shall be activated:
/flash/cat9k-cc_srdriver.17.11.01.SPA.pkg
/flash/cat9k-espbases.17.11.01.SPA.pkg
/flash/cat9k-guestshell.17.11.01.SPA.pkg
/flash/cat9k-lni.17.11.01.SPA.pkg
/flash/cat9k-rpbases.17.11.01.SPA.pkg
/flash/cat9k-sipbase.17.11.01.SPA.pkg
/flash/cat9k-sipspace.17.11.01.SPA.pkg
/flash/cat9k-srdriver.17.11.01.SPA.pkg
/flash/cat9k-webui.17.11.01.SPA.pkg
/flash/cat9k-wlc.17.11.01.SPA.pkg
/flash/cat9k-rpboot.17.11.01.SPA.pkg
```

```
This operation may require a reload of the system. Do you want to proceed? [y/n]y
```

```
--- Starting Activate ---
Performing Activate on all members
[1] Activate package(s) on Switch 1
[2] Activate package(s) on Switch 2
[2] Finished Activate on Switch 2
[1] Finished Activate on Switch 1
Checking status of Activate on [1 2]
Activate: Passed on [1 2]
Finished Activate
```

```
--- Starting Commit ---
Performing Commit on all members
[1] Commit package(s) on Switch 1
[2] Commit package(s) on Switch 2
[1] Finished Commit on Switch 1
[2] Finished Commit on Switch 2
```

```

Checking status of Commit on [1 2]
Commit: Passed on [1 2]
Finished Commit operation

*Mar 22 10:22:00.934: %IOSXEBOOT-4-BOOTLOADER_UPGRADE: (rp/0): Starting boot preupgrade
*Mar 22 10:22:00.937: %IOSXEBOOT-4-BOOTLOADER_UPGRADE: (rp/0): ### Wed Mar 22 10:22:00 PDT
  2023 PLEASE DO NOT POWER CYCLE ### BOOT LOADER UPGRADING
*Mar 22 10:22:50.808: %IOSXEBOOT-4-flashcp: (rp/0): polaris_adelphi_rommon_sb.bin
*Mar 22 10:22:56.093: %IOSXEBOOT-4-BOOTLOADER_UPGRADE: (rp/0): boot loader upgrade successful

      SUCCESS: install_add_activate_commit Wed Mar 22 10:22:59 PDT 2023
stack-nyqcr3#
Chassis 1 reloading, reason - Reload command
Mar 22 10:23:05.604: %PMAN-5-EXITACTION: F0/0: pvp: Process manager is exiting: reload fp
action requested
Mar 22 10:23:07.295: %PMAN-5-EXITACTION: R0/0: pvp: Process manager is exiting: rp processes
  exit with reload switch code

Initializing Hardware.....

System Bootstrap, Version 17.11.1r[FC1], RELEASE SOFTWARE (P)
Compiled Wed 02/08/2023 14:36:07.63 by rel

Current ROMMON image : Primary
Last reset cause      : SoftwareReload
C9300-48UXM platform with 8388608 Kbytes of main memory

Preparing to autoboot. [Press Ctrl-C to interrupt] 0
boot: attempting to boot from [flash:packages.conf]
boot: reading file packages.conf
#####
#####

Waiting for 120 seconds for other switches to boot

Switch number is 1
All switches in the stack have been discovered. Accelerating discovery
<output truncated>

```

Note

The system reloads automatically after executing the **install add file activate commit** command. You do not have to manually reload the system.

Step 5 Verify installation

After the software has been successfully installed, use the **dir flash:** command to verify that the flash partition has ten new .pkg files and two .conf files.

a) **dir flash:*.pkg**

The following is sample output of the **dir flash:*.pkg** command:

```

Switch# dir flash:*.pkg

Directory of flash:/
75140 -rw- 2012104      Nov 14 2022 09:52:41 -07:00 cat9k-cc_srdriver.17.10.01.SPA.pkg
475141 -rw- 70333380     Nov 14 2022 09:52:44 -07:00 cat9k-espsbase.17.10.01.SPA.pkg
475142 -rw- 13256        Nov 14 2022 09:52:44 -07:00 cat9k-guestshell.17.10.01.SPA.pkg
475143 -rw- 349635524    Nov 14 2022 09:52:54 -07:00 cat9k-rpbase.17.10.01.SPA.pkg

```

```

475149 -rw- 24248187 Nov 14 2022 09:53:02 -07:00 cat9k-rpboot.17.10.01.SPA.pkg
475144 -rw- 25285572 Nov 14 2022 09:52:55 -07:00 cat9k-sipbase.17.10.01.SPA.pkg
475145 -rw- 20947908 Nov 14 2022 09:52:55 -07:00 cat9k-sipspa.17.10.01.SPA.pkg
475146 -rw- 2962372 Nov 14 2022 09:52:56 -07:00 cat9k-srdriver.17.10.01.SPA.pkg
475147 -rw- 13284288 Nov 14 2022 09:52:56 -07:00 cat9k-webui.17.10.01.SPA.pkg
475148 -rw- 13248 Nov 14 2022 09:52:56 -07:00 cat9k-wlc.17.10.01.SPA.pkg

491524 -rw- 25711568 Mar 27 2023 11:49:33 -07:00 cat9k-cc_srdriver.17.11.01.SPA.pkg
491525 -rw- 78484428 Mar 27 2023 11:49:35 -07:00 cat9k-espbases.17.11.01.SPA.pkg
491526 -rw- 1598412 Mar 27 2023 11:49:35 -07:00 cat9k-guestshell.17.11.01.SPA.pkg
491527 -rw- 404153288 Mar 27 2023 11:49:47 -07:00 cat9k-rpbase.17.11.01.SPA.pkg
491533 -rw- 31657374 Mar 27 2023 11:50:09 -07:00 cat9k-rpboot.17.11.01.SPA.pkg
491528 -rw- 27681740 Mar 27 2023 11:49:48 -07:00 cat9k-sipbase.17.11.01.SPA.pkg
491529 -rw- 52224968 Mar 27 2023 11:49:49 -07:00 cat9k-sipspa.17.11.01.SPA.pkg
491530 -rw- 31130572 Mar 27 2023 11:49:50 -07:00 cat9k-srdriver.17.11.01.SPA.pkg
491531 -rw- 14783432 Mar 27 2023 11:49:51 -07:00 cat9k-webui.17.11.01.SPA.pkg
491532 -rw- 9160 Mar 27 2023 11:49:51 -07:00 cat9k-wlc.17.11.01.SPA.pkg

```

```

11353194496 bytes total (9544245248 bytes free)
Switch#

```

b) **dir flash:*.conf**

The following is sample output of the **dir flash:*.conf** command. It displays the .conf files in the flash partition; note the two .conf files:

- **packages.conf**—the file that has been re-written with the newly installed .pkg files
- **cat9k_iosxe.17.11.01.SPA.conf**— a backup copy of the newly installed packages.conf file

```

Switch# dir flash:*.conf

Directory of flash:/*.conf
Directory of flash:/

434197 -rw- 7406 Mar 27 2023 10:59:16 -07:00 packages.conf
516098 -rw- 7406 Mar 27 2023 10:58:08 -07:00 cat9k_iosxe.17.11.01.SPA.conf
11353194496 bytes total (8963174400 bytes free)

```

Step 6 **show version**

After the image boots up, use this command to verify the version of the new image.

The following sample output of the **show version** command displays the Cisco IOS XE Dublin 17.11.1 image on the device:

```

Switch# show version

Cisco IOS XE Software, Version 17.11.01
Cisco IOS Software [Dublin], Catalyst L3 Switch Software (CAT9K_IOSXE), Version 17.11.1,
RELEASE SOFTWARE (fcl)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2023 by Cisco Systems, Inc.
<output truncated>

```

Downgrading in Install Mode

Follow these instructions to downgrade from one release to another, in install mode. To perform a software image downgrade, you must be booted into IOS through **boot flash:packages.conf**.

Before you begin

Note that you can use this procedure for the following downgrade scenarios:

When downgrading from ...	Use these commands...	To downgrade to...
Cisco IOS XE Dublin 17.11.x	Either install commands or request platform software command ⁵ .	Cisco IOS XE Dublin 17.10.x or earlier releases.

⁵ The **request platform software** commands are deprecated. So although they are still visible on the CLI, we recommend that you use **install** commands.



Note New switch models that are introduced in a release cannot be downgraded. The release in which a switch model is introduced is the minimum software version for that model.

The sample output in this section shows downgrade from Cisco IOS XE Dublin 17.11.1 to Cisco IOS XE Dublin 17.10.1, using **install** commands.

Microcode Downgrade Prerequisite:

Starting from Cisco IOS XE Gibraltar 16.12.1, a new microcode is introduced to support IEEE 802.3bt Type 3 standard for UPOE switches in the series (C9300-24U, C9300-48U, C9300-24UX, C9300-48UXM, C9300-48UN). The new microcode is not backward-compatible with some releases, because of which you must also downgrade the microcode when you downgrade to one of these releases. If the microcode is not downgraded, PoE features will be impacted after the downgrade.

Depending on the *release* you are downgrading to and the *commands* you use to downgrade, review the table below for the action you may have to take:

When downgrading from ...	To one of These Releases	by Using...	Action For Microcode Downgrade
Cisco IOS XE Gibraltar 16.12.1 or a later release	Cisco IOS XE Everest 16.6.1 through Cisco IOS XE Everest 16.6.6	install commands	Microcode will roll back automatically as part of the software installation. No further action is required.
	Cisco IOS XE Fuji 16.9.1 through Cisco IOS XE Fuji 16.9.2	request platform software commands or or bundle boot	Manually downgrade the microcode before downgrading the software image. Enter the hw-module mcu rollback command in global configuration mode, to downgrade microcode.

Procedure

Step 1 Clean-up

install remove inactive

Use this command to clean-up old installation files in case of insufficient space and to ensure that you have at least 1GB of space in flash, to expand a new image.

The following sample output displays the cleaning up of unused files, by using the **install remove inactive** command:

```
Switch# install remove inactive

install_remove: START Wed Mar 22 10:34:24 PDT 2023
install_remove: Removing IMG
Cleaning up unnecessary package files
No path specified, will use booted path /flash/packages.conf

Cleaning /flash
Scanning boot directory for packages ... done.
Preparing packages list to delete ...
[R0]: /flash/packages.conf File is in use, will not delete.
[R1]: /flash/packages.conf File is in use, will not delete.
[R0]: /flash/cat9k-cc_srdriver.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-cc_srdriver.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-espbases.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-espbases.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-guestshell.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-guestshell.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-lni.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-lni.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-rpbases.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-rpbases.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-sipbase.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-sipbase.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-sipspace.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-sipspace.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-srdriver.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-srdriver.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-webui.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-webui.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k-wlc.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-wlc.17.11.01.SPA.pkg File is in use, will not delete.
[R0]: /flash/cat9k_iosxe.17.11.01.SPA.conf File is in use, will not delete.
[R1]: /flash/cat9k_iosxe.17.11.01.SPA.conf File is in use, will not delete.
[R0]: /flash/cat9k-rpboot.17.11.01.SPA.pkg File is in use, will not delete.
[R1]: /flash/cat9k-rpboot.17.11.01.SPA.pkg File is in use, will not delete.
```

The following files will be deleted:

```
[R0]: /flash/cat9k_iosxe.17.11.01.SPA.bin
[R1]: /flash/cat9k_iosxe.17.11.01.SPA.bin
[R0]: /flash/cat9k-cc_srdriver.17.09.02.SPA.pkg
[R1]: /flash/cat9k-cc_srdriver.17.09.02.SPA.pkg
[R0]: /flash/cat9k-espbases.17.09.02.SPA.pkg
[R1]: /flash/cat9k-espbases.17.09.02.SPA.pkg
[R0]: /flash/cat9k-guestshell.17.09.02.SPA.pkg
[R1]: /flash/cat9k-guestshell.17.09.02.SPA.pkg
[R0]: /flash/cat9k-lni.17.09.02.SPA.pkg
[R1]: /flash/cat9k-lni.17.09.02.SPA.pkg
[R0]: /flash/cat9k-rpbases.17.09.02.SPA.pkg
```

```
[R1]: /flash/cat9k-rpbase.17.09.02.SPA.pkg
[R0]: /flash/cat9k-sipbase.17.09.02.SPA.pkg
[R1]: /flash/cat9k-sipbase.17.09.02.SPA.pkg
[R0]: /flash/cat9k-sipspace.17.09.02.SPA.pkg
[R1]: /flash/cat9k-sipspace.17.09.02.SPA.pkg
[R0]: /flash/cat9k-srdriver.17.09.02.SPA.pkg
[R1]: /flash/cat9k-srdriver.17.09.02.SPA.pkg
[R0]: /flash/cat9k-webui.17.09.02.SPA.pkg
[R1]: /flash/cat9k-webui.17.09.02.SPA.pkg
[R0]: /flash/cat9k-wlc.17.09.02.SPA.pkg
[R1]: /flash/cat9k-wlc.17.09.02.SPA.pkg
[R0]: /flash/cat9k_iosxe.17.09.02.SPA.conf
[R1]: /flash/cat9k_iosxe.17.09.02.SPA.conf
[R0]: /flash/cat9k-rpboot.17.09.02.SPA.pkg
[R1]: /flash/cat9k-rpboot.17.09.02.SPA.pkg
```

Do you want to remove the above files? [y/n]y

```
Deleting file /flash/cat9k_iosxe.17.11.01.SPA.bin ... done.
Deleting file /flash/cat9k-cc_srdriver.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-espbases.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-guestshell.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-lni.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-rpbase.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-sipbase.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-sipspace.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-srdriver.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-webui.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k-wlc.17.09.02.SPA.pkg ... done.
Deleting file /flash/cat9k_iosxe.17.09.02.SPA.conf ... done.
Deleting file /flash/cat9k-rpboot.17.09.02.SPA.pkg ... done.
Deleting /flash/.images/17.12.01.0.172764.1674613814 ... done.
SUCCESS: Files deleted.
```

```
--- Starting Post_Remove_Cleanup ---
Performing REMOVE_POSTCHECK on all members
Finished Post_Remove_Cleanup
SUCCESS: install_remove Wed Mar 22 10:34:32 PDT 2023
```

Step 2 Copy new image to flash

a) copy tftp:[[/location]/directory]/filenameflash:

Use this command to copy the new image from a TFTP server to flash memory. The location is either an IP address or a host name. The filename is specified relative to the directory used for file transfers. Skip this step if you want to use the new image from a TFTP server.

```
Switch# copy tftp://10.8.0.6/image/cat9k_iosxe.17.10.01.SPA.bin flash:
Destination filename [cat9k_iosxe.17.10.01.SPA.bin]?
Accessing tftp://10.8.0.6/cat9k_iosxe.17.10.01.SPA.bin...
Loading /cat9k_iosxe.17.10.01.SPA.bin from 10.8.0.6 (via GigabitEthernet0/0):
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
[OK - 508584771 bytes]
508584771 bytes copied in 101.005 secs (5035244 bytes/sec)
```

b) dir flash:

Use this command to confirm that the image has been successfully copied to flash.

```
Switch# dir flash:*.bin

Directory of flash:/*.bin

Directory of flash:/
```

```
434184 -rw- 508584771 Mar 13 2023 13:35:16 -07:00 cat9k_iosxe.17.10.01.SPA.bin
11353194496 bytes total (9055866880 bytes free)
```

Step 3 Set boot variable

a) **boot system flash:packages.conf**

Use this command to set the boot variable to **flash:packages.conf**.

```
Switch(config)# boot system flash:packages.conf
```

b) **no boot manual**

Use this command to configure the switch to auto-boot.

```
Switch(config)# no boot manual
Switch(config)# exit
```

c) **write memory**

Use this command to save boot settings.

```
Switch# write memory
```

d) **show boot**

Use this command to verify the boot variable (packages.conf) and manual boot setting (no):

```
Switch# show boot

Current Boot Variables:
BOOT variable = flash:packages.conf;

Boot Variables on next reload:
BOOT variable = flash:packages.conf;
Manual Boot = no
Enable Break = yes
Boot Mode = DEVICE
iPXE Timeout = 0
```

Step 4 Downgrade software image

install add file activate commit

Use this command to install the image.

We recommend that you point to the source image on your TFTP server or the flash drive of the *active* switch, if you have copied the image to flash memory. If you point to an image on the flash or USB drive of a member switch (instead of the active), you must specify the exact flash or USB drive - otherwise installation fails. For example, if the image is on the flash drive of member switch 3 (flash-3): Switch# **install add file flash-3:cat9k_iosxe.17.10.01.SPA.bin activate commit**.

The following example displays the installation of the Cisco IOS XE Dublin 17.10.1 software image to flash, by using the **install add file activate commit** command.

```
Switch# install add file flash:cat9k_iosxe.17.10.01.SPA.bin activate commit

install_add_activate_commit: START Wed Mar 22 10:55:53 PDT 2023
install_add: START Wed Mar 22 10:55:53 PDT 2023
install_add: Adding IMG
  [2] Switch 2 Warning!!! Image is being downgraded from 17.11.01.0.1186 to 17.10.01.0.1444.
--- Starting initial file syncing ---
Copying flash:cat9k_iosxe.17.10.01.SPA.bin from Switch 1 to Switch 1 2
```

```
Info: Finished copying to the selected Switch
Finished initial file syncing
```

```
--- Starting Add ---
Performing Add on all members
Checking status of Add on [1 2]
Add: Passed on [1 2]
Image added. Version: 17.10.01.0.1444
```

```
Finished Add
```

```
install_activate: START Wed Mar 22 10:57:32 PDT 2023
install_activate: Activating IMG
Following packages shall be activated:
/flash/cat9k-cc_srdriver.17.10.01.SPA.pkg
/flash/cat9k-espbases.17.10.01.SPA.pkg
/flash/cat9k-guestshell.17.10.01.SPA.pkg
/flash/cat9k-lni.17.10.01.SPA.pkg
/flash/cat9k-rpbases.17.10.01.SPA.pkg
/flash/cat9k-sipbases.17.10.01.SPA.pkg
/flash/cat9k-sipspa.17.10.01.SPA.pkg
/flash/cat9k-srdriver.17.10.01.SPA.pkg
/flash/cat9k-webui.17.10.01.SPA.pkg
/flash/cat9k-wlc.17.10.01.SPA.pkg
/flash/cat9k-rpboot.17.10.01.SPA.pkg
```

```
This operation may require a reload of the system. Do you want to proceed? [y/n]y
```

```
--- Starting Activate ---
Performing Activate on all members
[1] Activate package(s) on Switch 1
[2] Activate package(s) on Switch 2
[2] Finished Activate on Switch 2
[1] Finished Activate on Switch 1
Checking status of Activate on [1 2]
Activate: Passed on [1 2]
Finished Activate
```

```
--- Starting Commit ---
Performing Commit on all members
[1] Commit package(s) on Switch 1
[2] Commit package(s) on Switch 2
[2] Finished Commit on Switch 2
[1] Finished Commit on Switch 1
Checking status of Commit on [1 2]
Commit: Passed on [1 2]
Finished Commit operation
```

```
SUCCESS: install_add_activate_commit Wed Mar 22 11:00:19 PDT 2023
stack-nyqcr3#
Chassis 1 reloading, reason - Reload command
Mar 22 11:00:25.253: %PMAN-5-EXITACTION: F0/0: pvp: Process manager is exiting: reload fp
action requested
Mar 22 11:00:26.878: %PMAN-5-EXITACTION: R0/0: pvp: Process manager is exiting: rp processes
exit with reload switch code
```

```
Initializing Hardware.....
```

```
System Bootstrap, Version 17.11.1r[FC1], RELEASE SOFTWARE (P)
Compiled Wed 02/08/2023 14:36:07.63 by rel
```

```
Current ROMMON image : Primary
```

```
Last reset cause      : SoftwareReload
C9300-48UXM platform with 8388608 Kbytes of main memory
```

```
Preparing to autoboot. [Press Ctrl-C to interrupt]  0
boot: attempting to boot from [flash:packages.conf]
boot: reading file packages.conf
#
```

```
#####
#####
#####
```

```
Waiting for 120 seconds for other switches to boot
```

```
Switch number is 1
All switches in the stack have been discovered. Accelerating discovery
```

Note

The system reloads automatically after executing the **install add file activate commit** command. You do not have to manually reload the system.

Step 5 Verify version

show version

After the image boots up, use this command to verify the version of the new image.

Note

When you downgrade the software image, the ROMMON version does not downgrade. It remains updated.

The following sample output of the **show version** command displays the Cisco IOS XE Dublin 17.10.1 image on the device:

```
Switch# show version

Cisco IOS XE Software, Version 17.10.01
Cisco IOS Software [Dublin], Catalyst L3 Switch Software (CAT9K_IOSXE), Version 17.10.1,
RELEASE SOFTWARE (fcl)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2023 by Cisco Systems, Inc.
<output truncated>
```

Field-Programmable Gate Array Version Upgrade

A field-programmable gate array (FPGA) is a type of programmable memory device that exists on Cisco switches. They are re-configurable logic circuits that enable the creation of specific and dedicated functions.

To check the current FPGA version, enter the **version -v** command in ROMMON mode.



Note

- Not every software release has a change in the FPGA version.
- The version change occurs as part of the regular software upgrade and you do not have to perform any other additional steps.



CHAPTER 9

Caveats

- [Cisco Bug Search Tool](#), on page 43
- [Open Caveats in Cisco IOS XE Dublin 17.11.x](#), on page 43
- [Resolved Caveats in Cisco IOS XE Dublin 17.11.99SW](#), on page 43
- [Resolved Caveats in Cisco IOS XE Dublin 17.11.1](#), on page 43

Cisco Bug Search Tool

The Cisco [Bug Search Tool](#) (BST) allows partners and customers to search for software bugs based on product, release, and keyword, and aggregates key data such as bug details, product, and version. The BST is designed to improve the effectiveness in network risk management and device troubleshooting. The tool has a provision to filter bugs based on credentials to provide external and internal bug views for the search input.

To view the details of a caveat, click on the identifier.

Open Caveats in Cisco IOS XE Dublin 17.11.x

There are no open caveats in this release.

Resolved Caveats in Cisco IOS XE Dublin 17.11.99SW

There are no resolved caveats in this release.

Resolved Caveats in Cisco IOS XE Dublin 17.11.1

Identifier	Applicable Models	Headline
CSCwc87761	9300	C9300L PWR-C1-350WAC-P power supply may turn off requiring power cable OIR



CHAPTER 10

Additional Information

- [Troubleshooting](#), on page 45
- [Related Documentation](#), on page 45
- [Communications, Services, and Additional Information](#), on page 45

Troubleshooting

For the most up-to-date, detailed troubleshooting information, see the Cisco TAC website at this URL:

<https://www.cisco.com/en/US/support/index.html>

Go to **Product Support** and select your product from the list or enter the name of your product. Look under Troubleshoot and Alerts, to find information for the problem that you are experiencing.

Related Documentation

Information about Cisco IOS XE at this URL: <https://www.cisco.com/c/en/us/products/ios-nx-os-software/ios-xe/index.html>

All support documentation for Cisco Catalyst 9300 Series Switches is at this URL: <https://www.cisco.com/c/en/us/support/switches/catalyst-9300-series-switches/tsd-products-support-series-home.html>

Cisco Validated Designs documents at this URL: <https://www.cisco.com/go/designzone>

To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: <https://cfnng.cisco.com/mibs>

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business results you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco DevNet](#).

- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2023 Cisco Systems, Inc. All rights reserved.

