



Configuring Virtual Private LAN Service (VPLS) and VPLS BGP-Based Autodiscovery

- [Finding Feature Information, on page 1](#)
- [Configuring VPLS, on page 1](#)
- [Configuring VPLS BGP-based Autodiscovery, on page 15](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

Configuring VPLS


Information About VPLS

VPLS Overview

VPLS (Virtual Private LAN Service) enables enterprises to link together their Ethernet-based LANs from multiple sites via the infrastructure provided by their service provider. From the enterprise perspective, the service provider's public network looks like one giant Ethernet LAN. For the service provider, VPLS provides an opportunity to deploy another revenue-generating service on top of their existing network without major capital expenditures. Operators can extend the operational life of equipment in their network.

Virtual Private LAN Services (VPLS) uses the provider core to join multiple attachment circuits together to simulate a virtual bridge that connects the multiple attachment circuits together. From a customer point of view, there is no topology for VPLS. All of the CE devices appear to connect to a logical bridge emulated by the provider core.

Figure 1: VPLS Topology



Full-Mesh Configuration

The full-mesh configuration requires a full mesh of tunnel label switched paths (LSPs) between all the PEs that participate in the VPLS. With full-mesh, signaling overhead and packet replication requirements for each provisioned VC on a PE can be high.

You set up a VPLS by first creating a virtual forwarding instance (VFI) on each participating PE router. The VFI specifies the VPN ID of a VPLS domain, the addresses of other PE devices in the domain, and the type of tunnel signaling and encapsulation mechanism for each peer PE router.

The set of VFIs formed by the interconnection of the emulated VCs is called a VPLS instance; it is the VPLS instance that forms the logic bridge over a packet switched network. The VPLS instance is assigned a unique VPN ID.

The PE devices use the VFI to establish a full-mesh LSP of emulated VCs to all the other PE devices in the VPLS instance. PE devices obtain the membership of a VPLS instance through static configuration using the Cisco IOS CLI.

The full-mesh configuration allows the PE router to maintain a single broadcast domain. Thus, when the PE router receives a broadcast, multicast, or unknown unicast packet on an attachment circuit, it sends the packet out on all other attachment circuits and emulated circuits to all other CE devices participating in that VPLS instance. The CE devices see the VPLS instance as an emulated LAN.

To avoid the problem of a packet looping in the provider core, the PE devices enforce a "split-horizon" principle for the emulated VCs. That means if a packet is received on an emulated VC, it is not forwarded on any other emulated VC.

After the VFI has been defined, it needs to be bound to an attachment circuit to the CE device.

The packet forwarding decision is made by looking up the Layer 2 virtual forwarding instance (VFI) of a particular VPLS domain.

A VPLS instance on a particular PE router receives Ethernet frames that enter on specific physical or logical ports and populates a MAC table similarly to how an Ethernet switch works. The PE router can use the MAC address to switch those frames into the appropriate LSP for delivery to the another PE router at a remote site.

If the MAC address is not in the MAC address table, the PE router replicates the Ethernet frame and floods it to all logical ports associated with that VPLS instance, except the ingress port where it just entered. The PE router updates the MAC table as it receives packets on specific ports and removes addresses not used for specific periods.

VPLS BGP Based Autodiscovery

VPLS Autodiscovery enables each Virtual Private LAN Service (VPLS) provider edge (PE) device to discover other PE devices that are part of the same VPLS domain. VPLS Autodiscovery also tracks PE devices when they are added to or removed from a VPLS domain. As a result, with VPLS Autodiscovery enabled, you no longer need to manually configure a VPLS domain and maintain the configuration when a PE device is added or deleted. VPLS Autodiscovery uses the Border Gateway Protocol (BGP) to discover VPLS members and set up and tear down pseudowires in a VPLS domain.


BGP uses the Layer 2 VPN (L2VPN) Routing Information Base (RIB) to store endpoint provisioning information, which is updated each time any Layer 2 virtual forwarding instance (VFI) is configured. The prefix and path information is stored in the L2VPN database, which allows BGP to make decisions about the best path. When BGP distributes the endpoint provisioning information in an update message to all its BGP neighbors, this endpoint information is used to configure a pseudowire mesh to support L2VPN-based services.

The BGP autodiscovery mechanism facilitates the configuration of L2VPN services, which are an integral part of the VPLS feature. VPLS enables flexibility in deploying services by connecting geographically dispersed sites as a large LAN over high-speed Ethernet in a robust and scalable IP Multiprotocol Label Switching (MPLS) network.

For scale information related to this feature, see [Cisco Catalyst 9500 Series Switches Data Sheet](#).

Configuration Examples for VPLS

Figure 2: VPLS Topology



| PE1 Configuration | PE2 Configuration |
|---|---|
| <pre>pseudowire-class vpls2129 encapsulation mpls ! l2 vfi 2129 manual vpn id 2129 neighbor 44.254.44.44 pw-class vpls2129 ! neighbor 188.98.89.98 pw-class vpls2129 ! interface TenGigabitEthernet1/0/24 switchport trunk allowed vlan 2129 switchport mode trunk ! interface Vlan2129 no ip address xconnect vfi 2129 !</pre> | <pre>pseudowire-class vpls2129 encapsulation mpls no control-word ! l2 vfi 2129 manual vpn id 2129 neighbor 1.1.1.72 pw-class vpls2129 neighbor 188.98.89.98 pw-class vpls2129 ! interface TenGigabitEthernet1/0/47 switchport trunk allowed vlan 2129 switchport mode trunk end ! interface Vlan2129 no ip address xconnect vfi 2129 !</pre> |

The **show mpls 12transport vc detail** command provides information the virtual circuits.

```
Local interface: VFI 2129 vfi up
 Interworking type is Ethernet
 Destination address: 44.254.44.44, VC ID: 2129, VC status: up
 Output interface: Gil/0/9, imposed label stack {18 17}
 Preferred path: not configured
 Default path: active
 Next hop: 177.77.177.2
 Create time: 19:09:33, last status change time: 09:24:14
 Last label FSM state change time: 09:24:14
 Signaling protocol: LDP, peer 44.254.44.44:0 up
 Targeted Hello: 1.1.1.72(LDP Id) -> 44.254.44.44, LDP is UP
 Graceful restart: configured and enabled
 Non stop routing: not configured and not enabled
 Status TLV support (local/remote) : enabled/supported
 LDP route watch : enabled
 Label/status state machine : established, LruRru
 Last local dataplane status rcvd: No fault
 Last BFD dataplane status rcvd: Not sent
 Last BFD peer monitor status rcvd: No fault
 Last local AC circuit status rcvd: No fault
 Last local AC circuit status sent: No fault
 Last local PW i/f circ status rcvd: No fault
 Last local LDP TLV status sent: No fault
 Last remote LDP TLV status rcvd: No fault
 Last remote LDP ADJ status rcvd: No fault
 MPLS VC labels: local 512, remote 17
 Group ID: local n/a, remote 0
 MTU: local 1500, remote 1500
 Remote interface description:
 Sequencing: receive disabled, send disabled
 Control Word: Off
```

```
SSO Descriptor: 44.254.44.44/2129, local label: 512
Dataplane:
  SSM segment/switch IDs: 20498/20492 (used), PWID: 2
VC statistics:
  transit packet totals: receive 0, send 0
  transit byte totals:   receive 0, send 0
  transit packet drops: receive 0, seq error 0, send 0
```

The **show l2vpn atom vc** shows that ATM over MPLS is configured on a VC.

```
pseudowire100005 is up, VC status is up PW type: Ethernet
  Create time: 19:25:56, last status change time: 09:40:37
  Last label FSM state change time: 09:40:37
  Destination address: 44.254.44.44 VC ID: 2129
  Output interface: Gi1/0/9, imposed label stack {18 17}
  Preferred path: not configured
  Default path: active
  Next hop: 177.77.177.2
Member of vfi service 2129
  Bridge-Domain id: 2129
  Service id: 0x32000003
Signaling protocol: LDP, peer 44.254.44.44:0 up
  Targeted Hello: 1.1.1.72 (LDP Id) -> 44.254.44.44, LDP is UP
  Graceful restart: configured and enabled
  Non stop routing: not configured and not enabled
  PWid FEC (128), VC ID: 2129
  Status TLV support (local/remote)      : enabled/supported
  LDP route watch                        : enabled
  Label/status state machine             : established, LruRru
  Local dataplane status received        : No fault
  BFD dataplane status received          : Not sent
  BFD peer monitor status received       : No fault
  Status received from access circuit    : No fault
  Status sent to access circuit          : No fault
  Status received from pseudowire i/f    : No fault
  Status sent to network peer            : No fault
  Status received from network peer      : No fault
  Adjacency status of remote peer        : No fault
  Sequencing: receive disabled, send disabled
  Bindings
  Parameter      Local      Remote
  -----
  Label          512          17
  Group ID       n/a          0
  Interface
  MTU            1500         1500
  Control word   off           off
  PW type        Ethernet    Ethernet
  VCCV CV type   0x02         0x02
```

```

                                LSPV [2]                                LSPV [2]
VCCV CC type 0x06                                0x06
                                RA [2], TTL [3]                        RA [2], TTL [3]
Status TLV    enabled                            supported
SSO Descriptor: 44.254.44.44/2129, local label: 512
Dataplane:
  SSM segment/switch IDs: 20498/20492 (used), PWID: 2
Rx Counters
  0 input transit packets, 0 bytes
  0 drops, 0 seq err
Tx Counters
  0 output transit packets, 0 bytes
  0 drops

```

Restrictions for VPLS

- Protocol-based CLI Method (interface pseudowire configuration) is not supported. Only VFI and Xconnect mode are supported.
- Flow-Aware Transport Pseudowire (FAT PW) is not supported.
- IGMP Snooping is not Supported. Multicast traffic floods with IGMP Snooping disabled.
- L2 Protocol Tunneling is not supported.
- Integrated Routing and Bridging (IRB) not supported.
- Virtual Circuit Connectivity Verification (VCCV) ping with explicit null is not supported.
- The switch is supported only as spoke in H-VPLS but not as hub.
- L2 VPN Interworking is not supported.
- **ip unnumbered** command is not supported in MPLS configuration.
- VC statistics are not displayed for flood traffic in the output of show mpls l2 vc vcid detail command.
- dot1q tunnel is not supported in the attachment circuit.

Configuring PE Layer 2 Interfaces to CEs

Configuring 802.1Q Trunks for Tagged Traffic from a CE

Procedure

| | Command or Action | Purpose |
|---------------|---|--|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. Enter your password if prompted. |

| | Command or Action | Purpose |
|---------------|--|---|
| Step 2 | configure terminal Example: Device# <code>configure terminal</code> | Enters the global configuration mode. |
| Step 3 | interface <i>interface-id</i> Example: Device(config)# <code>interface</code> <code>TenGigabitEthernet1/0/24</code> | Defines the interface to be configured as a trunk, and enters interface configuration mode. |
| Step 4 | no ip address <i>ip_address mask</i> [secondary] Example: Device(config-if)# <code>no ip address</code> | Disables IP processing and enters interface configuration mode. |
| Step 5 | switchport Example: Device(config-if)# <code>switchport</code> | Modifies the switching characteristics of the Layer 2-switched interface. |
| Step 6 | switchport trunk encapsulation dot1q Example: Device(config-if)# <code>switchport trunk encapsulation dot1q</code> | Sets the switch port encapsulation format to 802.1Q. |
| Step 7 | switchport trunk allow vlan <i>vlan_ID</i> Example: Device(config-if)# <code>switchport trunk allow</code> <code>vlan 2129</code> | Sets the list of allowed VLANs. |
| Step 8 | switchport mode trunk Example: Device(config-if)# <code>switchport mode trunk</code> | Sets the interface to a trunking VLAN Layer 2 interface. |
| Step 9 | end Example: Device(config)# <code>end</code> | Returns to privileged EXEC mode. |

Configuring 802.1Q Access Ports for Untagged Traffic from a CE

Procedure

| | Command or Action | Purpose |
|---------------|--|---|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters the global configuration mode. |
| Step 3 | interface <i>interface-id</i> Example: Device(config)# interface TenGigabitEthernet1/0/24 | Defines the interface to be configured as a trunk, and enters interface configuration mode. |
| Step 4 | no ip address <i>ip_address mask</i> [secondary] Example: Device(config-if)# no ip address | Disables IP processing and enters interface configuration mode. |
| Step 5 | switchport Example: Device(config-if)# switchport | Modifies the switching characteristics of the Layer 2-switched interface. |
| Step 6 | switchport mode access Example: Device(config-if)# switchport mode access | Sets the interface type to nontrunking, nontagged single VLAN Layer 2 interface. |
| Step 7 | switchport access vlan <i>vlan_ID</i> Example: Device(config-if)# switchport access vlan 2129 | Sets the VLAN when the interface is in access mode. |
| Step 8 | end Example: | Returns to privileged EXEC mode. |

| | Command or Action | Purpose |
|--|----------------------------|---------|
| | Device(config)# end | |

Configuring Layer 2 VLAN Instances on a PE

Configuring the Layer 2 VLAN interface on the PE enables the Layer 2 VLAN instance on the PE router to the VLAN database to set up the mapping between the VPLS and VLANs.

Procedure

| | Command or Action | Purpose |
|---------------|--|--|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters the global configuration mode. |
| Step 3 | vlan <i>vlan-id</i> Example: Device(config)# vlan 2129 | Configures a specific virtual LAN (VLAN). |
| Step 4 | interface vlan <i>vlan-id</i> Example: Device(config-vlan)# interface vlan 2129 | Configures an interface on the VLAN. |
| Step 5 | end Example: Device(config)# end | Returns to privileged EXEC mode. |

Configuring MPLS in the PE

To configure MPLS in the PE, you must provide the required MPLS parameters.

Procedure

| | Command or Action | Purpose |
|---------------|---|---|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters the global configuration mode. |
| Step 3 | mpls ip Example: Device(config)# mpls ip | Configures MPLS hop-by-hop forwarding. |
| Step 4 | mpls label protocol ldp Example: Device(config-vlan)# mpls label protocol ldp | Specifies the default Label Distribution Protocol for a platform. |
| Step 5 | end Example: Device(config)# end | Returns to privileged EXEC mode. |
| Step 6 | mpls ldp logging neighbor-changes Example: Device(config)# mpls ldp logging neighbor-changes | (Optional) Determines logging neighbor changes. |

Configuring VFI in the PE

The virtual switch instance (VFI) specifies the VPN ID of a VPLS domain, the addresses of other PE devices in this domain, and the type of tunnel signaling and encapsulation mechanism for each peer (This is where you create the VFI and associated VCs.). Configure a VFI as follows:

Procedure

| | Command or Action | Purpose |
|---------------|--|---|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters the global configuration mode. |
| Step 3 | l2 vfi vfi-name manual Example: Device(config)# l2 vfi 2129 manual | Enables the Layer 2 VFI manual configuration mode. |
| Step 4 | vpn id vpn-id Example: Device(config-vfi)# vpn id 2129 | Configures a VPN ID for a VPLS domain. The emulated VCs bound to this Layer 2 VRF use this VPN ID for signaling. Note <i>vpn-id</i> is the same as <i>vlan-id</i> . |
| Step 5 | neighbor router-id {encapsulation mpls} Example: Device(config-vfi)# neighbor remote-router-id encapsulation mpls | Specifies the remote peering router ID and the tunnel encapsulation type or the pseudo-wire property to be used to set up the emulated VC. |
| Step 6 | end Example: Device(config)# end | Returns to privileged EXEC mode. |

Associating the Attachment Circuit with the VFI at the PE

After defining the VFI, you must bind it to one or more attachment circuits.


Procedure

| | Command or Action | Purpose |
|---------------|----------------------------------|--|
| Step 1 | enable Example: | Enables privileged EXEC mode. Enter your password if prompted. |

| | Command or Action | Purpose |
|---------------|---|--|
| | Device> enable | |
| Step 2 | configure terminal Example: Device# configure terminal | Enters the global configuration mode. |
| Step 3 | interface vlan <i>vlan-id</i> Example: Device(config)# interface vlan 2129 | Creates or accesses a dynamic switched virtual interface (SVI). Note <i>vlan-id</i> is the same as <i>vpn-id</i> . |
| Step 4 | no ip address Example: Device(config-if)# no ip address | Disables IP processing. (You configure a Layer 3 interface for the VLAN if you configure an IP address.) |
| Step 5 | xconnect vfi <i>vfi-name</i> Example: Device(config-if)# xconnect vfi 2129 | Specifies the Layer 2 VFI that you are binding to the VLAN port. |
| Step 6 | end Example: Device(config)# end | Returns to privileged EXEC mode. |

Configuration Examples for VPLS

Figure 3: VPLS Topology



365165

| PE1 Configuration | PE2 Configuration |
|--|---|
| <pre>pseudowire-class vpls2129 encapsulation mpls ! 12 vfi 2129 manual vpn id 2129 neighbor 44.254.44.44 pw-class vpls2129 ! neighbor 188.98.89.98 pw-class vpls2129 ! interface TenGigabitEthernet1/0/24 switchport trunk allowed vlan 2129 switchport mode trunk ! interface Vlan2129 no ip address xconnect vfi 2129 !</pre> | <pre>pseudowire-class vpls2129 encapsulation mpls no control-word ! 12 vfi 2129 manual vpn id 2129 neighbor 1.1.1.72 pw-class vpls2129 neighbor 188.98.89.98 pw-class vpls2129 ! interface TenGigabitEthernet1/0/47 switchport trunk allowed vlan 2129 switchport mode trunk end ! interface Vlan2129 no ip address xconnect vfi 2129 !</pre> |

The **show mpls 12transport vc detail** command provides information the virtual circuits.

```
Local interface: VFI 2129 vfi up
  Interworking type is Ethernet
  Destination address: 44.254.44.44, VC ID: 2129, VC status: up
  Output interface: Gi1/0/9, imposed label stack {18 17}
  Preferred path: not configured
  Default path: active
  Next hop: 177.77.177.2
  Create time: 19:09:33, last status change time: 09:24:14
  Last label FSM state change time: 09:24:14
  Signaling protocol: LDP, peer 44.254.44.44:0 up
  Targeted Hello: 1.1.1.72 (LDP Id) -> 44.254.44.44, LDP is UP
  Graceful restart: configured and enabled
  Non stop routing: not configured and not enabled
  Status TLV support (local/remote)   : enabled/supported
  LDP route watch                      : enabled
  Label/status state machine          : established, LruRru
  Last local dataplane status rcvd: No fault
Last BFD dataplane status rcvd: Not sent
  Last BFD peer monitor status rcvd: No fault
  Last local AC circuit status rcvd: No fault
  Last local AC circuit status sent: No fault
  Last local PW i/f circ status rcvd: No fault
  Last local LDP TLV status sent: No fault
  Last remote LDP TLV status rcvd: No fault
  Last remote LDP ADJ status rcvd: No fault
MPLS VC labels: local 512, remote 17
  Group ID: local n/a, remote 0
  MTU: local 1500, remote 1500
  Remote interface description:
  Sequencing: receive disabled, send disabled
  Control Word: Off
```

```

SSO Descriptor: 44.254.44.44/2129, local label: 512
Dataplane:
  SSM segment/switch IDs: 20498/20492 (used), PWID: 2
VC statistics:
  transit packet totals: receive 0, send 0
  transit byte totals:   receive 0, send 0
  transit packet drops: receive 0, seq error 0, send 0

```

The **show l2vpn atom vc** shows that ATM over MPLS is configured on a VC.

```

pseudowire100005 is up, VC status is up PW type: Ethernet
  Create time: 19:25:56, last status change time: 09:40:37
  Last label FSM state change time: 09:40:37
  Destination address: 44.254.44.44 VC ID: 2129
  Output interface: Gi1/0/9, imposed label stack {18 17}
  Preferred path: not configured
  Default path: active
  Next hop: 177.77.177.2
Member of vfi service 2129
  Bridge-Domain id: 2129
  Service id: 0x32000003
Signaling protocol: LDP, peer 44.254.44.44:0 up
  Targeted Hello: 1.1.1.72(LDP Id) -> 44.254.44.44, LDP is UP
  Graceful restart: configured and enabled
  Non stop routing: not configured and not enabled
  PWid FEC (128), VC ID: 2129
  Status TLV support (local/remote)           : enabled/supported
  LDP route watch                             : enabled
  Label/status state machine                  : established, LruRru
  Local dataplane status received             : No fault
  BFD dataplane status received               : Not sent
  BFD peer monitor status received            : No fault
  Status received from access circuit         : No fault
  Status sent to access circuit               : No fault
  Status received from pseudowire i/f        : No fault
Status sent to network peer                   : No fault
  Status received from network peer           : No fault
  Adjacency status of remote peer             : No fault
Sequencing: receive disabled, send disabled
Bindings
  Parameter      Local                               Remote
  -----
  Label          512                               17
  Group ID      n/a                               0
  Interface
  MTU           1500                               1500
  Control word  off                               off
  PW type       Ethernet                             Ethernet
  VCCV CV type  0x02                               0x02

```

```

LSPV [2]
VCCV CC type 0x06
RA [2], TTL [3]
Status TLV enabled
SSO Descriptor: 44.254.44.44/2129, local label: 512
Dataplane:
SSM segment/switch IDs: 20498/20492 (used), PWID: 2
Rx Counters
0 input transit packets, 0 bytes
0 drops, 0 seq err
Tx Counters
0 output transit packets, 0 bytes
0 drops

```

Configuring VPLS BGP-based Autodiscovery

Information About VPLS BGP-Based Autodiscovery

VPLS BGP Based Autodiscovery

VPLS Autodiscovery enables each Virtual Private LAN Service (VPLS) provider edge (PE) device to discover other PE devices that are part of the same VPLS domain. VPLS Autodiscovery also tracks PE devices when they are added to or removed from a VPLS domain. As a result, with VPLS Autodiscovery enabled, you no longer need to manually configure a VPLS domain and maintain the configuration when a PE device is added or deleted. VPLS Autodiscovery uses the Border Gateway Protocol (BGP) to discover VPLS members and set up and tear down pseudowires in a VPLS domain.

BGP uses the Layer 2 VPN (L2VPN) Routing Information Base (RIB) to store endpoint provisioning information, which is updated each time any Layer 2 virtual forwarding instance (VFI) is configured. The prefix and path information is stored in the L2VPN database, which allows BGP to make decisions about the best path. When BGP distributes the endpoint provisioning information in an update message to all its BGP neighbors, this endpoint information is used to configure a pseudowire mesh to support L2VPN-based services.

The BGP autodiscovery mechanism facilitates the configuration of L2VPN services, which are an integral part of the VPLS feature. VPLS enables flexibility in deploying services by connecting geographically dispersed sites as a large LAN over high-speed Ethernet in a robust and scalable IP Multiprotocol Label Switching (MPLS) network.

For scale information related to this feature, see [Cisco Catalyst 9500 Series Switches Data Sheet](#).

Enabling VPLS BGP-based Autodiscovery

Perform this task to enable Virtual Private LAN Service (VPLS) PE devices to discover other PE devices that are part of the same VPLS domain.

Procedure

| | Command or Action | Purpose |
|---------------|--|---|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters the global configuration mode. |
| Step 3 | l2 vfi vfi-name autodiscovery Example: Device (config)# l2 vfi 2128 autodiscovery | Enables VPLS Autodiscovery on a PE device and enters L2 VFI configuration mode. |
| Step 4 | vpn id vpn-id Example: Device (config-vfi)# vpn id 2128 | Configures a VPN ID for the VPLS domain. |
| Step 5 | end Example: Device (config)# end | Returns to privileged EXEC mode. |

Configuring BGP to Enable VPLS Autodiscovery

The Border Gateway Protocol (BGP) Layer 2 VPN (L2VPN) address family supports a separate L2VPN Routing Information Base (RIB) that contains endpoint provisioning information for Virtual Private LAN Service (VPLS) Autodiscovery. BGP learns the endpoint provisioning information from the L2VPN database, which is updated each time a Layer 2 virtual forwarding instance (VFI) is configured. When BGP distributes the endpoint provisioning information in an update message to all its BGP neighbors, the endpoint information is used to configure a pseudowire mesh to support L2VPN-based services.

Procedure

| | Command or Action | Purpose |
|---------------|----------------------------------|--|
| Step 1 | enable Example: | Enables privileged EXEC mode. Enter your password if prompted. |

| | Command or Action | Purpose |
|---------------|--|---|
| | Device> enable | |
| Step 2 | configure terminal Example: Device# configure terminal | Enters the global configuration mode. |
| Step 3 | router bgp <i>autonomous-system-number</i> Example: Device(config)# router bgp 1000 | Enters router configuration mode for the specified routing process. |
| Step 4 | no bgp default ipv4-unicast Example: Device(config-router)# no bgp default ipv4-unicast | Disables the IPv4 unicast address family for the BGP routing process. Note Routing information for the IPv4 unicast address family is advertised by default for each BGP routing session configured using the neighbor remote-as router configuration command unless you configure the no bgp default ipv4-unicast router configuration command before configuring the neighbor remote-as command. Existing neighbor configurations are not affected. |
| Step 5 | bgp log-neighbor-changes Example: Device(config-router)# bgp log-neighbor-changes | Enables logging of BGP neighbor resets. |
| Step 6 | neighbor remote-as { <i>ip-address</i> <i>peer-group-name</i> } remote-as <i>autonomous-system-number</i> Example: Device(config-router)# neighbor 44.254.44.44 remote-as 1000 | Adds the IP address or peer group name of the neighbor in the specified autonomous system to the IPv4 multiprotocol BGP neighbor table of the local device. <ul style="list-style-type: none"> • If the autonomous-system-number argument matches the autonomous system number specified in the router bgp command, the neighbor is an internal neighbor. • If the autonomous-system-number argument does not match the autonomous |

| | Command or Action | Purpose |
|----------------|--|---|
| | | system number specified in the router bgp command, the neighbor is an external neighbor. |
| Step 7 | neighbor { <i>ip-address</i> <i>peer-group-name</i> } update-source <i>interface-type interface-number</i> Example: <pre>Device(config-router)# neighbor 44.254.44.44 update-source Loopback300</pre> | (Optional) Configures a device to select a specific source or interface to receive routing table updates. |
| Step 8 | Repeat Steps 6 and 7 to configure other BGP neighbors. | Exits interface configuration mode. |
| Step 9 | address-family l2vpn [vpls] Example: <pre>Device(config-router)# address-family l2vpn vpls</pre> | Specifies the L2VPN address family and enters address family configuration mode. The optional vpls keyword specifies that the VPLS endpoint provisioning information is to be distributed to BGP peers. |
| Step 10 | neighbor { <i>ip-address</i> <i>peer-group-name</i> } activate Example: <pre>Device(config-router-af)# neighbor 44.254.44.44 activate</pre> | Enables the exchange of information with a BGP neighbor. |
| Step 11 | neighbor { <i>ip-address</i> <i>peer-group-name</i> } send-community { both standard extended } Example: <pre>Device(config-router-af)# neighbor 44.254.44.44 send-community both</pre> | Specifies that a communities attribute should be sent to a BGP neighbor. |
| Step 12 | Repeat Steps 10 and 11 to activate other BGP neighbors under an L2VPN address family. | |
| Step 13 | exit-address-family Example: <pre>Device(config-router-af)# exit-address-family</pre> | Exits address family configuration mode and returns to router configuration mode. |

| | Command or Action | Purpose |
|----------------|---|--|
| Step 14 | end Example: Device(config-router-af)# end | Exits router configuration mode and returns to privileged EXEC mode. |

Configuration Examples for VPLS BGP-AD

```

PE Configuration

router bgp 1000
  bgp log-neighbor-changes
  bgp graceful-restart
  neighbor 44.254.44.44 remote-as 1000
  neighbor 44.254.44.44 update-source Loopback300
!
  address-family l2vpn vpls
    neighbor 44.254.44.44 activate
    neighbor 44.254.44.44 send-community both
  exit-address-family
!
l2 vfi 2128 autodiscovery
  vpn id 2128
  interface Vlan2128
    no ip address
    xconnect vfi 2128
!
    
```

The following is a sample output of **show platform software fed sw 1 matm macTable vlan 2000** command :

| VLAN | MAC | Type | Seq# | macHandle | siHandle |
|------|----------------|-----------|---------|------------------|--------------|
| | diHandle | *a_time | *e_time | ports | |
| 2000 | 2852.6134.05c8 | 0X8002 | 0 | 0xffbba312c8 | 0xffbb9ef938 |
| | 0x5154 | 0 | 0 | Vlan2000 | |
| 2000 | 0000.0078.9012 | 0X1 | 32627 | 0xffbb665ec8 | 0xffbb60b198 |
| | 0xffbb653f98 | 300 | 278448 | Port-channel11 | |
| 2000 | 2852.6134.0000 | 0X1 | 32651 | 0xffba15e1a8 | 0xff454c2328 |
| | 0xffbb653f98 | 300 | 63 | Port-channel11 | |
| 2000 | 0000.0012.3456 | 0X2000001 | 32655 | 0xffba15c508 | 0xff44f9ec98 |
| | 0x0 | 300 | 1 | 2000:33.33.33.33 | |

Total Mac number of addresses:: 4

*a_time=aging_time(secs) *e_time=total_elapsed_time(secs)

Type:

| | | | |
|------------------|-------|------------------|-------|
| MAT_DYNAMIC_ADDR | 0x1 | MAT_STATIC_ADDR | 0x2 |
| MAT_CPU_ADDR | 0x4 | MAT_DISCARD_ADDR | 0x8 |
| MAT_ALL_VLANS | 0x10 | MAT_NO_FORWARD | 0x20 |
| MAT_IPMULT_ADDR | 0x40 | MAT_RESYNC | 0x80 |
| MAT_DO_NOT_AGE | 0x100 | MAT_SECURE_ADDR | 0x200 |
| MAT_NO_PORT | 0x400 | MAT_DROP_ADDR | 0x800 |

```

MAT_DUP_ADDR          0x1000      MAT_NULL_DESTINATION 0x2000
MAT_DOT1X_ADDR        0x4000      MAT_ROUTER_ADDR      0x8000
MAT_WIRELESS_ADDR     0x10000     MAT_SECURE_CFG_ADDR  0x20000
MAT_OPQ_DATA_PRESENT  0x40000     MAT_WIRED_TUNNEL_ADDR 0x80000
MAT_DLR_ADDR          0x100000    MAT_MRP_ADDR         0x200000
MAT_MSRP_ADDR         0x400000    MAT_LISP_LOCAL_ADDR  0x800000
MAT_LISP_REMOTE_ADDR  0x1000000    MAT_VPLS_ADDR        0x2000000

```

The following is a sample output of **show bgp l2vpn vpls all** command :

```

BGP table version is 6, local router ID is 222.5.1.1
Status codes: s suppressed, d damped, h history, * valid, > best, i -
internal,
  r RIB-failure, S Stale, m multipath, b backup-path, f RT-Filter,
  x best-external, a additional-path, c RIB-compressed,
  t secondary path,
Origin codes: i - IGP, e - EGP, ? - incomplete
RPKI validation codes: V valid, I invalid, N Not found
Network          Next Hop          Metric LocPrf Weight Path
Route Distinguisher: 1000:2128
*>  1000:2128:1.1.1.72/96
      0.0.0.0                      32768 ?
*>i  1000:2128:44.254.44.44/96
      44.254.44.44                0    100    0 ?

```