



Preface

This guide includes information about the Cisco Unified Computing System (Cisco UCS) Invicta Scaling System for both performance and data reduction silicon storage systems.

Information applies to both types of systems unless otherwise noted. Unique content is identified within the content.

Document History

This document applies to the following Cisco Invicta Scaling System OS releases:

- 501
- 5011
- 5011a

Organization

This guide includes the following sections:

Chapter	Title	Description
1	Overview	Describes prerequisite and initial configuration information.
2	Home	Describes the GUI Home tab including the Main Dashboard and drive tasks.
3	SSR Configuration	Describes topics related to configuration, including network, MPIO, and VG settings.
4	SSR Configuration	Describes LUN configuration tasks and includes information on snapshots.
5	Asynchronous Replication	Describes how to create a duplicate version of a LUN on a device attached to a partner host.
6	Users	Describes how to perform user-related tasks, such as creating, editing, modifying, or deleting user accounts and creating, deleting, or modifying user roles.

Conventions

This document uses the following conventions:

Convention	Indication
bold font	Commands and keywords and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.
{ x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Caution

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



Warning

IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.