

Preface

This preface includes the following sections:

- Audience, page i
- Organization, page i
- Related Documentation, page ii
- Obtaining Documentation and Submitting a Service Request, page ii

Audience

This troubleshooting guide is designed for users who are responsible for troubleshooting issues that arise with a Cisco UCS instance.

Organization

This reference guide is organized into the following parts and chapters:

- Cisco UCS Manager Faults
 - Chapter 1, "Introduction to UCS Faults"
 - Chapter 2, "Cisco UCS Faults"
 - Chapter 3, "FSM Faults"
 - Chapter 4, "Call Home Faults in Cisco UCS Manager"
 - Chapter 5, "Troubleshooting Transient Faults"
- Cisco UCS Manager SEL Messages
 - Chapter 6, "Introduction to System Event Log Messages"
 - Chapter 7, "Baseboard Management Controller Messages"

Related Documentation

Cisco UCS Manager GUI System Monitoring Guide, Release 2.5 and Cisco UCS Manager CLI System Monitoring Guide, Release 2.5 provide detailed information about fault suppression, and is available at the following URLs:

http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/sw/gui/config/guide/2-5/b_UCSM_GUI_System_Monitoring_Guide_2_5.html

http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/sw/cli/config/guide/2-5/b_UCSM_CLI_System_Monitoring_Guide_2_5.html

A roadmap that lists all documentation for the Cisco Unified Computing System (Cisco UCS) is available at the following URL:

http://www.cisco.com/en/US/products/ps10477/products_documentation_roadmaps_list.html

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation*.

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the What's New in Cisco Product Documentation RSS feed. The RSS feeds are a free service.