



Preface

This preface includes the following sections:

- [Audience, page i](#)
- [Organization, page i](#)
- [Related Documentation, page ii](#)
- [Obtaining Documentation and Submitting a Service Request, page ii](#)

Audience

This troubleshooting guide is designed for users who are responsible for troubleshooting issues that arise with a Cisco UCS instance.

Organization

This reference guide is organized into the following parts and chapters:

- Cisco UCS Manager Faults
 - [Chapter 1, “Introduction to UCS Faults”](#)
 - [Chapter 2, “Cisco UCS Faults”](#)
 - [Chapter 3, “FSM Faults”](#)
 - [Chapter 4, “Call Home Faults in Cisco UCS Manager”](#)
 - [Chapter 5, “Troubleshooting Transient Faults”](#)
- Cisco UCS Manager SEL Messages
 - [Chapter 6, “Introduction to System Event Log Messages”](#)
 - [Chapter 7, “Baseboard Management Controller Messages”](#)

Related Documentation

A roadmap that lists all documentation for the Cisco Unified Computing System (Cisco UCS) is available at the following URL:

http://www.cisco.com/en/US/products/ps10477/products_documentation_roadmaps_list.html

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *[What's New in Cisco Product Documentation](#)*.

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the *[What's New in Cisco Product Documentation RSS feed](#)*. The RSS feeds are a free service.