



INDEX

A

- abbreviated dialing [3](#)
- About window, build versions might vary [15](#)
- adjunct licensing [9](#)
- administration tool
 - for audio IP address detection [9](#)
 - for unsupported VPN clients [9](#)
- advanced audio settings [11](#)
- alarms, displaying [17](#)
- application performance
 - degraded [14](#)
 - monitoring [19](#)
- audience, for this document [9](#)
- audio devices
 - installing [1](#)
 - selecting and tuning [1,5](#)
 - selection for audio modes [5](#)
 - supported [1](#)
 - tuning [5](#)
- audio formats, supported [12](#)
- audio IP address
 - and Administration Tool [9](#)
 - auto-detection of [9,10](#)
 - reflector web page for [9,10](#)
 - resolving problems with [9,10](#)
 - with VPN, how detected [9](#)
- audio modes, selecting devices for [5](#)
- audio port range, selections for [11](#)
- audio quality, troubleshooting [1](#)
- audio settings
 - common tuning mistakes [6](#)
 - configuring advanced [11](#)

- for remote use [12](#)
- audio tuning wizard
 - and Windows 2000 [15](#)
 - microphone tuning restrictions [15](#)
 - using [1,5](#)
- authenticated calls [14](#)
- authentication
 - certificate for device [13](#)
 - providing Quick Search information to users [13](#)
 - security profiles [14](#)
 - signaling [13](#)
- auto answer [3](#)
- auto-registration
 - for SIP devices [5](#)
 - using [6](#)
 - with TAPS [7](#)

B

- background images
 - See custom background images
- background noise, reducing [11](#)
- barge [3](#)
- BAT, adding Cisco IP Communicator with [8](#)
- block external-to-external transfer [3](#)

C

- caller ID [3](#)
- call-forward alternate party
 - See CFAP
- call forward display, configuring [4](#)
- call park [3](#)

- call pickup [3](#)
- call preferences, displaying [6](#)
- calls
 - authenticated [14](#)
 - digits not recognized [14](#)
 - display restrictions [3](#)
- Call Statistics screen, viewing locally [13](#)
- call waiting [3](#)
- CAPF, described [13](#)
- CDP [2](#)
- Certificate Authority Proxy Function
 - See CAPF
- certificate for device authentication [13](#)
- certificate trust list
 - See CTL [4](#)
- CFAP [5](#)
- checklist
 - for configuring after installation [1](#)
 - for deploying [2](#)
- Cisco Call Back [3](#)
- Cisco Discovery Protocol
 - See CDP
- Cisco IP Communicator
 - adding manually [8](#)
 - auto-registering [6](#)
 - configuring [1](#)
 - deploying [2](#)
 - deploying in SCCP and SIP environments [11](#)
 - described [1](#)
 - device web page for [14](#)
 - methods for adding [6](#)
 - registering [6](#)
 - resetting unexpectedly [14](#)
- Cisco IP Manager Assistant [4](#)
- Cisco IP Telephony Locale Installer [3](#)
- Cisco TAC Case Collection tool [2](#)
- Cisco Unified Communications Manager
 - configuring features for [1](#)
 - directory servers for [9](#)
 - interaction with Cisco IP Communicator [4](#)
 - releases supported [5](#)
 - requirements for Cisco IP Communicator [1](#)
 - with auto-registration and TAPS [7](#)
 - with BAT [8](#)
- client matter codes
 - See CMC
- client PC
 - deploying on [4](#)
 - requirements of [1](#)
- CMC [4](#)
- codecs
 - mismatches between IP Communicator and another device [10](#)
 - poor audio quality with low-bandwidth codecs and cell phones [10](#)
- command-line options
 - allowing SIP devices to auto-register [5](#)
 - displaying a dialog box that users must manually dismiss [6](#)
 - for the MSI package [4](#)
 - installing a language locale [5](#)
 - specifying a device name
 - free-form [5](#)
 - free-form and TFTP server addresses [5](#)
 - network interface [5](#)
 - network interface and TFTP server addresses [5](#)
 - specifying a TFTP server
 - multiple [5](#)
 - single [5](#)
 - specifying device name with [7](#)
 - specifying network interface with [7](#)
- common tuning mistakes [6](#)
- conference [4](#)
- configurable call forward display [4](#)
- configuration files
 - cnf.xml, described [6](#)
 - CTLFile.tlv, described [6](#)
 - damage to [6](#)
 - described [7](#)

- requesting at startup [6](#)
 - requests for [7](#)
 - types generated by TFTP server [8](#)
 - xmldefault.cnf.xml, described [6](#)
 - configuration server, locating at startup [5](#)
 - conventions, use of [10](#)
 - credentials
 - for Quick Search [13](#)
 - providing to users [13](#)
 - CTL file
 - and TLS connection [7](#)
 - described [13](#)
 - erasing [19](#)
 - information displayed in Cisco IP Communicator [8](#)
 - request for it during startup process [5](#)
 - CTL File screen [8](#)
 - custom background images
 - configuring [5](#)
 - described [3](#)
 - List.xml file format requirements [4](#)
 - PNG file requirements [5](#)
 - custom phone rings
 - described [1](#)
 - PCM file requirements [2](#)
-
- ## D
- debug messages, displaying [17](#)
 - deployment
 - checklist [2](#)
 - methods [3](#)
 - tools
 - for software updates [6](#)
 - using [4](#)
 - detailed logs, described [4](#)
 - device authentication [13](#)
 - device information
 - displaying call preferences [6](#)
 - displaying line settings information [5](#)
 - displaying SIP configuration information [4](#)
 - viewing from web page [15](#)
 - viewing locally [2](#)
 - device logs, viewing remotely [17](#)
 - device names
 - and docking station [8](#)
 - and laptops [8](#)
 - and MAC address [7](#)
 - and network interface [7](#)
 - and wireless interface [8](#)
 - derivation of [7](#)
 - for switching between SCCP and SIP configurations [12](#)
 - selecting
 - after disabled or removed interface [8](#)
 - described [7](#)
 - multiple network interfaces [8](#)
 - shared PCs [8](#)
 - specifying
 - free-form name with command-line options [5](#)
 - network interface with command-line options [5](#)
 - troubleshooting [7](#)
 - DHCP
 - at startup [5](#)
 - described [2](#)
 - dialing rules
 - for Quick Search [14](#)
 - for SIP [8](#)
 - directories
 - button [8](#)
 - configuring [8](#)
 - integrating [9](#)
 - directory numbers, assigning
 - manually [8](#)
 - with auto-registration [6](#)
 - with BAT [8](#)
 - with TAPS and auto-registration [7](#)
 - directory search methods, overview [8](#)
 - directory wizard

configuring Quick Search with [10](#)
 tips for configuring [11](#)
 direct transfer [4](#)
 disk space, insufficient [5](#)
 docking stations, and network interfaces [8](#)
 do not disturb [4](#)
 Dynamic Host Configuration Protocol
 See DHCP

E

echoes, resolving problems with [11](#)
 enable logging setting [4](#)
 Ethernet interface, and device name [8](#)
 executable installer, using [2](#)
 Extensible Markup Language
 See XML

F

FAC [4](#)
 features, described [1](#)
 firewalls, selecting port range for [11](#)
 forced authorization codes
 See FAC
 forward [4](#)

G

getIP.asp, creating for audio IP address detection [9](#)
 group call pickup [4](#)
 guide, conventions [10](#)

H

hardware requirements [1](#)
 headsets
 See audio devices

hold [4](#)
 HTTP
 use of [3](#)
 HyperText Transfer Protocol
 See HTTP

I

idle display, configuring [6](#)
 immediate divert [4](#)
 information needed by users [1](#)
 installation
 adding devices to the database [6](#)
 checklist [2](#)
 client PC requirements [1](#)
 network requirements [1](#)
 prerequisites [1](#)
 requirements [1](#)
 installer packages, described [3](#)
 internal web server, disabling [14](#)
 IP, described [3](#)

J

join [4](#)

L

language locale
 prompted for during installation [4](#)
 specifying with command-line option [5](#)
 languages, support for [3](#)
 laptops, and network interfaces [8](#)
 LDAP
 and personal directories [15](#)
 use of [3](#)
 with Quick Search [9](#)
 licensing, adjunct

- configuring [9](#)
- described [9](#)
- restrictions [9](#)

Lightweight Directory Access Protocol

- See LDAP

line buttons, templates for [6](#)

line settings, displaying [5](#)

local configuration, understanding [13](#)

localization, installing Cisco IP Telephony Locale Installer [3](#)

Locally Significant Certificate

- See LSC

local settings access, disabling [13](#)

locked configuration options

- described [18](#)
- locked padlock icon [18](#)
- unlocking [18](#)

logging, enabling [4](#)

logs

- capturing detailed [4](#)
- collecting when the application crashes [3](#)

low bandwidth

- and digital cell phones [10](#)
- enabling [12](#)

LSC

- described [12](#)
- does not install issue [8](#)

M

MAC address

- and device name [7](#)
- and network interface [7](#)

malicious caller identification

- See MCID

MCID [5](#)

meet-me conference [5](#)

message waiting [5](#)

Microsoft Windows Installer package (MSI), using [2](#)

MLPP [5](#)

model information [7](#)

multilevel precedence and preemption

- See MLPP

music-on-hold [5](#)

N

network, disabling settings [13](#)

Network Configuration web page [16](#)

networking protocols

- BootP [2](#)
- CDP [2](#)
- DHCP [2](#)
- HTTP [3](#)
- IP [3](#)
- LDAP [3](#)
- RTP [3](#)
- SCCP [3](#)
- SDP [3](#)
- SIP [3](#)
- TCP [3](#)
- TFTP [4](#)
- TLS [4](#)
- UDP [4](#)
- XML [4](#)

network interface

- and device name [7](#)
- and docking stations [8](#)
- and laptops [8](#)
- and MAC address [7](#)
- Ethernet [8](#)
- removing or disabling [7](#)
- selecting [7](#)
- specifying with command-line options [7](#)
- troubleshooting [7](#)
- wireless [8](#)

network requirements, for installing [1](#)

noise suppression [11](#)

O

one-way audio

- resolving problems with [11](#)
- with unsupported VPN clients [9](#)

operational information

- overview [1](#)
- viewing locally [2](#)
- viewing remotely [14](#)

Ppasswords, providing to users [13](#)

PCM

- custom ring type file requirements [2](#)
- described [1](#)

PC requirements [1](#)performance, improving for remote users [12](#)performance degraded from detailed logs [4](#)performance monitoring [19](#)

personal address book service

- configuring [15](#)
- using Quick Search with [15](#)
- using synchronizer with [15](#)

personal directories [15](#)personal fast dial service [15](#)phone button templates, modifying [6](#)phone load information [7](#)

phone screen

- configuring idle display [6](#)
- configuring images [3](#)

platform requirements [1](#)port range, selecting [11](#)

post-installation tasks

- recommended [4](#)
- required [2](#)

privacy [5](#)

privileges

- for deploying [3,4](#)

Problem Reporting Tool

- caveats for roaming users [3](#)
- described [3](#)

protocols

- call control running on Cisco IP Communicator [7](#)
- supported [2](#)

pulse code modulation

- See PCM

Q

QoS

- network modifications to prioritize voice traffic [9](#)
- restricted range of RTP ports [11](#)

QRT [5](#)

- described [2](#)
- softkey [5,3](#)

quality of service

- See QoS

Quality Reporting Tool

- See QRT

Quick Search

- described [9](#)
- dialing rules for [14](#)
- resolving problems with [14](#)
- specifying authentication information for [13](#)
- specifying credentials for [13](#)
- supported releases [11](#)
- with external directories [12](#)
- with the personal address book service [15](#)

R

Real-Time Transport Protocol

- See RTP

redial [5](#)

registration

- failure [6,7](#)

- methods of [6](#)
- preparing for [2](#)
- with auto-registration [6](#)
- with BAT [8](#)
- with TAPS [7](#)

remote configuration, versus local [13](#)

remote use, settings for [12](#)

ring activity [5](#)

ringer

- customizing [3](#)
- selecting devices for [5](#)

RingList.xml

- described [1](#)
- file format requirements [2](#)

route patterns, with Quick Search [14](#)

RTP

- described [3](#)
- selecting audio port range [11](#)

S

SCCP

- converting existing IP Communicator installation to [11](#)
- described [3](#)
- using a device name to switch to SIP [12](#)

SDP, described [3](#)

secondary licensing

- See licensing, adjunct

security

- CTLFile.tlv, described [6](#)
- resolving
 - configuring IP error message [9](#)
 - LSC does not install on client PC [8](#)
 - registration rejected, security error message [8](#)

security and cryptographic features [12](#)

security configuration information, described [7](#)

security features

- CAPF, described [13](#)

configuring with Release 4.x [15](#)

configuring with Release 5.x [16](#)

CTL file, described [13](#)

function of [12](#)

list of related topics [19](#)

locked padlock icon [18](#)

LSC, described [12](#)

supported [13](#)

verifying the configuration [18](#)

services

- adding or deleting [8](#)
- button [9](#)
- configuring [7](#)
- description [5](#)
- subscribing to [8](#)

Services URL button [5](#)

Session Description Protocol

- See SDP

Session Initiation Protocol

- See SIP

settings button, disabling [13](#)

shared location, deploying to a [3](#)

shared PC

- specifying device name for [8](#)
- specifying network interface for [8](#)
- specifying TFTP server for [7](#)

signaling authentication [13](#)

SIP

- allowing auto-registration with command-line options [5](#)
- converting
 - existing IP Communicator installation to [11](#)
 - new IP Communicator installation to [10](#)
- described [3](#)
- dialing rules [8](#)
- using a device name to switch to SCCP [12](#)

SIP configuration information, displaying [4](#)

Skinny Client Control Protocol

- See SCCP

- softkey templates, configuring 7
 - software
 - download site 6
 - software deployment tool
 - described 4
 - for updates 6
 - speed dial
 - described 5
 - templates for 6
 - SRST, IP address of router 9
 - startup
 - configuration tasks after 1
 - configuring audio devices after 5
 - improving performance for remote users 12
 - overview of 5
 - resolving problems with 5
 - resolving when unresponsive or slow 6
 - selecting device name after 7
 - selecting network interface after 7
 - specifying TFTP server after 6
 - statistics
 - call 13
 - sound sample mismatch 10
 - streaming 18
 - Status menu 9
 - Status Messages
 - screen, viewing locally 9
 - web page, viewing remotely 17
 - streaming statistics, viewing remotely 18
 - Survivable Remote Site Telephony
 - See SRST
-
- T**
- TAC Case Collection tool 2
 - TAPS, with auto-registration 7
 - TCP, described 3
 - telephony features
 - abbreviated dialing 3
 - auto answer 3
 - barge 3
 - block external-to-external transfer 3
 - call display restrictions 3
 - caller ID 3
 - call park 3
 - call pickup 3
 - call waiting 3
 - Cisco Call Back 3
 - Cisco IP Manager Assistant 4
 - client matter codes 4
 - conference 4
 - configurable call forward display 4
 - direct transfer 4
 - do not disturb 4
 - forced authorization codes 4
 - forward 4
 - group call pickup 4
 - hold 4
 - immediate divert 4
 - join 4
 - malicious caller identification 5
 - meet-me conference 5
 - message waiting 5
 - multilevel precedence and preemption 5
 - music-on-hold 5
 - overview of 2
 - privacy 5
 - Quality Reporting Tool 5
 - redial 5
 - ring activity 5
 - services 5
 - Services URL button 5
 - speed dial 5
 - Time-of-Day Routing 6
 - transfer 6
 - video support 6
 - voice messaging system 6
 - TFTP

- at startup [5](#)
- described [4](#)
- use of [5](#)

TFTP server, specifying [6](#)

third-party headsets and handsets [2](#)

Time-of-Day Routing [6](#)

TLS

- described [4](#)
- establishing a connection [7](#)

tools

- Problem Reporting [3](#)
- Quality Report [2](#)

transfer [6](#)

Transmission Control Protocol

- See TCP

Transport Layer Security

- See TLS

Trivial File Transfer Protocol

- See TFTP

troubleshooting

- security problems [8](#)
- startup problems [5](#)
- viewing device logs [17](#)

trust list information, described [8](#)

Trust List screen [8](#)

tuning audio devices [5](#)

U

UDP, described [4](#)

uninstall problem, all files not removed [5](#)

User Datagram Protocol

- See UDP

user information, providing [1](#)

users

- access to documentation and online help [4](#)
- adding [1](#)
- contact names to provide assistance [4](#)
- helping with configuration [14](#)

- how to report problems [4](#)
- information to complete configuration tasks [1](#)
- instructions for accessing voice messaging system [4](#)
- password information for [13](#)
- personal directory username and password [2](#)
- required information for [1](#)
- username and password for User Options web pages [2](#)

V

video support [6](#)

voice messaging system [6](#)

voice quality

- disruptions, silences, jittery sounds [12](#)
- echoes [11](#)
- gaps in calls [10](#)
- no audio [10](#)
- QRT [2](#)
- robotic or distorted [12](#)
- with low-bandwidth codec and cell phone [10](#)

voice quality and voice gateways, diagnosing [2](#)

volume, for audio devices [5](#)

VPN clients

- audio IP address, how detected [9](#)
- supported software [9](#)
- support for [2](#)
- with audio IP address detection [9, 10](#)

W

web page

- about [14](#)
- accessing [15](#)
- Device Information [15](#)
- for Cisco IP Communicator devices [14](#)
- Network Configuration [16](#)
- Status Messages [17](#)

web server, disabling [14](#)

Windows Performance Tool

setting up on Windows 2000 and XP [19](#)

setting up on Windows Vista [21](#)

wireless interface, and device name [8](#)

X

XML

use of [4](#)

with Quick Search [9](#)