



## INDEX

---

### A

- access ports, about [5-6](#)
- alarms
  - location of panel [1-3](#)

---

### B

- best practices
  - for security [4-1](#)
- blades
  - and port information [1-8](#)

---

### C

- CD-ROM drive, about [1-4](#)
- Cisco Unified MeetingPlace
  - about [1-1](#)
- Cisco Unified MeetingPlace 8106
  - about [1-3](#)
  - isolating from broadcast storm [3-2](#)
  - LEDs
    - disk drives [1-6](#)
    - fan tray [1-6](#)
    - power supply units [1-6](#)
  - maximum ports allowed [1-9](#)
- Cisco Unified MeetingPlace 8112
  - about [1-3](#)
  - isolating from broadcast storm [3-2](#)
  - LEDs
    - component out of service [1-7](#)
    - system in service [1-7](#)
    - system out of service [1-7](#)

- Telco critical alarm [1-7](#)
- Telco major alarm [1-7](#)
- Telco minor alarm [1-7](#)
- maximum ports allowed [1-16](#)
- slot configuration examples [1-16](#)
- Cisco Unified MeetingPlace Audio Server
  - software [1-20](#)
  - user licenses [1-20](#)
  - voice-only configuration [1-20](#)
- Cisco Unified MeetingPlace Directory Services
  - about [1-22, 5-11](#)
- Cisco Unified MeetingPlace for Lotus Notes
  - about [1-21](#)
- Cisco Unified MeetingPlace for Outlook
  - about [1-21](#)
- Cisco Unified MeetingPlace H.323/SIP IP Gateway
  - about [1-22](#)
- Cisco Unified MeetingPlace Network Backup Gateway
  - about [1-22](#)
- Cisco Unified MeetingPlace SMTP E-Mail Gateway
  - about [1-22](#)
- Cisco Unified MeetingPlace Web Conferencing
  - for web conferencing [1-21](#)
- combined access, about [5-3](#)
- company information
  - about [5-2](#)
  - worksheet for planning [5-26](#)
- conference ports
  - about [5-6](#)
  - calculating number of [5-6](#)
- configuration
  - information
    - Cisco Unified MeetingPlace [5-2](#)

server [5-5](#)

telephony [5-3](#)

## configuring

Cisco Unified MeetingPlace Audio Server

examples [1-16](#)

Cisco Unified MeetingPlace system [5-2](#)

MIB files [5-5](#)

port groups [5-4](#)

ports [5-4](#)

contingency ports, about [5-6](#)

## D

### database planning

worksheets [5-12](#)

disk drives, LEDs [1-6](#)

## E

Euro ISDN [1-5](#)

external modem, about [1-6](#)

## F

fan tray LEDs [1-6](#)

### flex fields

about [5-2](#)

worksheet for planning [5-28](#)

### floater ports

about [5-6](#)

## G

### guard times

about [5-2](#)

### guest profile

about [5-7](#)

## importing

user groups [5-10](#)

### user profiles

general [5-10](#)

manually [5-11](#)

required file format [5-11](#)

installation planning [5-12](#)

### installation planning worksheets

about [5-12](#)

### installing

Cisco Unified MeetingPlace

activities for [2-1](#)

site selection [3-1](#)

warnings [2-2](#)

worksheets for planning [3-2](#)

## L

### LAN

#### requirements

Hong Kong [3-12](#)

U.S., Canada, Japan [3-12](#)

### LEDs

Cisco Unified MeetingPlace 8106

disk drives [1-6](#)

fan tray [1-6](#)

power supply units [1-6](#)

Cisco Unified MeetingPlace 8112

component out of service [1-7](#)

system in service [1-7](#)

system out of service [1-7](#)

Telco critical alarm [1-7](#)

Telco major alarm [1-7](#)

Telco minor alarm [1-7](#)

power supply units [1-6](#)

### licenses

about [1-20](#)

---

**M**

- master switch controller [1-5](#)
- meeting access [5-3](#)
- MeetingTime
  - about [1-20](#)
- MIB files, loading and configuring [5-5](#)
- Multi Access Blades
  - about [1-5](#)
- multiserver meetings
  - requirements [5-49](#)
  - worksheet for planning [5-50](#)

---

**N**

- network
  - getting status information [5-5](#)
  - interface [1-6](#)
  - management
    - communities [5-5](#)
    - information [5-5](#)
    - worksheet for planning communities [5-43](#)
    - worksheet for planning information [5-42](#)
- NS site configuration, worksheet for planning [5-47](#)

---

**O**

- outdialing
  - and user profiles [5-10](#)

---

**P**

- parameters
  - scheduling [5-2](#)
  - security [4-3](#)
  - usage [5-2](#)
  - user profiles [5-61](#)
- port resource card [1-5](#)

---

 ports

- access [5-6](#)
  - and blade information [1-8](#)
  - conference [5-6](#)
  - configuring [5-4](#)
  - configuring groups [5-4](#)
  - contingency [5-6](#)
  - creating groups [5-4](#)
  - floater [5-6](#)
  - groups
    - organizing [5-3](#)
  - types [5-6](#)
  - worksheet for planning [5-33](#)
  - worksheet for planning port groups [5-36](#)
- Primary Rate Interface [1-5](#)
- profile access [5-3](#)

---

**Q**

- QSIG [1-5](#)

---

**R**

- Rapid Adoption Plan
  - about [6-1](#)
  - worksheets [6-3](#)
- requirements
  - for installation site [2-3](#)
- LAN
  - Hong Kong [3-12](#)
  - U.S., Canada, Japan [3-12](#)
- multiserver meetings [5-49](#)
- reservationless meetings [5-40](#)
- telephony
  - Hong Kong [3-8](#)
  - ISDN-PRI lines (U.S., Canada, Japan) [3-6](#)
  - non-ISDN T1 lines (U.S., Canada, Japan) [3-4](#)
- VoIP telephone connections [3-14](#)

reservationless meetings  
 and user profiles [5-10](#)  
 requirements [5-40](#)

---

## S

safety warnings

translated [A-1](#)

scheduling parameters

about [5-2](#)

worksheet for planning [5-19](#)

security

best practices for Cisco Unified MeetingPlace [4-1](#)

parameters [4-3](#)

server

configuration

information [5-5](#)

worksheet for planning [5-44](#)

Simple Network Management Protocol

see SNMP

site

selection requirements worksheet [2-3](#)

SNMP

and monitoring Cisco Unified MeetingPlace [5-5](#)

and trap messages [5-5](#)

software

additional options [1-21](#)

Cisco Unified MeetingPlace Audio Server [1-20](#)

SQL database [1-20](#)

UNIX/POSIX [1-20](#)

software options

Cisco Unified MeetingPlace Directory Services [1-22](#)

Cisco Unified MeetingPlace for Lotus Notes [1-21](#)

Cisco Unified MeetingPlace for Outlook [1-21](#)

Cisco Unified MeetingPlace H.323/SIP IP  
Gateway [1-22](#)

Cisco Unified MeetingPlace Network Backup  
Gateway [1-22](#)

Cisco Unified MeetingPlace SMTP E-Mail  
Gateway [1-22](#)

Cisco Unified MeetingPlace Web Conferencing [1-21](#)

SQL database [1-20](#)

system configuration

for Cisco Unified MeetingPlace [5-2](#)

system database disks, about [1-5](#)

system parameters, worksheet for planning [5-38](#)

---

## T

teams

about [5-8](#)

Telco alarms [1-7](#)

telephony

access

about [5-3](#)

worksheet for planning [5-30](#)

requirements

Hong Kong [3-8](#)

ISDN-PRI lines (U.S., Canada, Japan) [3-6](#)

non-ISDN T1 lines (U.S., Canada, Japan) [3-4](#)

time zones

and user profile [5-10](#)

traps

messages when sent [5-5](#)

---

## U

usage

parameters [5-2](#)

worksheet for planning parameters [5-13](#)

user groups

about [5-7, 5-8](#)

creating [5-8](#)

defined by class-of-service [5-8](#)

importing information [5-10](#)

worksheet for planning [5-52](#)

user information

see user profiles

user profiles

about 5-7

and outdialing 5-10

and time zones 5-10

creating 5-10

importing

information 5-10

manually 5-11

parameters 5-61

required file format for import 5-11

worksheet for planning 5-61

---

## V

video conferencing

about 1-21

VoIP, requirements for telephone connections 3-14

---

## W

warnings about installation 2-2

worksheets

Cisco Unified MeetingPlace for VoIP telephone connections 3-14

Cisco Unified MeetingPlace LAN requirements (Hong Kong) 3-12

Cisco Unified MeetingPlace LAN requirements (U.S., Canada, Japan) 3-12

Cisco Unified MeetingPlace site requirements 2-3

Cisco Unified MeetingPlace telephony requirements (Hong Kong) 3-8

Cisco Unified MeetingPlace telephony requirements for ISDN-PRI lines (U.S., Canada, Japan) 3-6

Cisco Unified MeetingPlace telephony requirements for non-ISDN T1 lines (U.S., Canada, Japan) 3-4

company information 5-26

flex fields 5-28

multiserver meeting requirements 5-49

network management communities 5-43

network management information 5-42

NS site configuration 5-47

other Cisco Unified MeetingPlace servers 5-50

port groups 5-36

ports 5-33

Rapid Adoption Plan

about 6-3

announce 6-7

monitor and expand 6-12

permeate 6-10

prepare 6-4

quick start 6-8

reservationless meetings, requirements 5-40

scheduling parameters 5-19

server configuration 5-44

system parameters 5-38

telephony access 5-30

usage parameters 5-13

user groups 5-52

user profiles 5-61

