



# IMEI-TAC-Group Configuration Mode Commands

The IMEI-TAC-Group Configuration Mode provides access to the commands used to configure the IMEI-TAC values and ranges included in the IMEI-TAC groups. These IMEI-TAC values and ranges are used as the selection criteria for operator policy selection based on IMEI-TAC. For details about this functionality, refer to the *Operator Policy Selection Based on IMEI-TAC* chapter in the *MME Administration Guide*.

## Command Modes

Exec > Global Configuration > LTE Policy Configuration > IMEI-TAC-Group

**configure** > **lte-policy** > **imei-tac-group** *group\_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(imei-tac-group) #
```



## Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [end, on page 1](#)
- [exit, on page 2](#)
- [tac, on page 2](#)
- [tac-range, on page 3](#)

## end

Exits the current configuration mode and returns to the Exec mode.

## Product

All

## Privilege

Security Administrator, Administrator

## Syntax Description

**end**

## Usage Guidelines

Use this command to return to the Exec mode.

## exit

Exits the current mode and returns to the parent configuration mode.

---

**Product**

All

---

**Privilege**

Security Administrator, Administrator

---

**Syntax Description**

**exit**

---

**Usage Guidelines**

Use this command to return to the parent configuration mode.

## tac

Configures individual TAC (type allocation code) values to be included in a IMEI-TAC group which will be used as criteria for operator policy selection.

---

**Product**

MME

---

**Privilege**

Administrator

---

**Command Modes**

Exec > Global Configuration > LTE Policy Configuration > IMEI-TAC-Group

**configure > lte-policy > imei-tac-group***group\_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(imei-tac-group)#
```

---

**Syntax Description**

[ **no** ] **tac** *tac\_value* [ *tac\_value tac\_value +* ]

---

**no**

Removes the identified TAC from the IMEI-TAC group configuration.

---

**tac\_value**

Specifies the 8-digit number that identifies a specific "type allocation code". When entering more than one TAC, simply use a space between each TAC. Additional TAC values can be added at any time after the IMEI-TAC group is configured.

---

**Usage Guidelines**

Use this command to enter one or more individual TAC (type allocation code) values to the IMEI-TAC group. Up to 500 unique IMEI-TAC values can be included in an IMEI-TAC group.

The TAC, the first eight digits of the 15-digit IMEI or 16-digit IMEI-SV, identifies the equipment manufacturer, the wireless device type and the model number (if there is one); for example, TAC of 35201906 identifies an Apple iPhone 5S.

---

**Example**

The following command adds four IMEI-TAC to an IMEI-TAC group:

```
tac 31441551 77777777 87650506 87654321
```

## tac-range

Defines a range of IMEI-TAC values to be included in a IMEI-TAC group which will be used as criteria for operator policy selection.

---

### Product

MME

---

### Privilege

Administrator

---

### Command Modes

Exec > Global Configuration > LTE Policy Configuration > IMEI-TAC-Group  
**configure > lte-policy > imei-tac-group***group\_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(imei-tac-group)#
```

---

### Syntax Description

[ **no** ] **tac-range from** *start\_tac\_value* **to** *end\_tac\_value*

**no**

Removes the identified TAC range from the IMEI-TAC group configuration.

***start\_tac\_value to end\_tac\_value***

*tac\_value* - Specifies the 8-digit number that identifies a specific "type allocation code". The **start** TAC is the first TAC in the range. The **end** TAC is the last TAC in the range.

---

### Usage Guidelines

Use this command to enter up to 20 IMEI-TAC value ranges. Ranges can be overlapping.

The TAC, the first eight digits of the 15-digit IMEI or 16-digit IMEI-SV, identifies the equipment manufacturer, the wireless device type and the model number (if there is one); for example, TAC of 35201906 identifies an Apple mobile phone. Defining ranges would enable carriers to select operator policies for call handling based on multiple device types.

### Example

The following command defines a TAC range to be added to the IMEI-TAC group:

```
tac-range from 23456789 to 23456889
```

■ tac-range