



# show ipv6

This chapter describes the outputs of the **show ipv6** command.

- [show ipv6 interface summary, on page 1](#)
- [show ipv6 neighbors, on page 2](#)
- [show ipv6 pool summary, on page 3](#)
- [show ipv6 pool verbose, on page 4](#)
- [show ipv6 route, on page 5](#)

## show ipv6 interface summary

*Table 1: show ipv6 interface summary Command Output Descriptions*

Field	Description
Intf name	Interface name
Intf Type	Interface type
Description	
Router Advertisement	Displays whether the system is sending router advertisements. Options are either enabled or disabled.
IP State	Displays the IP state (UP/DOWN) and binding detail
MTU	The subscriber's Maximum Transmission Unit (MTU) size in octets.
MRU	The subscriber's Maximum Receive Unit (MRU) size in octets.
IPv6 Link-Local Address:	Displays the IPv6 link-local address
IPv6 Global Unicast Address:	Displays the ipv6 Global Unicast Address address

# show ipv6 neighbors

Table 2: show ipv6 neighbors Command Output Descriptions

Field	Description
Address	IPv6 address from table
Type	Interface type: <ul style="list-style-type: none"><li>• Broadcast (Ethernet)</li><li>• Loopback</li></ul>
Link address	MAC address
Flags	One of the following flag codes: <ul style="list-style-type: none"><li>• I = Incomplete</li><li>• R = Reachable</li><li>• M = Permanent</li><li>• S = Stale</li><li>• D = Delay</li><li>• P = Probe</li><li>• F = Failed</li></ul>
Interface	Interface name

# show ipv6 pool summary

Table 3: show ipv6 pool summary Command Output Descriptions

Field	Description
Type	<p>Identifies the type of IP address pool.</p> <p>(P) - Public: Indicates that the pool is comprised of public IP addresses.</p> <p>(R) - Private: Indicates that the pool is comprised of private IP addresses.</p> <p>(S) - Static: Indicates that the pool is comprised of statically assigned IP addresses.</p> <p>(E) - Resource: Indicates that the pool is comprised of resource IP addresses.</p> <p>(N) - NAT: Indicates that the pool is comprised of NAT IP addresses.</p>
State	<p>Identifies the state of the IP address pool.</p> <p>(G) - Good: Indicates that the pool is ready to provide addresses.</p> <p>(D) - Pending Delete: Indicates that the pool is in the process of being deleted.</p> <p>(R) - Resizing: Indicates that the pool is in the process of being resized.</p> <p>(I) - Inactive: Indicates that the pool is not being used.</p>
Priority	Specifies the priority use of a public or private pool. Pools with lower priority numbers are used first.
Busyout	Indicates whether or not the pool has been configured for busyout.
Pool Name	Identifies the name of the IP address pool.
Start Prefix	Identifies the starting IPv6 prefix of the pool.
End Prefix	Identifies the ending IPv6 prefix of the pool.
Used	Specifies the number of IP addresses currently in use.
Avail	Specifies the number of IP addresses currently available for use.
Total Pool Count	Specifies the total number of IP address pools in the summary.

# show ipv6 pool verbose

Table 4: show ip pool verbose Command Output Descriptions

Field	Description
Pool Name	Name of the IPv6 pool.
Group Name	Identifies the group to which the IP pool belongs.
Pool Type	Specifies the Type of IPv6 pool (Public, Private, Static, Resource) and its Priority (0 = highest, 10 = lowest).
Pool Status	Identifies the status of the group.  Good: Indicates that the pool is ready to provide addresses.  Pending Delete: Indicates that the pool is in the process of being deleted.  Resizing: Indicates that the pool is in the process of being resized.  Inactive: Indicates that the pool is not being used.
Start Prefix	Identifies the starting prefix of the pool.
End Prefix	Identifies the ending prefix of the pool.
Total Prefix Used Prefix Free Prefix	Total number of IPv6 prefixes with Used and Free sub-categories.
Pool Address Type	Type of IPv6 address pool.
Configured Prefix	
Busy-Out Range	Range of IPv6 addresses that have been busied out.
Total Busy-Out usage	
Used Free	Number of busy-out ranges currently being Used or Free.
Nexthop Forwarding Address	Identifies the IP address of the next hop gateway where a subscriber that is assigned an IP address from this pool is forwarded.  Status = Enabled or Disabled
Suppress-Switchover-ADVS	Identifies if the ability to suppress corresponding gratuitous ARP generation when a line card switchover occurs is enabled or disabled for this pool.  Status = Enabled or Disabled

Field	Description
Allow-Static-Allocation	Indicates whether IP pool configured to allow static allocation of IP address or not. Status = Enabled or Disabled
Duplicate-Addr-Detection	Indicates whether or not a unicast IPv6 address will initiate an internal test for the uniqueness of its address using ICMPv6 type 135 and 136 messages. Status = Enabled or Disabled
Group Available Threshold Clear	Specifies the low threshold IP pool utilization percentage that must be met or passed within the polling interval to generate an alert or alarm.  Clear: Specifies the high threshold IP pool utilization percentage that maintains a previously generated alarm condition. If the utilization percentage rises above the high threshold within the polling interval, a clear alarm will be generated. Status = Enabled or Disabled
Pool-Free Threshold Clear	Specifies the low threshold IP pool utilization percentage that must be met or exceeded within the polling interval to generate an alert or alarm.  Clear: Specifies the high threshold IP pool utilization percentage that maintains a previously generated alarm condition. If the utilization percentage rises above the high threshold within the polling interval, a clear alarm will be generated. Status = Enabled or Disabled
Pool-Used Threshold Clear	Specifies the high threshold IP pool utilization percentage that must be met or exceeded within the polling interval to generate an alert or alarm.  Clear: Specifies the low threshold IP pool utilization percentage that maintains a previously generated alarm condition. If the utilization percentage falls beneath the low threshold within the polling interval, a clear alarm will be generated. Status = Enabled or Disabled

## show ipv6 route

Table 5: show ipv6 route Command Output Descriptions

Field	Description
Destination	Designating ipv6 address prefix/length

Field	Description
Next hop	Address of the directly connected next hop interface
Protocol	Connected Unconnected
Prec	Number of precedence bits set
Cost	Number of router hops to destination address
Interface	Name of the next hop interface
Total Route Count	Total number of routes Number connected Number of static routes