



## Multiple Authentications for a Client

- [Information About Multiple Authentications for a Client, on page 1](#)
- [Configuring Multiple Authentications for a Client, on page 2](#)
- [Verifying Multiple Authentication Configurations, on page 8](#)

## Information About Multiple Authentications for a Client

Multiple Authentication feature is an extension of Layer 2 and Layer 3 security types supported for client join.



**Note** You can enable both L2 and L3 authentication for a given SSID.



**Note** The Multiple Authentication feature is applicable for regular clients only.

## Information About Supported Combination of Authentications for a Client

The Multiple Authentications for a Client feature supports multiple combination of authentications for a given client configured in the WLAN profile.

The following table outlines the supported combination of authentications:

Layer 2	Layer 3	Supported
MAB	CWA	Yes
MAB Failure	LWA	Yes
802.1X	CWA	Yes
PSK	CWA	Yes
iPSK + MAB	CWA	Yes
iPSK	LWA	No

MAB Failure + PSK	LWA	No
MAB Failure + PSK	CWA	No

From 16.10.1 onwards, 802.1X configurations on WLAN support web authentication configurations with WPA or WPA2 configuration.

The feature also supports the following AP modes:

- Local
- FlexConnect
- Fabric

## Configuring Multiple Authentications for a Client

### Configuring WLAN for 802.1X and Local Web Authentication (GUI)

#### Procedure

---

- Step 1** Choose Configuration > Tags & Profiles > WLANs.
  - Step 2** Select the required WLAN from the list of WLANs displayed.
  - Step 3** Choose Security > Layer2 tab.
  - Step 4** Select the security method from the Layer 2 Security Mode drop-down list.
  - Step 5** In the Auth Key Mgmt, check the 802.1x check box.
  - Step 6** Check the MAC Filtering check box to enable the feature.
  - Step 7** After MAC Filtering is enabled, from the Authorization List drop-down list, choose an option.
  - Step 8** Choose Security > Layer3 tab.
  - Step 9** Check the Web Policy check box to enable web authentication policy.
  - Step 10** From the Web Auth Parameter Map and the Authentication List drop-down lists, choose an option.
  - Step 11** Click Update & Apply to Device.
- 

### Configuring WLAN for 802.1X and Local Web Authentication (CLI)

#### Procedure

---

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b> <b>Example:</b> <pre>Device# configure terminal</pre>	Enters global configuration mode.

	Command or Action	Purpose
<b>Step 2</b>	<b>wlan profile-name wlan-id SSID_Name</b> <b>Example:</b> <pre>Device(config)# wlan wlan-test 3 ssid-test</pre>	Enters WLAN configuration sub-mode. <ul style="list-style-type: none"> <li>• <i>profile-name</i>: Profile name of the configured WLAN.</li> <li>• <i>wlan-id</i>: Wireless LAN identifier. Range is from 1 to 512.</li> <li>• <i>SSID_Name</i>: SSID that can contain 32 alphanumeric characters.</li> </ul> <p><b>Note</b> If you have already configured this command, enter the <b>wlan profile-name</b> command.</p>
<b>Step 3</b>	<b>security dot1x authentication-list auth-list-name</b> <b>Example:</b> <pre>Device(config-wlan)# security dot1x authentication-list default</pre>	Enables security authentication list for dot1x security. The configuration is similar for all dot1x security WLANs.
<b>Step 4</b>	<b>security web-auth</b> <b>Example:</b> <pre>Device(config-wlan)# security web-auth</pre>	Enables web authentication.
<b>Step 5</b>	<b>security web-auth authentication-list authenticate-list-name</b> <b>Example:</b> <pre>Device(config-wlan)# security web-auth authentication-list default</pre>	Enables authentication list for dot1x security.
<b>Step 6</b>	<b>security web-auth parameter-map parameter-map-name</b> <b>Example:</b> <pre>Device(config-wlan)# security web-auth parameter-map WLAN1_MAP</pre>	Maps the parameter map. <p><b>Note</b> If a parameter map is not associated with a WLAN, the configuration is considered from the global parameter map.</p>
<b>Step 7</b>	<b>no shutdown</b> <b>Example:</b> <pre>Device(config-wlan)# no shutdown</pre>	Enables the WLAN.

**Example**

```
wlan wlan-test 3 ssid-test
  security dot1x authentication-list default
  security web-auth
  security web-auth authentication-list default
```

```
security web-auth parameter-map WLAN1_MAP
no shutdown
```

## Configuring WLAN for Preshared Key (PSK) and Local Web Authentication (GUI)

### Procedure

---

- Step 1** Choose Configuration > Tags & Profiles > WLANs.
  - Step 2** Select the required WLAN.
  - Step 3** Choose Security > Layer2 tab.
  - Step 4** Select the security method from the **Layer 2 Security Mode** drop-down list.
  - Step 5** In the Auth Key Mgmt, uncheck the **802.1x** check box.
  - Step 6** Check the **PSK** check box.
  - Step 7** Enter the **Pre-Shared Key** and choose the PSK Format from the **PSK Format** drop-down list and the PSK Type from the **PSK Type** drop-down list.
  - Step 8** Choose Security > Layer3 tab.
  - Step 9** Check the **Web Policy** checkbox to enable web authentication policy.
  - Step 10** Choose the Web Auth Parameter Map from the **Web Auth Parameter Map** drop-down list and the authentication list from the **Authentication List** drop-down list.
  - Step 11** Click **Update & Apply to Device**.
- 

## Configuring WLAN for Preshared Key (PSK) and Local Web Authentication

### Procedure

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 2</b>	<b>wlan profile-name wlan-id SSID_Name</b> <b>Example:</b> Device(config)# <b>wlan wlan-test 3 ssid-test</b>	Enters WLAN configuration sub-mode. <ul style="list-style-type: none"> <li>• <i>profile-name</i>- Is the profile name of the configured WLAN.</li> <li>• <i>wlan-id</i> - Is the wireless LAN identifier. Range is from 1 to 512.</li> <li>• <i>SSID_Name</i> - Is the SSID which can contain 32 alphanumeric characters.</li> </ul>

	<b>Command or Action</b>	<b>Purpose</b>
		<b>Note</b> If you have already configured this command, enter <b>wlan profile-name</b> command.
<b>Step 3</b>	<b>security wpa psk set-key ascii/hex key password</b>  <b>Example:</b> Device(config-wlan)# <b>security wpa psk set-key ascii 0 PASSWORD</b>	Configures the PSK shared key.
<b>Step 4</b>	<b>no security wpa akm dot1x</b>  <b>Example:</b> Device(config-wlan)# <b>no security wpa akm dot1x</b>	Disables security AKM for dot1x.
<b>Step 5</b>	<b>security wpa akm psk</b>  <b>Example:</b> Device(config-wlan)# <b>security wpa akm psk</b>	Configures the PSK support.
<b>Step 6</b>	<b>security web-auth</b>  <b>Example:</b> Device(config-wlan)# <b>security web-auth</b>	Enables web authentication for WLAN.
<b>Step 7</b>	<b>security web-auth authentication-list authenticate-list-name</b>  <b>Example:</b> Device(config-wlan)# <b>security web-auth authentication-list webauth</b>	Enables authentication list for dot1x security.
<b>Step 8</b>	<b>security web-auth parameter-map parameter-map-name</b>  <b>Example:</b> (config-wlan)# <b>security web-auth parameter-map WLAN1_MAP</b>	Configures the parameter map.  <b>Note</b> If parameter map is not associated with a WLAN, the configuration is considered from the global parameter map.

**Example**

```
wlan wlan-test 3 ssid-test
  security wpa psk set-key ascii 0 PASSWORD
  no security wpa akm dot1x
  security wpa akm psk
  security web-auth
  security web-auth authentication-list webauth
  security web-auth parameter-map WLAN1_MAP
```

## Configuring WLAN for PSK or Identity Preshared Key (iPSK) and Central Web Authentication (GUI)

### Procedure

- 
- Step 1** Choose Configuration > Tags & Profiles > WLANs.
- Step 2** Select the required WLAN.
- Step 3** Choose Security > Layer2 tab.
- Step 4** Select the security method from the **Layer 2 Security Mode** drop-down list.
- Step 5** In the **Auth Key Mgmt**, uncheck the **802.1x** check box.
- Step 6** Check the **PSK** check box.
- Step 7** Enter the **Pre-Shared Key** and choose the PSK Format from the **PSK Format** drop-down list and the PSK Type from the **PSK Type** drop-down list.
- Step 8** Check the **MAC Filtering** check box to enable the feature.
- Step 9** With MAC Filtering enabled, choose the Authorization List from the **Authorization List** drop-down list.
- Step 10** Choose Security > Layer3 tab.
- Step 11** Check the **Web Policy** checkbox to enable web authentication policy.
- Step 12** Choose the Web Auth Parameter Map from the **Web Auth Parameter Map** drop-down list and the authentication list from the **Authentication List** drop-down list.
- Step 13** Click **Update & Apply to Device**.
- 

## Configuring WLAN for PSK or Identity Preshared Key (iPSK) and Central Web Authentication

### Configuring WLAN

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b>  <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 2</b>	<b>wlan profile-name wlan-id SSID_Name</b>  <b>Example:</b> Device(config)# <b>wlan wlan-test 3 ssid-test</b>	Enters WLAN configuration sub-mode.  <ul style="list-style-type: none"> <li>• <i>profile-name</i> - Is the profile name of the configured WLAN.</li> <li>• <i>wlan-id</i> - Is the wireless LAN identifier. Range is from 1 to 512.</li> </ul>

	<b>Command or Action</b>	<b>Purpose</b>
		<ul style="list-style-type: none"> <li>• <b>SSID_Name</b> - Is the SSID which can contain 32 alphanumeric characters.</li> </ul> <p><b>Note</b> If you have already configured this command, enter <b>wlan profile-name</b> command.</p>
<b>Step 3</b>	<b>no security wpa akm dot1x</b>  <b>Example:</b> Device(config-wlan)# no security wpa akm dot1x	Disables security AKM for dot1x.
<b>Step 4</b>	<b>security wpa psk set-key ascii/hex key password</b>  <b>Example:</b> Device(config-wlan)# security wpa psk set-key ascii 0 PASSWORD	Configures the PSK AKM shared key.
<b>Step 5</b>	<b>mac-filtering auth-list-name</b>  <b>Example:</b> Device(config-wlan)# mac-filtering test-auth-list	Sets the MAC filtering parameters.

**Example**

```
wlan wlan-test 3 ssid-test
  no security wpa akm dot1x
  security wpa psk set-key ascii 0 PASSWORD
  mac-filtering test-auth-list
```

**Applying Policy Profile to a WLAN****Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 2</b>	<b>wireless profile policy policy-profile-name</b>  <b>Example:</b> Device(config)# wireless profile policy policy-iot	Configures the default policy profile.

## Verifying Multiple Authentication Configurations

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 3</b>	<b>aaa-override</b>  <b>Example:</b> Device(config-wireless-policy)# <b>aaa-override</b>	Configures AAA override to apply policies coming from the AAA or ISE servers.
<b>Step 4</b>	<b>nac</b>  <b>Example:</b> Device(config-wireless-policy)# <b>nac</b>	Configures NAC in the policy profile.
<b>Step 5</b>	<b>no shutdown</b>  <b>Example:</b> Device(config-wireless-policy)# <b>no shutdown</b>	Shutdown the WLAN.
<b>Step 6</b>	<b>end</b>  <b>Example:</b> Device(config-wireless-policy)# <b>end</b>	Returns to privileged EXEC mode.

### Example

```
wireless profile policy policy-iot
  aaa-override
  nac
  no shutdown
```

# Verifying Multiple Authentication Configurations

### Layer 2 Authentication

After L2 authentication (Dot1x) is complete, the client is moved to *Webauth Pending* state.

To verify the client state after L2 authentication, use the following commands:

```
Device# show wireless client summary
Number of Local Clients: 1
MAC Address AP Name WLAN State Protocol Method Role
-----
58ef.68b6.aa60 ewlc1_ap_1 3 Webauth Pending 11n(5) Dot1x Local
Number of Excluded Clients: 0

Device# show wireless client mac-address <mac_address> detail
Auth Method Status List

Method: Dot1x
Webauth State: Init
Webauth Method: Webauth
Local Policies:
Service Template: IP-Adm-V6-Int-ACL-global (priority 100)
```

```

URL Redirect ACL: IP-Adm-V6-Int-ACL-global
Service Template: IP-Adm-V4-Int-ACL-global (priority 100)
URL Redirect ACL: IP-Adm-V4-Int-ACL-global
Service Template: wlan_svc_default-policy-profile_local (priority 254)
Absolute-Timer: 1800
VLAN: 50

Device# show platform software wireless-client chassis active R0

      ID   MAC Address       WLAN   Client      State
-----
0xa00000003      58ef.68b6.aa60     3          L3        Authentication

Device# show platform software wireless-client chassis active F0

      ID   MAC Address       WLAN   Client      State   AOM ID      Status
-----
0xa00000003      58ef.68b6.aa60     3          L3        Authentication.    730.
Done

Device# show platform hardware chassis active qfp feature wireless wlclient cpp-client
summary

Client Type Abbreviations:
RG - REGULAR     BLE - BLE
HL - HALO        LI - LWFL INT

Auth State Abbreviations:
UK - UNKNOWN      IP - LEARN      IP IV - INVALID
L3 - L3 AUTH RN - RUN

Mobility State Abbreviations:
UK - UNKNOWN      IN - INIT
LC - LOCAL         AN - ANCHOR
FR - FOREIGN       MT - MTE
IV - INVALID

EoGRE Abbreviations:
N - NON EOGRE Y - EOGRE

      CPP IF_H   DP IDX       MAC Address       VLAN   CT   MCVL AS MS E   WLAN      POA
-----
0X49      0XA0000003      58ef.68b6.aa60     50     RG      0   L3 LC N wlan-test 0x90000003

Device# show platform hardware chassis active qfp feature wireless wlclient datapath summary
Vlan   DP IDX       MAC Address       VLAN   CT   MCVL AS MS E   WLAN      POA
-----
0X49      0xa0000003      58ef.68b6.aa60     50     RG      0   L3 LC N wlan-test 0x90000003

```

### Layer 3 Authentication

Once L3 authentication is successful, the client is moved to *Run* state.

To verify the client state after L3 authentication, use the following commands:

```
Device# show wireless client summary
```

```

Number of Local Clients: 1
MAC Address  AP Name  WLAN  State  Protocol  Method  Role
-----
58ef.68b6.aa60  ewlc1_ap_1  3      Run     11n(5)  Web Auth  Local
Number of Excluded Clients: 0

```

## Verifying Multiple Authentication Configurations

```

Device# show wireless client mac-address 58ef.68b6.aa60 detail

Auth Method Status List

Method: Web Auth
Webauth State: Authz
Webauth Method: Webauth
Local Policies:
Service Template: wlan_svc_default-policy-profile_local (priority 254)
Absolute-Timer: 1800
VLAN: 50

Server Policies:

Resultant Policies:
VLAN: 50
Absolute-Timer: 1800

Device# show platform software wireless-client chassis active R0

ID      MAC Address      WLAN     Client State
-----
0xa0000001 58ef.68b6.aa60      3        Run

Device# show platform software wireless-client chassis active f0

ID      MAC Address      WLAN     Client State   AOM ID.   Status
-----
0xa0000001 58ef.68b6.aa60.    3        Run          11633     Done

Device# show platform hardware chassis active qfp feature wireless wlclient cpp-client summary

Client Type Abbreviations:
RG - REGULAR    BLE - BLE
HL - HALO       LI - LWFL INT

Auth State Abbreviations:
UK - UNKNOWN    IP - LEARN     IP IV - INVALID
L3 - L3 AUTH RN - RUN

Mobility State Abbreviations:
UK - UNKNOWN      IN - INIT
LC - LOCAL        AN - ANCHOR
FR - FOREIGN      MT - MTE
IV - INVALID

EoGRE Abbreviations:
N - NON EOGRE Y - EOGRE

CPP IF_H      DP IDX      MAC Address      VLAN   CT   MCVL AS MS E      WLAN      POA
-----
0X49        0XA0000003    58ef.68b6.aa60  50     RG   0    RN LC N wlan-test 0x90000003

Device# show platform hardware chassis active qfp feature wireless wlclient datapath summary

Vlan      pal_if_hdl      mac            Input Uidb      Output Uidb
-----
50        0xa0000003     58ef.68b6.aa60    95929           95927

```

## Verifying PSK+Webauth Configuration

```

Device# show wlan summary

Load for five secs: 0%/0%; one minute: 0%; five minutes: 0%
Time source is NTP, 12:08:32.941 CEST Tue Oct 6 2020

```

Number of WLANs: 1

ID	Profile Name	SSID	Status	Security
----	--------------	------	--------	----------

23	Gladius1-PSKWEBAUTH	Gladius1-PSKWEBAUTH	UP	[WPA2] [PSK] [AES], [Web Auth]
----	---------------------	---------------------	----	--------------------------------

## Verifying Multiple Authentication Configurations