cisco.



CUWN 8.1 WLC and FC AP - EoGRE Tunnel Gateway Deployment Guide

CUWN 8.1 WLC and FC AP - EoGRE Tunnel Gateway Deployment Guide 2 WLC EoGRE Tunneling 2 Supported Controller and APs 3 EoGRE Tunnels System Design Options 4 Design 1: WLC based EoGRE Tunnel 4 Installing WLC EoGRE 7 Configuring WLC EoGRE tunnel 9 Typical Deployment: WLC EoGRE Topology 14 Design 2: FlexConnect AP based EoGRE Tunnel 19 Show Commands 22 Example Configuration of the EoGRE Feature 23 References 27 Revised: September 22, 2016,

CUWN 8.1 WLC and FC AP - EoGRE Tunnel Gateway Deployment Guide



WLC EoGRE Tunneling

Ethernet over GRE (EoGRE) is a new aggregation solution for aggregating Wi-Fi traffic from hotspots. This solution enables customer premises equipment (CPE) devices to bridge the Ethernet traffic coming from an end host, and encapsulate the traffic in Ethernet

packets over an IP GRE tunnel. When the IP GRE tunnels are terminated on a service provider broadband network gateway, the end host's traffic is terminated and subscriber sessions are initiated for the end host.



Benefits of Tunneling in General

- Client can maintain IP address and policy across heterogeneous access networks with different technologies and/or vendors.
- Bypass MAC address scaling limitation of the L2 switch connecting to the WLC.
- Lawful Intercept (LI)

The EoGRE Tunneling offers the following benefits for mobile operators:

- Reduces network congestion by reducing OpEx and increasing network efficiency by offloading 3G and 4G traffic.
- Provides access to 3G and 4G core in spite of a lack of weak cell signal, leading to subscriber retention.
- Lowers CapEx on per user basis or bandwidth basis in dense metro environments.

The EoGRE tunneling offers the following benefits for wireline and Wi-Fi operators:

- Provides WiFi security and subscriber control.
- · Delivers scalable, manageable, and secure wireless connectivity.
- Enables new revenue-sharing business models.
- Delivers a WiFi platform that offers new location-based services.

The EoGRE tunneling offers the following benefits for subscribers:

- Provides enhanced quality of experience to subscribers on WiFi networks.
- · Provides unified billing across access networks.
- Provides mobility across radio access technologies-3G or 4G to WiFi and WiFi to WiFi.
- Provides multiple options within the Wi-Fi platform, thereby enabling location-based services.

Supported Controller and APs

- Cisco 5500 series, WiSM-2, 7500, and 8500 series wireless LAN controller.
- Cisco WLC 8.1 supported access points—3700, 2700, 1700, 1260, 1140, 1600, 3600, 2600, 2700, 702i, 3500, 702w, 1042N, 801, 1552, 1532, 1572.

EoGRE Tunnels System Design Options

Design 1: WLC based EoGRE Tunnel

- CAPWAP Control Path (AP-WLC)
- CAPWAP Data Path (AP-WLC)
- EoGRE Data Flow (WLC-TGW)

In this design model, a tunnel gets generated from WLC to the tunnel gateway such as ASR 1000. In release 8.1 and above, controller supports up to 10 tunnel gateways and 10 domains. Each of the 10 EoGRE Profiles can be configured with up to 16 rules. When realms are configured, it will be a user name followed by @. Realm is a string after @, for example, user_name@realm. Two or more tunnels can be configured for redundancy, so that when the primary or active tunnel fails, the secondary or standby tunnel will take over the operation of the EoGRE tunnel. Intra-controller and Inter-controller mobility is also supported with the EoGRE tunnel configuration.



The WLC in release 8.1 supports two tunnel type configurations on the northbound interface:

- 1 IP/GRE as defined in PMIPv6 (RFC 5213) L3
- 2 Ethernet over GRE L2



In this deployment guide, only EoGRE tunnel is discussed.

Only one type of tunnel is supported per WLAN. EoGRE is supported on either open or 802.1x based WLANs. Tunneled clients support EAP-SIM or EAP-AKA mode only. Other authentication modes are not supported by the tunneled clients.

When open SSID WLAN is used, either all local/simple or all tunneled clients are supported but cannot be mixed on the same WLAN. However, 802.1x authenticated simple or tunneled EoGRE clients are supported on the same WLAN.

Based on authentication, clients will be separated into local or tunneled mode.

The WLC supports two types of user's traffic such as Remote-Tunneled and Local on the same WLAN.

Local users traffic is defined as traffic that is locally bridged by the WLC.

Remote-Tunneled user traffic is defined as traffic of remote-tunnel users and is tunneled by the WLC to a TGW.

AAA override for EoGRE users is supported. Tunnel gateway can also act as AAA proxy.

If AAA Override is enabled on the controller for EoGRE EAP authenticated clients:

- WLC parses Access Accept and looks for MPC-Protocol-Type, such as EoGRE, GTPv2 or PMIPv6.
- If the Protocol-Type AVP exists, WLC looks for all parameters related to that tunnel-type. The static profile is ignored and the AAA provided parameters are used to setup tunnel.
- If AVP is not present, WLC uses static profile on WLC to determine tunnel type based on the realm extracted from user name.
- If some of the parameters are not present, the authentication fails. For example, if everything is present except T-GW IP, then the client authentication fails.
- If the MPC-Protocol-Type is None, then it will be simple IP.

Some of the attributes that can be returned by the AAA server are: *User-Name, Calling-Station-Id, gw-domain-name, mn-service, cisco-mpc-protocol-interface, and eogre_vlan_id.*

Redundancy of the EoGRE Tunnels

Two or more tunnels can be configured for redundancy, so that when the primary or active tunnel fails, the secondary or standby tunnel will take over the operation of the EoGRE tunnel. Keep-alive messages are sent periodically and the periodicity is configurable, that is, how many keep-alives can be missed before tunnel is considered as down. This is a global command and is applicable for all types of tunnels. In EoGRE tunnels design, DTLS ICMP packets are sent to the tunnel gateway. When EoGRE tunnel is created, ICMP echo request packet is sent to tunnel gateway. After receiving, ICMP echo response is sent back updating the tunnel gateway status.

When primary tunnel fails, the clients will de-authenticate and dis-associate from the primary WAG. If a secondary WAG is available, the controller will establish a secondary tunnel and reconnect to the secondary WAG, if the secondary tunnel is configured as shown in the following example. After secondary tunnel is established, the remote-client devices will re-authenticate and re-associate to WAG and will renew their IP addresses from the DHCP server on the secondary WAG. Clients will remain connected to the secondary WAG even if the primary WAG comes back on line.

ياليران.						Saye	Configuration	<u>P</u> ing Logout	Refresh
CISCO	MONITOR WLANS		R WIRE	LESS <u>S</u> EC	URITY MANAGER	MENT COMMA	NDS HELP	EEEDBACK	🔒 Home
Controller	EoGRE Gener	al							
General Inventory Interfaces Interface Groups Multicast Multicast	Apply I Interface Name Heartbeat Inter Max Heartbeat	val(Seconds) 60 Skip Count 3	anagemen)	ıt					
 Redundancy Internal DHCP Server 	Add New TGW				Add New Doma	nin			
Mobility Management Ports	TGW Name TGW IP Address	,			TGW-1	None	•		
▶ NTP	Add				Add	None	× .		
▶ CDP ▶ PMIPv6	TGW List				Domain List				
Tunneling	Name	IP Address	Status	Total Clients	Name	TGW-1	TGW-2	Active Gatewa	v
Profiles	ASR1K-PR	10.10.200.5	UP	0 🖬	domain4	ASR1K-PR	ASR1K-SEC	None	٥

EoGRE Tunnel DHCP Option-82 Design

The DHCP option-82 for EoGRE clients is inserted at the WLC in the bridge mode. The DHCP request packets from the clients are punted up to the controller as with any other DHCP packets. In the controller, based on the client type, the EoGRE clients are handled specially. For EoGRE clients, the DHCP option-82 configurations are picked from the Tunnel Profile data base. The global DHCP configurations have no impact on EoGRE clients.

The DHCP code in controller inserts DHCP option-82 parameters based on the tunnel profile configurations. Also, the EoGRE tunnel header information is added in the controller. The controller assembles the complete DHCP packet along with EoGRE tunnel headers and sends out on the tunnel.

The configuration commands gives flexibility to configuring option-82 format, delimiter character, remote-id, and circuit-id. The remote-id and circuit-id can be easily configured by providing up to a maximum of five different parameter-ids supported. The parameters entered will overwrite the previously entered configurations. If no parameters are input, the remote-id and circuit-id will be erased and no parameter for that field will be sent.

Configuration commands

```
config tunnel profile eogre <profile name> dhCP-Opt-82 enable / disable
config tunnel profile eogre <profile name> dhCP-Opt-82 format binary / ascii
config tunnel profile eogre <profile name> dhCP-Opt-82 delimiter <delimiter character>
config tunnel profile eogre <profile name> dhCP-Opt-82 remote-id <Paramater ID - 1> <Paramater ID - 2> <Paramater
ID - 3> <Paramater ID - 4> <Paramater ID - 5>
```

config tunnel profile eogre <profile name> dhCP-Opt-82 circuit-id <Paramater ID - 1> <Paramater ID - 2> <Paramater
ID - 3> <Paramater ID - 4> <Paramater ID - 5>



Figure 1: DHCP Option-82 Configuration From the GUI Interface

Installing WLC EoGRE

To install EoGRE, perform the following steps:

Procedure

- **Step 1** To configure EoGRE feature, create SSID.
- Step 2 From the WLC main menu, choose WLANs and click Go.

VLANs	None	[Change Filter] [C	lear Filter)		Create New - Go
WLAN ID	Туре	Profile Name	WLAN SSID	Admin S	Status Security Policies
1	WLAN	POD2-PSK	POD2-PSK	Enabled	[WPA2][Auth(PSK)]

Step 3 Create a WLAN with the naming convention, for example, POD4-EoGRE, and then click **Apply**.

WLANs > New		< Back Apply
Туре	WLAN -	
Profile Name	PODX-EoGRE	
SSID	PODX-EoGRE	
ID	2 -	

Step 4 On the **General** tab, map the WLAN to management interface.

IIIIII CISCO MONITO	R <u>W</u> LANS <u>C</u> ONTROLLE	Sage Configuration <u>P</u> ing Logout <u>R</u> efresh R WIRELESS <u>S</u> ECURITY M <u>A</u> NAGEMENT C <u>O</u> MMANDS HELP <u>F</u> EEDBACK d Home
WLANs	WLANs > Edit 'POD	4-EoGRE' < Back Apply
WLANS	General Securit	ty QoS Policy-Mapping Advanced
▶ Advanced	Profile Name Type SSID Status Security Policies Radio Policy Interface/Interface Group(G) Multicast Vlan Feature Broadcast SSID	POD4-EoGRE WLAN POD4-EoGRE C E Enabled None (Modifications done under security tab will appear after applying the changes.) All T management T Enabled F Enabled
	NAS-ID	POD4-WLC

Step 5 On the Security tab, set Layer 2 Security to None, and then click Apply.

ANS > E	dit 'PODX-	EoGRE'	< Back Apply
General	Security	QoS Policy-Mapping Advanced	
Layer 2	Layer 3	AAA Servers	
Layer 2	Security 1 N	one •	

Configuring WLC EoGRE tunnel



To configure the WLC EoGRE tunnel through GUI, perform the following steps:

Procedure

Step 1 Assign a tunnel gateway address:

- a) From WLC main menu, choose CONTROLLER > Tunneling > EoGRE.
- b) Set Heartbeat Interval to 60 seconds.
 The controller sends keep alive every 60 seconds. If the TGW does not reply after three keep alive pings, then controller decides that the TGW is down.
- c) Set Max Heartbeat Skip Count to 3.

The number of skip count decides how many times the TGW can skip consecutive replies, before the controller knows the TGW is down.

- d) Add TGW Name, for example, ASR1K.
- e) Add TGW IP Address, for example, 10.10.200.5.

սիսիս		Sage Configuration Eing Logout Befrest	•
CISCO	MONITOR WLANS CONTROLLER WIRELESS SECURITY	MANAGEMENT COMMANDS HELP EEEDBACK	
Controller	EoGRE General		*
General Inventory	Apply Default		
Interfaces Interface Groups Multicast Network Routes	Interface Name management Heartbeat Interval(Seconds) 60 Max Heartbeat Skip Count 3		
Redundancy Mobility	Add New TGW	Add New Domain Domain Name domain4	
Management	TGW Name ASR1K	TGW-1 None -	
▶ NTP	Add	TGW-2 None -	
+ CDP + PMIPv6	TGW List	Domain List	
* Tunneling	Name IP Address Status Total Clients	Active	
Profiles	ASR1K 10.10.200.5 UP 0	Name TGW-1 TGW-2 Gatewray	
► IPv6		domain4 ASR1K ASR1K	

- f) Add TGW IP Address, for example, 10.10.200.5.
- g) Add a Domain Name, for example, domain4.

h) Select the tunnel gateway TGW-1 as ASR1K, and click Add. If the tunnel gateway is reachable, then the state should show UP under the TGW List.

EoGRE General						
Interface Name	managem	ent				
Heartbeat Interval(Seconds)	60					
Max Heartbeat Skip Count	3					
Add How York			Add New Dor	main		
Add New IGW	-		Domain Nam	e	domain	4 🥌
TGW Name	19		TGW-1		ASR1K	
TGW IP Address			TGW-2		None	
Add			Add			
TGW List			Domain List			
Name IP Addr	ess Sta	tus Total Clients				
ASR1K 10.10.200.	S UP	0	Name	TGW-1	TGW-2	Gateway

Domain represents a virtual collection of one or more tunnels used for redundancy purposes. As mentioned previously, up to 16 tunnels can exist in one single domain. If one tunnel fails, the traffic will be redirected to another TGW.

- **Step 2** Create a tunnel profile:
 - a) From WLC main menu, choose **CONTROLLER > Tunneling > Profiles**.
 - b) Configure the **Profile Name**, for example, pod6, and click **Add**.

MONITOR	<u>₩</u> LANs	CONTROLLER	WIRELESS	SECURITY	MANAGEMENT	COMMANDS	HELP	EEDBACK
Profiles								
Profile Lis	st						Add	New
Profile Nar	me	WLAN ID	(Mapped)				Pro	ofile Name pod6
							Co	py of None 1
							Ade	4
							1	
	MONITOR Profiles Profile Nat	MONITOR WLANS Profiles Profile List Profile Name	MONITOR WLANS CONTROLLER Profile List Profile Name WLAN IOS	MONITOR WLANS CONTROLLER WIRELESS Profiles Profile List Profile Name WLAN IDs (Mapped)	MONITOR WLANS CONTROLLER WIRELESS SECURITY Profiles	MONITOR WLANS CONTROLLER WIRELESS SECURITY MANAGEMENT Profiles	MONITOR WLANS CONTROLLER WIRELESS SECURITY MANAGEMENT COMMANDS Profiles	MONITOR WLANS CONTROLLER WIRELESS SECURITY MANAGEMENT COMMANDS HELP Profiles Profile Name WLAN IDs (Mapped)

The profile name appears in the Profile List.

Profiles		
Profile List		
Profile Name	WLAN IDs (M	apped)
pod6	None	

- **Step 3** Define a tunnel profile rule:
 - a) Click the profile (pod6) that you created.
 - b) To map a specific realm to the profile, enter the realm name such as user_name@realm. To match any **Realm**, use * (* means all realms are accepted).
 - c) Choose Tunnel Type as EoGRE.
 - d) Set VLAN to 0.
 - e) Choose Gateway Domain as domain4.
 - f) Click Add.

1.0	Tunnal Drammatan	
ne	runner Parameters	
-		
Profile	le Name pod4	
Profil	le Name pod4	

g) Click **Apply** to apply the rule to the profile.

nnel Profile :	> Edit					< Back App
tule Tunne	Parameters					
Profile Name	pod 6					
Realm *		Tunnel	Type EoGRE 🗸 VI	LAN 0 Gatewa	y Domain domain4 🗸	
Realm		Tunnel Type	VLAN	Gateway Domain		

- **Step 4** Add / Associate the tunnel profile to WLAN:
 - a) From the WLC GUI, go to WLAN on which enabling EoGRE (POD4-EoGRE) tunnel.
 - b) On the Advanced tab, in the Tunneling area, select the Tunnel Profile as pod6.

ieneral	Security	QoS	Policy-Mapping	Advanced	-1-2
NAI-PAI		-	Endored		0
Central A	SSOC	01	Enabled	PMIP	
nc				PMIP Mobility Type	0
Lync Ser	ver	Disab	led :	PMIP NAI Type	Hexadecimal #
k				PMIP Profile	None +
Assisted	Roaming Predic	tion Optin	nization 🗌 Enabled	PMIP Realm	
Neighbor	List		Enabled	Universal AP Admin Support	
Neighbor	List Dual Band		Enabled	Universal AP Admin	2
				11v BSS Transition Support	
				BSS Transition	0
				Disassociation Imminent	0
				Disassociation Timer(0 to 3000 TBTT)	200
				Optimized Roaming Disassociation Tim	er(0 to 40 TBTT) 40
				Tunneling	
				Tunnel Profile	pod6 \$

Step 5 To verify if the tunnel is properly configured, from WLC main menu, choose CONTROLLER > Tunneling > Profiles and see if the profile name is set to the correct WLAN.
In this example, the ASR1K is pre-configured for EoGRE tunnel and a DHCP pool. For your reference, the tunnel configuration on ASR1K is shown below.

```
ip dhcp pool IPv4-EoGRE
network 10.55.55.0 255.255.255.0
default-router 10.55.55.1
dns-server 171.70.168.183
 domain-name cisco.com
 lease 0 0 10
interface Loopback0
ip address 11.11.11.11 255.255.255.255
interface Tunnel1
mac-address 0000.5e00.5213
 ip address 10.55.55.1 255.255.255.0
 no ip redirects
 load-interval 30
tunnel source GigabitEthernet0/0/0.200
tunnel mode ethernet gre ipv4
interface GigabitEthernet0/0/0
no ip address
negotiation auto
interface GigabitEthernet0/0/0.200
 encapsulation dot10 200
 ip address 10.10.200.5 255.255.255.0
```

Connect a wireless client to the SSID, for example, POD4-EoGRE. You get an IP address from 10.55.55.0 subnet, which is configured on the ASR1K.





You can also verify that the client is associated through EoGRE tunnel by running **show client detail** command on your POD WLC.

(POD2-WLC) >show client detail b8:f6:b1:11:7f:23	
Client MAC Address	b8:f6:b1:11:7f:23
Client Username	N/A
AP MAC Address	3c:ce:73:38:24:70
AP Name	POD2-AP3600
AP radio slot Id	1
Client State	Associated
Client User Group	
Client NAC 008 State	Access
Wireless LAN Id	2
wireless LAN Network Name (SSID)	PODX-EOGRE
wireless LAN Profile Name	PODX-EOGRE
Hotspot (802.11u)	Not Supported
BSSID	3c:ce:73:38:24:7e
Connected For	1363 secs
Channe1	36
IP Address	10.55.55.62
Policy Manager State	RUN
Policy Manager Rule Created	Yes
Audit Session ID	none
AAA Role Type	none
Local Policy Applied	none
IPv4 ACL Name	none
FlexConnect ACL Applied Status	Unavailable
IPv4 ACL Applied Status	Unavailable
IPv6 ACL Name	none
IPv6 ACL Applied Status	Unavailable
Layer2 ACL Name	none
Laver2 ACL Applied Status	Unavailable
client Type	EOGRE
EOGRE AAA MN SErvice	IPV4
EOGRE AAA NAI.	Unavailable
EOGRE AAA PGW Primary	10.10.200.5
EOGRE AAA PGW Secondary	Not contigured

Typical Deployment: WLC EoGRE Topology

In this typical EoGRE deployment configuration, two users MN1 and MN2 are connected to Realm @att.com and two other users MN3 and MN4 are connected to Realm @att.net. When the users MN1 and MN2 connect, they must be on the VLAN1 and TGW1 and users MN3 and MN4 must connect to VLAN2 and TGW2 as shown in the following figure. In this setup, two profiles with one realm in each are created and mapped to TGW1 and TGW2 accordingly in the same domain.



To configure WLC EoGRE, perform the following steps:

Procedure

Step 1 Create tunnel gateways and configure heartbeats:

- a) From WLC main menu, choose **CONTROLLER > Tunneling > EoGRE**.
- b) Set Heartbeat Interval to 60 seconds.
- c) Set Max Heartbeat Skip Count to 3.
- d) Set TGW-1 and TGW-2 with appropriate IP addresses.

alialo						Saye	Configura	tion <u>P</u> ing L	ogout <u>R</u> efresh
cisco	MONITOR WLAN		WIRELESS	SECURITY	MANAGEMENT	COMMANDS	HELP	EEEDBACK	🔒 <u>H</u> ome
Controller	EoGRE General								
General Inventory Interfaces Interface Groups Multicast	Apply De Interface Name Heartbeat Interva Max Heartbeat Sk	fault mane I(Seconds) 60 ip Count 3	gement						
 Redundancy Internal DHCP Server Mobility Management Ports NTP CDP 	Add New TGW TGW Name TGW IP Address Add TGW List	tgw2	-		Add New Doma Domain Name TGW-1 TGW-2 Add	dom) dom) tgw1 None	~		
PMIPv6 Tunneling EoGRE Profiles	Name tgw1	IP Address 9.9.89.100	Status DOWN 0	Total Clients	Name dom1	TGW-1	TGW	1-2 G	ctive ateway
▶ IPv6					and the			TROTT	-

To configure EoGRe heart-beat from CLI:

config tunnel eogre heart-beat interval 30
config tunnel eogre heart-beat max-skip-count 3
To configure EoGRE tunnel from CLI:
config tunnel eogre gateway add tgwl ipv4-address 9.9.89.100
config tunnel eogre gateway add tgw2 ipv4-address 9.9.90.100

Step 2 Configure EoGRE Tunnel Domain.

Figure 2: GUI configuration of Domain dom1 with tgw1 and tgw2.

Add New Di	omain		/		
Domain Na	ime	dom1	*		
TGW-1		None 💌		1	
TGW-2		None			
1011 -					
Add		tgw2	-		
Add Domain List	t TGW-1	tgw2			Active Gateway

To create tunnel domain from CLI:

config tunnel eogre domain create dom1
config tunnel eogre domain add dom1 tgw1
config tunnel eogre domain add dom1 tgw2

Step 3 Create profiles and add rules:

a) Configure a profile, for example, **prof-att**.

ululu cisco	MONITOR	<u>W</u> LANs		WIRELESS	SECURITY	MANAGEMENT	Sa <u>v</u> e Configur C <u>O</u> MMANDS	ation HELP	<u>Ping Logout</u>
Controlle Genera Invent Interfa Multica Networ Redund Redund Nobilit Manage Ports NTP CDP PMIPve CDP	er al ory acces acce Groups ast k Routes dancy y ement	Profi	les ile List le Name of1 of-att	WLAN ID None None	s (Mapped)	Add New Profile Copy o Add	Name prof-att		

b) From the WLC GUI, create realm att.com for VLAN1 and att.net for VLAN2 on domain dom1 and apply them to profile prof-att.

	nel Parameter	rs				
Profile Nam	e pro	of-att				
And a second sec				Contraction of the local data and the local data an		
Realm att.	net	Tunnel Type	Eogre 💟 VLA	N 2 G	ateway Domain	dom1 💌
Realm att.	net] Tunnel Type	Eogre VLA	N 2 G	ateway Domain	dom1 💌
Realm att. Add Realm	net Tunnel	Tunnel Type	Eogre VLA	N 2 G	ateway Domain nain	dom1 💌
Realm att. Add Realm att.com	net Tunnel EoGRE	Tunnel Type	Eogre VLA	N 2 G Gateway Dor dom1	ateway Domain nain	dom1 💌

To create profiles and realms from CLI:

	on VLAN 0.	
Note	* means wild car	d to catch everyone not belonging to any other rules; it is last in the order and will drop users
config	tunnel profile	rule add prof1 realm-filter * eogre vlan 0 dom1
config	tunnel profile	rule add prof-att realm-filter att.net eogre vlan 2 dom1
config	tunnel profile	rule add prof-att realm-filter att.com eogre vlan 1 dom1
config	tunnel profile	create prof-att

Step 4 Configure the tunnel parameters.

The following figure shows a sample configuration from GUI of tunnel parameters with AAA proxy GW enabled and and DHCP option-82 enabled.

	MONITOR WLANS CONTROLLER	WIRELESS SECURITY	MANAGEMENT COMMANDS HE	Saye Configuration Bing Logout Bel LP FEEDBACK ^ H	iresh ome
Controller General Inventory Interfaces Interface Groups Multicast Network Routes Redundancy Nobility Management Ports NTP CDP	Tunnel Profile > Edit Rule Tunnel Parameters EaGRE Gateway as AAA Proxy Gateway as Accounting Proxy DHCP Option 82 Pormat DHCP Option 82 Pormat DHCP Option 82 Delimiter Circuit-ID		Remote-ID	C Back Appl	
 PMIPv6 Tunneling TooRt Profiles IPv6 mDNS Advanced 	Fields Available	Fields Selected	Fields Available	Fields Selected	

To configure DHCP option82 from CLI:

config tunnel profile eogre prof-att DHCP-Opt-82 format Binary

config tunnel profile eogre prof-att DHCP-Opt-82 delimiter

config tunnel profile eogre prof-att DHCP-Opt-82 enable

config tunnel profile eogre prof-att DHCP-Opt-82 circuit-id ap-ethmac flex-group-name ap-group-name

config tunnel profile eogre prof1 DHCP-Opt-82 remote-id ap-name ap-location

To configure gateway as AAA proxy from CLI:

config tunnel profile eogre prof-att gateway-radius-proxy enable

config tunnel profile eogre prof-att gateway-radius-proxy accounting enable

Step 5 Map the profile to a WLAN.

Figure 3: Mapping the profile "prof-att" to WLAN

altala cisco	MONITOR WLANS CONTROLLER WIRELESS SECURITY MANAGE	MENT COMMANDS HELP EEEDBA	Sage Configuration Bing Logout Befre CK A Bon
WLANS WLANS WLANS	WLANs > Edit '5520-test' General Security QoS Policy-Mapping Advanced		< Back Apply
Advanced	Vian based Central Switching 21 Enabled Central DHCP Processing Enabled Override DNS Enabled NAT-PAT Enabled Central Assoc Enabled Lync Lync Server Disabled V	HTTP Profiling PHIP PHIP Mobility Type PHIP NAI Type PHIP Profile PHIP Realm Universal AP Admin Support Universal AP Admin Support	Mone •
	11k Assisted Roaming Prediction Optimization Neighbor List Brabled Neighbor List Brabled Neighbor List Doal Band	Inversa or Admin It v BSS Transition Support BSS Transition Disassociation Imminent Disassociation Timer(0 to 3000 TBTT) Optimized Roaming Disassociation Timer(0 to 40 TBTT) Tunneling Tunnel Profile	200 40 prof-att •

To map the profile to WLAN2 from CLI:

config wlan tunnel profile prof1 2 config wlan enable 2

Design 2: FlexConnect AP based EoGRE Tunnel

- CAPWAP Control Path (Flex AP-WLC)
- EoGRE Data Path (Flex AP-TGW)
- Once tunnel is established, data flows from FC AP directly to the TGW.

In this design, direct tunneling from the AP offers data and control planes separation from the controller and the AP. The central data throughput is limited only by the capacity of the core network with optimal data-path routing towards the core of the network. The inter/intra controller mobility is not supported but client can still roam in the same FlexConnect group in Locally Switched mode.



- FlexConnect AP EoGRE is supported on Open and 802.1x based WLANs.
- 802.1x authenticated "simple" and "tunneled" EoGRE clients are supported on the same WLAN.
- Based on authentication, clients are separated into local or tunneled mode.
- Tunneled clients support EAP-SIM or EAP-AKA modes.
- Open SSID WLAN supports either all local or all tunneled clients.
- AAA override for EoGRE users is supported.
- Tunnel GW can also act as AAA proxy.
- Flex Connect AP supports TGW failure detection and switch over to alternate TGW.
- TGW supports Fault Tolerance with Active/Standby mode.
- Inter and Intra Controller mobility is supported in connected FlexAP mode.
- In Stand-Alone mode, mobility supported only within FlexConnect group tunnel GW can be configured as AAA and Accounting proxy.
- Tunnel GW supports "Configurable" DHCP Option-82.

Basic Flex AP EoGRE Configuration

When configuring Flex AP with EoGRE tunnel:

- Same tunnel configurations apply to WLC or FC AP tunnels when profile is applied on the WLAN.
- When FC AP is in Locally Switched mode, the FC AP gateway tunnel automatically applies.
- Clients connected to Local Mode AP communicates through the WLC-TGW tunnel.

- Clients connected to FC AP communicates through the FC AP-TGW tunnel.
- Client selection is also impacted by the AAA or Profile override.



Typical Deployment: Flex Connect AP - EoGRE Topology

In this typical FC AP -EoGRE tunnel deployment configuration, two users MN1 and MN2 are connected to Realm @att.com and two other users MN3 and MN4 are connected to Realm @att.net. When users MN1 and MN2 connect, they should be on the VLAN1 and TGW1 and users MN3 and MN4 should connect to VLAN-2 and TGW2 as shown in the following figure. In this setup, two profiles with one realm in each will be created and mapped to TGW1 and TGW2 accordingly in the same domain. In this deployment scenario, the tunnel will be setup directly between FlexConnect AP in a Locally switched mode and TGW1 and TGW2; all data traffic will flow bypassing the controller.





In this configuration, EoGRE tunnel TGW, Domain, Profile Rules, and Realms are setup exactly in the same manner as in the deployment scenario with WLC-EoGRE. The only change is FC AP is setup in the Locally Switched mode.

1 Configure AP to FlexConnect Local Switching.



Note Only **FlexConnect Local Switching** option has to be configured on the FG AP or FC Group to enable FC AP-TGW tunnel. Other WLC EoGRE configurations will apply to FC AP-EoGRE settings.

Show Commands

Show Commands on WLC

```
Show tunnel eogre summary
show tunnel eogre gateway summary
show tunnel eogre domain summary
show tunnel profile summary
show tunnel profile detail <profile name>
show ap eogre domain <ap-name>
Show ap eogre gateway <ap-name>
```

Show Commands on AP

show dotll eogre-tunnel domain summary show dotll eogre-tunnel gateway summary show capwap reap associations show capwap client detailrcb

Example Configuration of the EoGRE Feature

CLI Summary Steps on ASR 1K

- 1 enable
- 2 configure terminal
- 3 interface interface-name
- 4 ip unnumbered loopback interface-name or ip address ip-address
- 5 tunnel source interface-type interface-number
- 6 (For simple IP mode) mac-address H.H.H
- 7 tunnel mode ethernet gre ipv4 or tunnel mode ethernet gre ipv6
- 8 (Optional) tunnel vlan vlan-id
- 9 end

Sample Configuration on ASR 1K

aaa new-model

```
!
```

aaa group server radius AAA_SERVER_CAR

```
server-private 5.3.1.76 auth-port 2145 acct-port 2146 key cisco
```

```
!
```

aaa authentication login default none

aaa authentication login ISG_PROXY_LIST group AAA_SERVER_CAR

aaa authorization network ISG_PROXY_LIST group AAA_SERVER_CAR

aaa authorization subscriber-service default local group AAA_SERVER_CAR

aaa accounting network PROXY_TO_CAR

action-type start-stop

group AAA_SERVER_CAR

```
!
```

aaa accounting network ISG_PROXY_LIST start-stop group AAA_SERVER_CAR

!

Intelligent Wireless Access Gateway Configuration Guide 46 OL-30226-06 Service Provider WiFi: Support for Integrated Ethernet Over GRE Example: Configuring the EoGRE Feature aaa server radius dynamic-author client 5.3.1.76 server-key cisco auth-type any ignore server-key !! ip dhcp excluded-address 172.16.254.254 ! ip dhcp pool ISG_SIMPLE_IP network 172.16.0.0 255.255.0.0 default-router 172.16.254.254 domain-name cisco.com ! policy-map type control EOGRE_L2_ISG class type control always event session-start 2 authorize aaa list ISG_PROXY_LIST password cisco identifier mac-address 4 set-timer IP UNAUTH TIMER 5 ! class type control always event service-start 1 service-policy type service identifier service-name 2 collect identifier nas-port ! ! interface Loopback0 ip address 9.9.9.9 255.255.255.255 interface GigabitEthernet1/0/0 ip address 192.168.0.9 255.255.255.0 negotiation auto ! interface GigabitEthernet1/0/0.778 description "to ASR5K GGSN" encapsulation dot1Q 778 ip address 172.16.199.9 255.255.255.0

!

interface Tunnel10 description "EoGRE Tunnel for Simple IP subscribers" mac-address 0000.5e00.5213 ip address 172.16.254.254 255.255.0.0 no ip redirects tunnel source 172.16.199.9 tunnel mode ethernet gre ipv4 service-policy type control EOGRE L2 ISG ip subscriber 12-connected initiator unclassified mac-address initiator dhcp interface Tunnel100 description "IPv4 EoGRE Tunnel for PMIP/GTP subscribers" ip unnumbered Loopback0 tunnel source GigabitEthernet1/0/0 tunnel mode ethernet gre ipv4 tunnel vlan 100 service-policy type control EOGRE_L2_ISG ip subscriber 12-connected initiator unclassified mac-address initiator dhcp ! interface Tunnel200 description "IPv6 EoGRE Tunnel for PMIP/GTP subscribers" ip unnumbered Loopback0 tunnel source 2001:161::9 tunnel mode ethernet gre ipv6 tunnel vlan 200 service-policy type control EOGRE L2 ISG ip subscriber 12-connected

initiator unclassified mac-address

initiator dhcp

!

mcsa

enable sessionmgr

!

ipv6 mobile pmipv6-domain D1 replay-protection timestamp window 255 lma LMA_5K Intelligent Wireless Access Gateway Configuration Guide OL-30226-06 47 Service Provider WiFi: Support for Integrated Ethernet Over GRE Example: Configuring the EoGRE Feature ipv4-address 192.168.199.1 ! ipv6 mobile pmipv6-mag M1 domain D1 sessionmgr role 3GPP address ipv4 9.9.9.9 interface Tunnel100 interface Tunnel200 lma LMA_5K D1 ipv4-address 192.168.199.1 encap gre-ipv4 ! ntp master ! gtp information-element rat-type wlan interface local GigabitEthernet1/0/0.778 apn 1 apn-name gtp.com ip address ggsn 172.16.199.1 fixed link-layer address 00ab.00cd.00ef default-gw 20.100.254.254 prefix-len 16 dns-server 20.100.254.254 dhcp-server 20.100.254.254 ! end You can use the following commands to check and show subscriber session information:

show ip dhcp sip statistics

show subscriber statistics show subscriber session show ipv6 mobile pmipv6 mag binding show gtp pdp-context all show interface tunnel-name

References

Refer to the Intelligent Wireless Access Gateway (IWAG) Configuration Guide.

© 2015 Cisco Systems, Inc. All rights reserved.



Americas Headquarters Cisco Systems, Inc. San Jose, CA 95134-1706 USA Asia Pacific Headquarters Cisco Systems (USA) Pte. Ltd. Singapore **Europe Headquarters** Cisco Systems International BV Amsterdam, The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.