



# Connecting a Connector to Cisco Catalyst 9300 Series Switches and Cisco Catalyst 9400 Series Switches Series

---

- [Connecting a Connector to Cisco Catalyst 9300 Series Switches and Cisco Catalyst 9400 Series Switches](#), on page 1

## Connecting a Connector to Cisco Catalyst 9300 Series Switches and Cisco Catalyst 9400 Series Switches

### Before you begin

- Deploy a Connector OVA and activate it using a token from Cisco Spaces.
- The IP address of a Cisco Catalyst 9300 Series Switches and Cisco Catalyst 9400 Series Switches that is reachable from the Cisco Spaces: Connector.
- Test the Netconf commands on the Cisco Catalyst 9300 Series Switches and Cisco Catalyst 9400 Series Switches

### SUMMARY STEPS

1. Log in to Cisco Spaces.
2. In the Cisco Spaces dashboard, choose **Setup > Wired Networks**.
3. From the **Step 3: Add Switches** area, click **Add Switch**.
4. From the **Add Switches** page, select the Connector, enter a name to identify the switch, the switch IP address. **Netconf username**, **Netconf password**, and click the checkbox to acknowledge that you have tested these commands on the switch.
5. Click **Test** to see if the connection to the switch.
6. Do one of the following:
  - Click **Save & Add Next Switch**
  - Click **Save & Close**

## DETAILED STEPS

- Step 1** Log in to Cisco Spaces.
- Step 2** In the Cisco Spaces dashboard, choose **Setup > Wired Networks**.
- Step 3** From the **Step 3: Add Switches** area, click **Add Switch**.




Figure 1:

- Step 4** From the **Add Switches** page, select the Connector, enter a name to identify the switch, the switch IP address. **Netconf username**, **Netconf password**, and click the checkbox to acknowledge that you have tested these commands on the switch.
- Step 5** Click **Test** to see if the connection to the switch.
- Step 6** Do one of the following:
- Click **Save & Add Next Switch**
  - Click **Save & Close**