

# **AMF** Authentication and GUTI Reallocation Configuration Control

- Feature Summary and Revision History, on page 1
- Feature Description, on page 1
- Feature Configuration, on page 3

## **Feature Summary and Revision History**

### **Summary Data**

#### Table 1: Summary Data

Applicable Products or Functional Area	AMF
Applicable Platforms	SMI
Feature Default Setting	Enabled – Always-on
Related Documentation	UE Configuration Management Procedures

### **Revision History**

#### **Table 2: Revision History**

Revision Details	Release
First introduced.	2022.01.0

## **Feature Description**

AMF supports the authentication activities and the GUTI (Globally Unique Temporary Identity) reallocation configuration control for call flows.

#### GUTI

GUTI is used to keep the subscriber's IMSI confidential. AMF allocates a GUTI to the UE. It's composed of PLMN ID, AMF ID, and TMSI. As it's a temporary identifier, its associations aren't fixed to any specific subscriber or mobile. A single 5G-GUTI is used to access the Security Context of 3GPP and non-3GPP technologies within the AMF.

#### **Supported Functions**

AMF supports the following functions:

- Authentication and GUTI reallocation counter maintained as per the UE. For each supported type, separate counters are maintained.
- Time reference per UE for network-initiated GUTI reallocation
- GUTI reallocation attempted as per the configuration for a specific time interval.
- Includes the new GUTI in either Registration Accept or Configuration Update Command NAS message
- AMF shows the allocated GUTI and the allocated time in the show subscriber command output.



Note

Collision of GUTI reallocation in Registration Accept or Configuration Update Command with other procedures isn't supported.

#### **Supported Scenarios**

This feature supports the following scenarios based on the UE on time and frequency of access attempts. These scenarios are part of the Registration and Service Request procedure:

- Selective authentication
- GUTI reallocation

The frequency supports access attempts per UE and not across UEs.

#### **Unsupported Scenarios**

The following scenario isn't supported:

- Authentication requirements dependent or based on EAP-AKA or EAPAKA' or EAPAKA Prime
- When the latest GUTI isn't acknowledged, the UE is paged simultaneously with the old and the new GUTI.



Note GUTI reallocation process takes place only for the successful procedure.


## **Feature Configuration**

To configure this feature, use the following configuration:

```
config
call-control-policy ccp_name
    authenticate registration-request type { frequency frequency_count |
  periodicity duration }
    no authenticate registration registration-request
    authenticate service-request type { frequency frequency_count |
  periodicity duration }
    no authenticate registration service-request
    authenticate all-events { frequency frequency_count | periodicity duration
  }
    no authenticate all-events
    guti-reallocation type { frequency frequency_count | periodicity duration
  }
    no guti-reallocation
    end
```

#### NOTES:

- call-control-policy ccp\_name—Specify the UE-specific name for call control policy. Must be a string.
- authenticate registration-request { normal | periodic | inter-rat | intra-rat }—Specify the required option to authenticate the registration process.
- registration-type normal Specify the initial registration details with locally allocated GUTI.
- authenticate service-request { data | signaling }—Specify the option to authenticate the service type for the service request.
- authenticate all-events Specify the option to authenticate all events. It's also the default or the fallback authentication option, when the configuration doesn't present for any type.
- guti-reallocation { periodic-registration | service-request }—Specify the options to authenticate the GUTI reallocation process.
- no authenticate { [registration-request ] | [service-request ] | [all-events ] | [guti-reallocation ] }—Specify the option for which the authentication isn't required.
- **frequency** *frequency\_count*—Specify the required frequency duration or count for authenticating each option. The frequency range is 0–256. The disabled value is 0.
- **periodicity** *duration*—Specify the time, period, or duration for authenticating the selected option. The periodicity duration range is 0–10800 (minutes). The disabled value is 0.



### **Configuration Example**

The following is an example configuration.

```
amf-global
  call-control-policy local
  guti-reallocation periodic-registration frequency 2 periodicity 1
  guti-reallocation service-request frequency 0 periodicity 1
  authenticate service-request signaling frequency 1 periodicity 20
  authenticate registration-request periodic frequency 1 periodicity 0
  end
```

### **Configuration Verification**

To verify the configuration:

show call-control-policy ccp\_name

5