

Overview



Note

The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

The Evolved Packet Core (EPC) network is evolving and moving toward Control User Plane Separation (CUPS) based architecture where User-Plane and Control-Plane are separate node for P-GW, S-GW, and TDF products. The User Plane and Control Plane combined together provide functionality of a node for other elements in the EPC network. However, keeping them separate has numerous advantages from the network point of view – support different scaling for Control-Plane and User-Plane, support more capacity on per session level in User-Plane, and so on.

This chapter highlights high-level details, call flows, and configurations related to the Sx Interface implementation for P-GW, S-GW, and SAEGW products.

- Product Description, on page 1
- How It Works, on page 1

Product Description


Sx is the interface between the Control-Plane and User-Plane in a split P-GW, S-GW, and TDF architecture in an Evolved Packet Core (EPC) that provides Packet Forwarding Control Protocol (PFCP) service. One of the main tasks of the Sx interface is to enable the Control-Plane function to instruct the User-Plane function about how to forward user data traffic.

How It Works

The following section provides a brief overview of the Sx service works.

Architecture

The following illustration provides a reference model in the case of separation between Control-Plane and User-Plane.





Note

- The -C or -U suffix appended to S2a, S2b, S5 and S8 existing reference points only indicate the Control-Plane and User-Plane components of those interfaces.
- The architecture only depicts the case when the Control-Plane and User-Plane functions of all S-GW, P-GW and TDF nodes are split. It also supports scenarios where the Control-Plane and User-Plane function of only one of these nodes is split while the Control-Plane and User-Plane function of the other interfacing node is not split. For example, it supports a scenario where the Control-Plane and User-Plane of the P-GW is split while that of the S-GW is not split. This split architecture of a node does not put any architectural requirements on the peer nodes with which it interfaces.
- TDF is an optional functional entity.

The following sections describe the services supported on the Sx Interface.

Sx Service

The Sx Service provides an interface mentioned as the following reference points:

- Sxa: Reference point between SGW-C and SGW-U.
- Sxb: Reference point between PGW-C and PGW-U.
- Sxc: Reference point between Traffic Detection Function-C (TDF-C) and TDF-U.

The Sx service is agnostic of the interface it supports. A single Sx service instance is capable of running on Sxa, Sxb, and Sxb interfaces. The Sx service runs in two different modes:

- Sx-Control instance
- Sx-Data instance

The Sx service is associated with the SAEGW service at the Control-Plane and User-Plane service at the User-Plane. There is one-to-one mapping of the Sx service with the Control-Plane and Data Plane.

The association of the SAEGW service occurs as follows:

```
saegw-service saegw-service
   associate sgw-service sgw-service
   associate pgw-service pgw-service
   associate gtpu-service control_gtpu up-tunnel
   associate sx-service sxc
```

The association of the User-Plane service occurs as follows:

```
user-plane-service user-plane-service
associate gtpu-service sx-gtpu-service pgw-ingress
associate gtpu-service sx-sgw_ingress_gtpu sgw-ingress
associate gtpu-service sx-sgw_egress_gtpu sgw-egress
associate gtpu-service control_gtpu cp-tunnel
associate sx-service sxu
```

At the Control-Plane for SAEGW service (legacy SAEGW Service), CUPS-enabled flag in EGTPC service determines whether SAEGW is CUPS enabled or not. If SAEGW service is CUPS enabled, then Sx service is a mandatory parameter for SAEGW service to start. Only having association at the SAEGW service does not make Sx a mandatory parameter for SAEGW service.

If Sx service is a mandatory parameter (because of CUPS-enabled flag), then Sx service stop and Sx IP address brings down the SAEGW service.

For information about configuring the Sx Service, see the "Configuring Sx Service" section.

Sx-u Interface

This section explains the interaction between the Sx-u Interface, User-Plane-service, and SAEGW-service.

Sx-u is the User-Plane interface over the Sxa and Sxb reference points. The protocol used on the Sx-u Interface is GTP-U. Both IPv4 and IPv6 transport is supported.

At the User-Plane, Sx-u service is a mandatory parameter for User-Plane service to start. Being a mandatory parameter, Sx-u Interface stops and Sx-u IP address brings down the User-Plane service.

The Control-Plane establishes one Sx-u tunnel per function or session as described in the section below.

Sx-u Tunnel per PDN session

Control-Plane establishes one Sx-u tunnel per PDN session for router advertisement and router solicitation messages.

In this scenario, Control-Plane uses the existing Sx tunnel per PDN (created during GTP-C initial attach procedure) for installing Packet Detection Rule (PDR) or Forwarding Action Rule (FAR) related to data forwarding between the Control-Plane and User-Plane functions on the User-Plane.

For information about configuring the Sx-u Interface, see the *Configuring Sx-u Interface* section.

Sx Demux

The Sx Demux provides session de-multiplexing functionality on the Data plane. One instance of Sx Demux is started per context. When implemented, the Sx Demux supports the following behavior:

- 1. Works as Sx Control-Plane Demux when implemented on the Control-Plane and supports handling of Node level messages such as Prime PDF Management Messages.
- 2. Works as Sx Data Plane Demux when implemented on the Data Plane and supports:

- Handling of Session level messages such as Session Establish Request.
- Handling of Session level messages such as Session Establish Request.
- **3.** Works as Sx Data Pane Demux performing load balancing of Session Establish Request between all Session Managers.
- 4. Supports default PFCP packet receiver port 8805.

The Sx service is associated with SAEGW service at Control-Plane and is associated with User-Plane Service at User-Plane. Sx Demux is initiated when the first Sx service is created with the minimum mandatory parameter in the context.

The Sx Demux functions as follows:

When working as Sx Data Demux

The Session Manager (Data Plane) sends the add session response indicating addition of new session and delete session request on deletion of session on Session Manager. Sx Data Demux maintains session count per session manager.

· When working as Sx Control Demux

The Sx Control Demux uses Prime PDF Management Messages (proprietary messages) to communicate static and dynamic rule configuration from Control-Plane to associated Data plane.

Proprietary Sx Messages Information

Proprietary Prime PFD message format

	Bits								
Octets	8	7	6	5	4	3	2	1	
1	Version	n		Spare	Spare	Spare	MP=0	S=0	
2	Messa	ge Type		1	-		1	1	
	47 Prir	47 Prime PFD Management Request							
	48 Prime PFD Management Response								
3	Messa	ge Length (1	st Octet)						
4	Messa	ge Length (2	2nd Octet)						
5	Sequer	nce Number	(1st Octet)						
6	Sequer	Sequence Number (2nd Octet)							
7	Sequer	Sequence Number (3rd Octet)							
8	Spare								

Cisco PFD Management Request

Information	P	Condition /	IE Length	IE ID
elements		Comment		

Config Action	M	1 – Add configuration	1 Byte	202
		2 – Delete Configuration		
Co-Relation id	М	unique number which will represent transaction id.	2 Byte	203
		During Split buffer message, correlation id will be same so that receiver can combine buffer.		
Number of Sub Part	О	N – Indicates Total number of sub parts	1 Byte	204
Sub Part index	0	Indicates the part number going into this message.	1 Byte	205
Content TLV	М	Type – Indicates Rule-Def, Charging Action or Action priority line - 1 Byte	3003 byte	
		Length – Length of Content - 2 Byte		206
		Value – Actual Buffer conent - Max size 3000 Bytes		

Cisco PFD Management Response

Information	P	Condition /	IE Length	IE ID	
elements		Comment			
PFCP Cause	M	1 Success	1 byte	19	
		0 Failure	-		
CoRelation id	M	Unique number – same as request message. Indicates to sender that this correlation has been received.	2 byte	203	

Sub Part Index	0	Indicates the part number received into this message.	1 byte	205	
		This will be only present when Split mode is used.			

Header information

Proprietary Sx Stats Query Req/Rsp/Ack

Table 1: PFCP Header format for Node level Query Message

Octets	8	7	6	5	4	3	2	1	
1	Version			Spare	Spare	Spare	MP=0	S=0	
2				Me	ssage Type				
		44 Sx Stats Query Request							
		45 Sx Stats Query Response							
		46 Sx Stats Query Ack/NAck							
3				Message I	Length (1st O	ectet)			
4		Message Length (2nd Octet)							
5		Sequence Number (1st Octet)							
6		Sequence Number (2nd Octet)							
7		Sequence Number (3rd Octet)							
8		Spare							

PFCP Header format for Subscriber/Session level Query Message

Octets	8	7	6	5	4	3	2	1	
1	Version			Spare	Spare	Spare	MP=0	S=1	
2				Messa	ge Type				
		44 Sx Stats Query Request							
		45 Sx Stats Query Response							
3		Message Length (1st Octet)							
4		Message Length (2nd Octet)							
5		Session Endpoint Identifier (1st Octet)							
6		Session Endpoint Identifier (2nd Octet)							
7		Session Endpoint Identifier (3rd Octet)							
8			Session	n Endpoint I	dentifier (4t	h Octet)			

9	Session Endpoint Identifier (5th Octet)
10	Session Endpoint Identifier (6th Octet)
11	Session Endpoint Identifier (7th Octet)
12	Session Endpoint Identifier (8th Octet)
13	Sequence Number (1st Octet)
14	Sequence Number (2nd Octet)
15	Sequence Number (3rd Octet)
16	Spare

IEs and Message Formats

Stats reporting framework shall use the messages and IE types as outlined below.

Table 2: Information Elements in Sx Stats Query Request Message

Information elements	P	Condition / Comment	ІЕ Туре	IE ID
Correlation ID	М	Unique number, which will represent transaction ID	Correlation ID	203
Stats Request	С	This IE shall be present if the Node Report Type indicates a statistics report request.	Stats request	209

Table 3: Information Elements in Sx Stats Query Response Message

Information elements	P	Condition / Comment	ІЕ Туре	IE ID
PFCP Cause	M	1 Success, 0 Failure	PFCP Cause	
Correlation ID	М	Unique number, which will represent transaction ID. During Split buffer message, Correlation ID will be same for all the messages so that receiver can identify uniquely the request to which the responses correspond.		203

Stats response	С	This IE shall be	Stats response	212
		present if the Node		
		Report Type		
		indicates a statistics		
		report response.		

Table 4: Information Elements in Sx Stats Query Ack/NAck

Information elements	P	Condition / Comment	ІЕ Туре	IE ID
Correlation ID	M	Unique number, which will represent transaction ID.	Correlation ID	203
Stats Ack/NAck	M	This IE shall be present to inform Ack/NAck to peer.	Stats response ACK/NACK	213

Sx Interface Private Information Element (IE) List

IE Type: 201

IE Name: PFCP_IE_UPDATE_ADDNL_FORW_PARAMS

Octet 1 and 2	Update Additi	Update Additional Forwarding Parameters IE Type = x (decimal)							
Octets 3 and 4	Length = n								
Information	P	Condition /	Appl.			IE Type			
elements		Comment	Sxa	Sxb	Sxc				
Destination Interface	С	This IE shall only be provided if it is changed.	X	X	X	Destination Interface			
		When present, it shall indicate the destination interface of the outgoing packet.							
Outer header removal	С	This IE shall only be provided if it is changed.	X	X	-				

Outer Header Creation	С	This IE shall only be provided if it is changed.	X	X	-	Outer Header Creation
Outer header marking	С	This IE shall only be provided if it is changed.			-	
Forwarding Policy	С	This IE shall only be provided if it is changed.	-	X	X	Forwarding Policy

Sx Message(s) Using the IE: Update FAR IE within Sx Session Modification Request.

IE Type: 202

IE Name: PFCP_IE_CONFIG_ACTION

IE Format and Encoding Information

Octet 1 and 2	Sub Part Number IE Type = 202 (decimal)						
Octets 3 and 4	Length = 1 byte	Length = 1 byte					
Information elements	P	P Condition / IE Length IE ID Comment					
Config Action	Add or Delete the config 1 Byte 202						

IE Type: 203

IE Name: PFCP_IE_CORRELATION_ID

Octet 1 and 2	Correlation ID IE Type = 203 (decimal)				
Octets 3 and 4	Length = 2 bytes				
Information elements	P	Condition / Comment	IE Length	IE ID	

Co-Relation ID	M	Unique number which will represent transaction ID.	2 Byte	203
		During Split buffer message, correlation ID will be same so that receiver can combine buffer.		

Sx Message(s) Using the IE: Sx Prime PFD MGMT Request for configuring the UP with various configurations.

Sx Prime PFD MGMT Response

IE Type: 204

IE Name: PFCP_IE_SUB_PART_NUMBER

IE Format and Encoding Information

Octet 1 and 2	Sub Part Number IE Type = 204 (decimal)					
Octets 3 and 4	Length = 1 byte					
Information elements	P Condition / IE Length IE ID Comment					
Number of Sub Parts	O N – Indicates Total number of sub parts for this config					

Sx Message(s) Using the IE: Sx Prime PFD MGMT Request for configuring the UP with various configurations.

IE Type: 205

IE Name: PFCP_IE_SUB_PART_INDEX

Octet 1 and 2	Sub Part Index IE Type = 205 (decimal)							
Octets 3 and 4	Length = 1 byte	Length = 1 byte						
Information elements	P Condition / IE Length IE ID Comment							
Sub Part index	О	Indicates the sub part number going into this config message.	1 Byte	205				

Sx Message(s) Using the IE: Sx Prime PFD MGMT Request for configuring the UP with various configurations.

Sx Prime PFD MGMT Response.

IE Type: 206

IE Name: PFCP_IE_CONTENT_TLV

IE Format and Encoding Information

Octet 1 and 2	Content TLV IE Type = 206 (decimal)							
Octets 3 and 4	Length = 3003 bytes							
Information elements	P	Condition / Comment	IE Length	IE ID				
Content TLV	М	Type – Indicates Rule-Def, Charging Action ,Action priority line , Rule and Route config,Group of Ruledef,	3003 bytes	206				
		Rule in GoR - 1 Byte						
		Length – Length of Content - 2 Byte						
		Value – Actual Buffer content - Max size 3000 Bytes						

Sx Message(s) Using the IE: Sx Prime PFD MGMT Request for configuring the UP with various configurations.

IE Type: 207

IE Name: PFCP_IE_RBASE_NAME

	Bits								
Octets	8	7	6	5	4	3	2	1	
1 to 2	Type = 2	202 (deci	mal)						
3 to 4	Length	= n							
5 to n	Rulebas	e Name							



Note

- Octets 1-2—Indicates Rulebase IE. Type 202 Reserved
- Octets 3-4—Indicates the length of rulebase name
- Octets 5-n—Rulebase name

This IE contains the active Rulebase Name for a subscriber to be communicated to User Plane.

IE Type: 208

IE Name: NSH-INFO

IE Format and Encoding Information

	Bits								
Octets	8	7	6	5	4	3	2	1	
1 to 2	Type =	208 (deci	mal)						
3 to 4	Length	= n							
5 to 5	BitOcto	et							
6 to 6	MSISDN Len								
7 to 22	MSISDN								
23 to 23	IMSI Len								
24 to 40	IMSI								

IE Type: 209

IE Name: Stats request IE

Information Elements	P	Condition / Comment	IE Type	IE ID
Query Params	M	Query Params shall describe the type of the query and optionally the name of the entity being queried.		210

Classifier Params	О	These shall be used	Classifier Params	211
		along with query		
		params for		
		narrowing down the		
		search.		

This IE are be of grouped type and consist of two IEs: Query Params IE and the Classifier Params IE. Multiple instances of Classifier Params IE can be present.

IE Type: 210

IE Name: Query Params IE

IE Format and Encoding Information

Octets	8	7	6	5	4	3	2	1		
1 to 2		Type = 210 (decimal)								
3 to 4		Length = n								
7		ENTITY TYPE								
8			Spa	are			QUERY TYPE	QUERY ALL		
9 to 10	Entity Name Length									
10 to n				Entity	Name					

Query Params is encoded as follows:

Octet 7: ENTITY TYPE - Numeric Identifier. Indicates the type of entity being queried:

- 1: Network Instance (APN name) [PFCP IE ID: 22] 2: Rulebase etc. (Future use) [PFCP IE ID: 207] Octet 8 encodes following flags:
 - QUERY ALL—Indicates whether we are querying one instance of the specified entity or all of them.
 - QUERY TYPE—Indicates whether we are querying individual ENTITY of the given type or we are expecting aggregated node level statistics. It takes values as follows:
 - 0: Bit when unset, indicates individual statistics.
 - 1: Bit when set indicates aggregated statistics.

Valid combinations of above flags are used to realize the use cases.

IE Type: 211

IE Name: Classifier Params IE

IE Format and Encoding Information

Bits

Octets	8	7	6	5	4	3	2	1	
1 to 2				Type =	= 211 (decir	nal)			
3 to 4				I	ength = n				
5		Classifier Type							
6				Clas	ssifier Leng	th			
7 to n					Classifier				

Classifier Params IE is encoded as follows:

Octet 5: Encodes the type of the classifier. It is defined by the context set by entity type.

So, same numeric identifiers may mean different for two different entity types.

Octet 6 encodes the length of classifier. The maximum of 256 byte long classifier is accommodated.

Octet 7 onwards is used to encode the classifier content. This content is encoded as an octet string. In case of numeric classifiers, the numbers are appropriately converted into string format and are delivered as is to the application. This process removes the length limitation on type of encoded numeric identifiers.

IE Type: 212

IE Name: Stats response IE

IE Format and Encoding Information

	Bits									
Octets	8	7	6	5	4	3	2	1		
1 to 2				Type =	= 212 (deci	mal)				
3 to 4		Length = n								
5		ENTITY TYPE								
6		Part Number								
7		Total Number of Parts								
8 to n				В	lob of data					

ENTITY TYPE is same as the one that is received in request. Else, Control Plane rejects the response from the User Plane.

The response from User plane can span across multiple messages depending upon the amount of data that needs to be sent to Control Plane.

- Message ID identifies one subpart of the response.
- Total number of messages this response consists of.

Blob of data consists of compressed context specific data. Contents of the same are uncompressed at Control Plane and interpreted as per the identifiers received (ENTITY TYPE).

IE Type: 213

IE Name: Stats response ACK/NACK

IE Format and Encoding Information

	Bits										
Octets	8	7	6	5	4	3	2	1			
1 to 2				Type =	= 213 (deci	mal)					
3 to 4		Length = n									
5		RESPONSE TYPE									
6 to n				Missing	g message	parts					

RESPONSE TYPE is: 0: ACK (success) if all parts of the response are correctly received at CP 1: NACK (failure) - CP responds with the message parts that were not received within the specified time.

Octets 6 and onwards specifies missing part numbers at CP in case CP sends out a NAck.

Use of NAck mechanism is not envisaged as of now. These will be incorporated in call flows, if required in future.

IE Type: 214

IE Name: PFCP_IE_PACKET_MEASUREMENT

IE Format and Encoding Information

The Packet Measurement IE contains the measured traffic volume in packets. This IE is encoded as shown below:

	Bits									
Octets	8	7	6	5	4	3	2	1		
1 to 2				Type =	= 214 (decim	nal)				
3 to 4		Length = n								
5			Spare	e		DLVO	L ULVO	DL TOVOL		
m to (m+7)				То	tal Packets	•	'			
p to (p+7)				Up	link Packets					
q to (q+7)				Dow	nlink Packe	ts				
s to (n+4)		Tl	nese octet(s) is/are pro	esent only if	explicitly	specified			

The following flags are coded within Octet 5:

- Bit 1 TOVOL— If this bit is set to "1", then the Total Packets field appears. Else, the Total Packets field is does not appear.
- Bit 2 ULVOL—If this bit is set to "1", then the Uplink Packets field appears. Else, the Uplink Packets field does not appear.
- Bit 3 DLVOL—If this bit is set to "1", then the Downlink Packets field appears. Else, the Downlink Packets field does not appear.
- Bit 4 to bit 8—These are spare bits for future use, and are set to 0.

At least one bit is set to 1. However, you can set many bits to 1.

The Total Packets, Uplink Packets, and Downlink Packets fields are encoded as an Unsigned64 binary integer value. They contain the total, uplink, or downlink number of packets respectively.

This is not a mandatory IE for any Message.

This IE is available in the following Messages between Control Plane and User Plane.

- Sx Session Modification over SxA, SxB, SxC, SxAB
- Sx Usage Report Session Deletion Response over SxA, SxB, SxC, SxAB
- Sx Usage Report Session Report Request over SxA, SxB, SxC, SxAB

IE Type: 215

IE Name: PFCP_IE_EXTENDED_MEASUREMENT_METHOD

IE Format and Encoding Information

A new IE (215 - Extended Measurement Method) is encoded as shown below. This IE indicates the method for measuring the usage of network resources.

	Bits									
Octets	8	7	6	5	4	3	2	1		
1 to 2	Type = 2	215 (decima	al)							
3 to 4	Length =	Length = n								
5	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Pkt		
6 to (n+4)	These or	ctet(s) is/ar	e present o	nly if expli	citly specif	fied	•	•		

Figure Extended Measurement Method

Octet 5 is encoded as follows:

- Bit 1 Pkt (Packet)—When set to 1, this bit indicates a request for measuring the usage of the traffic in packets.
- Bit 2 to 8—These are spare bits for future use, and are set to 0.



Note

Only one bit is set to 1.

This is not a mandatory IE for any Message.

This IE can be available in the following message between Control Plane and User Plane.

Sx Session Establishment over SxA, SxB, SxC, SxAB

Similarly, Usage Report from User Plane is enhanced to support the packet information.

IE Type: 216

IE Name: PFCP_IE_RECALCULATE_MEASUREMENT

IE Format and Encoding Information

This private IE has been added to support "Max number of change conditions" trigger for offline charging records, such as Gz and Rf.

	Bits										
Octets	8	7	6	5	4	3	2	1			
1 to 2	Type = 6	ppe = 62 (decimal)									
3 to 4	Length =	Length = n									
5	Spare	Spare	Spare	Spare	Spare	Spare	RCVOL	RCDUR			
6 to (n+4)	These oc	ctet(s) is/ar	e present o	nly if expl	icitly speci	fied	,				

The following flags are coded within Octet 5:

- Bit 1 RCDUR (Re-calculate Duration Measurement)—When set to 1, this flag indicates a request for resetting the Duration Measurement to '0' by the UP function.
- Bit 2 RCVOL (Re-calculate Volume Measurement)—When set to 1, this flag indicates a request for resetting the Volume Measurement to '0' by the UP function. Then, the UP function proceeds to repopulate the Volume Measurement. The repopulation is done by aggregating the Volume Measurement of all the URRs that contain Linked URR ID as the URR ID sent in Update URR IE.
- Bit 3 to 8—Spare bits for future use, and are set to 0.
- 1. PFCP Session Modification Request
- 2. PFCP Session Report Response

IE Name: PFCP_IE_SUB_INFO

IE Format and Encoding Information

	Bits										
Octets	8	7 6 5 4 3 2 1									
1 to 2	Type = 21	Type = 217 (decimal)									
3 to 4	Length =	n									
5 to 5	BitOctet										
6 to 6	MSISDN	Len									
7 to 22	MSISDN										
23 to 23	IMSI Len										
24 to 40	IMSI										
41 to 41	IMEI Len	IMEI Len									
42 to 57	IMEI	IMEI									
58 to 61	Call ID										

Octets 5-5: BitOctet. Indicates the available fields.

- Bit 1—IMSI
- Bit 2—MSISDN
- Bit 3—IMEI
- Bit 4—Call ID

IE Type: 218

IE Name: PFCP_IE_INTR_INFO

IE Format and Encoding Information

The IE is part of Create Dupl Params and Update Duplicate Params IE.

Create Duplicate Params IE can be part of SX Establishment Req and SX Session Modify Request.

Update Duplicate Params IE can be part of SX Session Modify Request.

Rife
Dits

Octets	8	7	6	5	4	3	2	1			
1 to 2	Type = 21	Type = 218 (decimal)									
3 to 4	Length =	n									
5 to 5	BitOctet										
6 to 9	Intercept	ID									
10 to 13	Charging	ID									
14 to 17	Bearer ID)									
18 to 18	Context n	ame Ler	1								
19 to 22	Context n	ame									

Octets 5-5: BitOctet. Indicates the available fields.

- Bit 1—Intercept ID
- Bit 2—Charging ID
- Bit 3—Bearer ID
- Bit 4—Context name

IE Type: 219

IE Name: PFCP_IE_NODE_CAPABILITY

IE Format and Encoding Information

	Bits								
Octets	8	7	6	5	4	3	2	1	
1 to 2	Type =	= 219 (deci	mal)						
3 to 4	Lengt	h = n							
5 to 8	Max S	Sessions Su	pported						
9 to (n+4)	These	octet(s) is	are present	only if ex	plicitly spe	cified			

The Max Sessions Supported value are encoded as an Unsigned32 binary integer value.

Max Sessions supported value is the maximum number of sessions that are supported by User Plane for this association with Control Plane.

IE Name: INNER PACKET MARKING

IE Format and Encoding Information

The Inner Packet Marking IE type shall be encoded as shown below. It indicates the DSCP to be used for UL/DL Inner packet marking.

	Bits									
Octets	8	7	6	5	4	3	2	1		
1 to 2	Type =	Type = 220 (decimal)								
3 to 4	Length	= n								
5 to 6	ToS/Tr	affic Clas	S							

The ToS/Traffic Class shall be encoded on two octets as an OctetString. The first octet shall contain the DSCP value in the IPv4 Type-of-Service or the IPv6 Traffic-Class field and the second octet shall contain the ToS/Traffic Class mask field, which shall be set to "0xFC".

IE Type: 221

IE Name: TRANSPORT LEVEL MARKING OPTIONS

IE Format and Encoding Information

TRANSPORT LEVEL MARKING OPTIONS shall be encoded as shown below. It indicates the copy-inner/outer flags for encaps-header marking.

	Bits										
Octets	8	7	6	5	4	3	2	1			
1 to 2	Type =	Type = 221 (decimal)									
3 to 4	Lengtl	h = n									
5 to 5	Copy-	Inner/Oute	er Flag								

Copy-Inner/Outer flags shall be encoded on 1 Octet.

IE Type: 223

PFCP IE CHARGING PARAMS

Bits]
	1

Octets	8	7	6	5	4	3	2	1					
1 to 2	Type = 22	Type = 223 (decimal)											
3 to 4	Length =	ength = n											
5 to 6	Charging	Charging Chars											
7	GTPP Gro	GTPP Group Name length											
8	GTPP Gro	oup											
9 to 12	GTPP Cor	ntextID											
13	Accountin	ng Policy N	lame lengtl	h									
14	Accountin	ng Policy N	lame										
15 to 18	Accountin	ng Policy S	ervice type	;									
19 to 22	Diameter	Interim Int	erval										
23	AAA Gro	up Name I	ength										
24	AAA Gro	up Name											
25 to 28	AAA Gro	up Contex	tId										
29 to 32	Radius In	Radius Interim Interval											
33	GY Offlin	GY Offline charging											
34	gtpp_dict												

IE Name: PFCP_IE_GY_OFFLINE_CHARGE

IE Format and Encoding Information

	Bits									
Octets	8	7	6	5	4	3	2	1		
1 to 2	Type =	Type = 224 (decimal)								
3 to 4	Length	Length = n								
5 to 5	Gy Of	fline Char	ging Status							

IE Type: 226

PFCP_IE_SUB_PARAMS

	Bits

Octets	8	7	6	5	4	3	2	1
1 to 2	Type = 22	6 (decim	al)	1	l	l		ı
3 to 4	Length = 1	n						
5 to 8	BitOctet							
9 to 10	Charging	Characte	rs					
11 to 11	Rat Type							
12 to 12	MCC MN	C Lengtl	1					
Variable Length	MCC MN	C Value						
4 bytes/16 bytes	SGSN Ad	dress IPv	4/IPV6					
1 byte	ULI Leng	th						
Variable Length	ULI Value	e						
4 bytes	Congestio	n Level \	Value					
1 byte	Customer	ID Leng	th					
Variable Length	Customer	ID value						
4 bytes/16 bytes	GGSN Ad	ldress IP	v4/IPV6					
1 byte	UserName	e Length						
Variable Length	UserName	e Value						
1 byte	Radius Str	ring Leng	gth					
Variable Length	Radius Sti	ring Valu	e					
1 byte	Session II) Length						
Variable Length	Session II) Value						
1 byte	MS Timez	zone Len	gth					
Variable Length	MS Timez	zone Valu	ie					
1 byte	User Ager	nt Length	l .					
Variable Length	User Ager	nt Value						

Variable Length	Hash Value	
1 byte	Called Station Id Length	
Variable Length	Called Station Id Value	
1 byte	Calling Station Id Length	
Variable Length	Calling Station Id Value	
4 bytes	Content Filtering Policy ID	
1 byte	Traffic Optimization Policy ID	

IE Name: PFCP_IE_RULE_NAME

IE Format and Encoding Information

	Bits										
Octets	8	7	6	5	4	3	2	1			
1 to 2	Type =	Type = 227 (decimal)									
3 to 4	Length	Length = n									
5 to 68	Rule N	lame									

IE Type: 228

IE Name: LAYER2 MARKING

IE Format and Encoding Information

To pass the L2 Marking information to the UP for the bearer, a new custom-IE is defined and the FAR is modified to include it as follows. It identifies the Layer 2 Marking to be applied for the packets matching this FAR.

The length of the IE could be either 0 or 1.

Bits

Octets	8	7	6	5	4	3	2	1	
1 to 2	Type	= 228 (deci	imal)						
3 to 4	Lengt	h = n							
5 to 5	TYPE	E (2 Bits) P	RIORITY (6 Bits)					
	Type	: (1-DSCP	, 2-QCI, 3-1	None) - be	ginning 2 I	Bits			
	Prior	ity-Value:	the last 6 b	its					
	• I	nternal-Pri	ority in cas	e of QCI/N	None type				
	• I	OCSP value	e in case of	DSCP typ	e				

IE Name: PFCP_IE_MONITOR_SUBSCRIBER_INFO

IE Format and Encoding Information

	Bits										
Octets	8	7	6	5	4	3	2	1			
1 to 2	Type =	229 (deci	mal)								
3 to 4	Length	= n									
5	Spare		С		D		Actio	n			
d to (d+7)	Data tra	Data tracing parameters									
p to (p+15)	Protoco	Protocol tracing parameters									
s to (n+4)	These o	octet(s) is/	are presen	t only if ex	plicitly spe	cified					

Action: STOP / START monitor subscriber tracing. STOP =1, START =2.

D = DATA events tracing is ON if D=1. The 8 octets (d to d+7) contain data events tracing (fastpath) information should be present only when D=1.

C = CONTROL events tracing is ON if C=1.

Data Tracing (fastpath) Information (8 octets): It will contain the data filter parameters like Packet capture, Packet capture size, and MEH header.

Octet 1:

- Bit 1 VPP enable/disable
- Bit 2 FCAP Packet capture
- Bit 3 MEH present
- Bit 4 to 6 Priority

Octet 2 to 3: Packet size

Octet 4 - 8: Reserved for future use. Currently, all set to 0.

Protocol Tracing Information (16 octets/128 bits): The 16 octets (p to p+15) contain protocol tracing information and should be present only when either control flag (C) or data flag (D) is enable. Each bit represents a unique protocol to monitor. E.g. If 49th bit is 1, PFCP events tracing is ON. Protocol Tracing 'Rulematch Events (Option 34)', 'L3 Data (Option 19)', 'EDR (Option 77)' and 'Subscriber Summary After Call Disconnect' are controlled by control event flag.

IE Type: 230

IE Name: PFCP_IE_MON_SUB_REPORT_SESS_REP_REQ

IE Format and Encoding Information

	Bits										
Octets	8	7	6	5	4	3	2	1			
1 to 2	Type =	Type = 230 (decimal)									
3 to 4	Length	Length = n									
5	Status	code									

Status code: It indicates the acceptance or the rejection of the subscriber trace at UP. Status code = 0 will mean a success. Values 1-255 will uniquely specify the specific error code or notification.

IE Type: 237

IE Name: PFCP_IE_RATING_GRP

IE Format and Encoding Information

	Bits										
Octets	8	7	6	5	4	3	2	1			
1 to 2	Type =	Type = 237 (decimal)									
3 to 4	Length	Length = 2 bytes									
5 to 8	Rating	Group									

IE Type: 238

IE Name: PFCP_IE_NEXTHOP

IE Format and Encoding Information

Bits

Octets	8	7	6	5	4	3	2	1	
1 to 2	Type =	Type = 238 (decimal)							
3 to 4	Lengtl	h = n							
5 to 10	PFCP	_IE_NEXT	HOP_ID						
11 to 14	PFCP	_IE_NEXT	HOP_IP						

IE Name: PFCP_IE_NEXTHOP_ID

IE Format and Encoding Information

	Bits									
Octets	8	7	6	5	4	3	2	1		
1 to 2	Type =	Type = 239 (decimal)								
3 to 4	Length	Length = 5								
5										

IE Type: 240

IE Name: PFCP_IE_NEXTHOP_IP

IE Format and Encoding Information

	Bits								
Octets	8	7	6	5	4	3	2	1	
1 to 2	Type = 240 (decimal)								
3 to 4	Length = n								
5	Spare			V4			V6		
m to (m+3)	IPv4 Address								
p to (p+15)	IPv6 A	Address							

IE Type: 241

PFCP_IE_QGR_INFO

D:4~
BHS
Dia

Octets	8	7	6	5	4	3	2	1
1 to 2	Type = 24	1 (decimal)					
3 to 4	Length =	n						
5 to 6	Number o	of QGR						
7 to 7	QGR 1 in	formation s	stats - Bit C	Octet				
8 to 8	QGR Ope	eration(Add	/Modify/R	emove)				
9 to 12	QGR Prio	ority						
13 to 13	QGR Nan	ne Length						
14 to n	QGR Nan	ne						
n+1 to n+4	FAR ID							
n+5 to n+8	QER ID							
n+8 to n+11	URR ID							
Same as 7 to n+11	Next QGF	R(if any) in	formation	stats				

IE Name: PFCP_IE_UE_IP_VRF

	Bits									
Octets	8	7	6	5	4	3	2	1		
1 to 2	Type $= 2$	242 (decin	nal)							
3 to 4	Length =	= n								
5	Spare		Identi	cal VRF flag	IPv6	VRF Valid	IPv4	VRF Valid		
m to (m+1)	VRF-1	Name Len	gth = p							
Variable Length	VRF-1	VRF-1 Name								
n to n+1	VRF-2	VRF-2 Name Length = q								
Variable Length	VRF-2	Name								

IE Name: PFCP_IE_GX_ALIAS

IE Format and Encoding Information

The IE to communicate a Gx-Alias GoR(Group-of-Ruledef) name, Start and End PDR IDs and also the operation to perform, from CP to UP during Sx Session Establishment/Modification Request message. There can be multiple instances of same IE in an Sx-message.

	Bits										
Octets	8	7	6	5	4	3	2	1			
1 to 2	Type = 2	46 (decir	nal)								
3 to 4	Length n	[Min=7,	Max=69	{5+ACSC	TRL_GRP	OF_RDE	FS_NAME	LEN (64)}]			
5	flags (Add/delete GoR Rules),for eg: 1 for Add, 0 Delete rules in GoR										
6 to 7	Start PDR ID										
8 to 9	End PDR ID										
10 to n+4	Gx-alias	GoR nar	ne (min si	ze=2, max	size=64)						