

Determinación de un servidor NTP en SPA3102

Contenido

[Introducción](#)

[¿Cómo fijar al servidor NTP en SPA3102?](#)

[Información Relacionada](#)

[Introducción](#)

Este artículo forma parte de una serie para ayudar con la configuración, el troubleshooting y el mantenimiento de productos para Pequeñas Empresas de Cisco.

Q. [¿Cómo fijar al servidor NTP en SPA3102?](#)

R.

Configure a un servidor NTP en SPA3102

Paso 1:

Acceda la página de configuración basada en web SPA3102. Para las instrucciones, haga clic [aquí](#).

Paso 2:

Cuando aparece la página de configuración basada en web, **login Admin del teclado**.



Paso 3:

Configuración rápida del teclado, entonces **avanzada**.

Paso 4:

Bajo el **servidor NTP primario**, ingrese el direccionamiento del servidor NTP en el campo proporcionado.

The screenshot shows the Linksys Phone Adapter Configuration interface. At the top left is the Linksys logo and the text "A Division of Cisco Systems, Inc.". The main title is "Linksys Phone Adapter Configuration". The navigation menu includes "Status", "Wan Setup", "Lan Setup", and "Application". There are also links for "User Login", "basic", and "advanced".

Yellow callout boxes provide instructions: "Click Wan Setup." points to the "Wan Setup" menu item, and "Click advanced." points to the "advanced" link.

The "Wan Setup" section is expanded, showing the following settings:

- Internet Connection Settings:** Connection Type: DHCP
- Static IP Settings:** Static IP, NetMask, Gateway
- PPPoE Settings:** PPPOE Login Name, PPPOE Login Password, PPPOE Service Name
- Optional Settings:** HostName, Domain, Primary DNS, Secondary DNS, DNS Server Order (Manual/Parallel), Primary NTP Server

A yellow callout box points to the "Primary NTP Server" field with the text: "Enter the **Primary NTP Server** here."

At the bottom of the page, there is a "Submit All Changes" button.

Paso 5:

Tecleo

[Información Relacionada](#)

- [Soporte Técnico y Documentación - Cisco Systems](#)