

Sauvegarde asynchrone avec des profils de numéroteur

Contenu

[Introduction](#)

[Avant de commencer](#)

[Conventions](#)

[Conditions préalables](#)

[Composants utilisés](#)

[Théorie générale](#)

[Configurez](#)

[Diagramme du réseau](#)

[Configurations](#)

[Vérifiez](#)

[Exemple de sortie avec show](#)

[Dépannez](#)

[Dépannage des commandes](#)

[Exemple de sortie de débogage](#)

[Informations connexes](#)

[Introduction](#)

Ce document décrit comment configurer un routeur distant (Cisco 3640) pour composer le lieu d'exploitation principal utilisant les POTS analogiques rayent au cas où la connexion de Relais de trames descendrait. Le Cisco 3640 emploie des Profils de composeur pour fournir l'Interface de sauvegarde pour le lien de Relais de trames. En outre, une interface asynchrone spécifique est mise de côté pour l'appel sortant de sauvegarde. Notez que cette configuration peut être développée pour inclure le PPP à liaisons multiples, qui augmenterait de manière significative la bande passante disponible pour la connexion de sauvegarde. Voyez le [PPP à liaisons multiples pour le DDR - La configuration de base et la vérification](#) documentent le pour en savoir plus.

Ce document affiche comment configurer une connexion de sauvegarde avec une exécution de protocole de routage sur la liaison asynchrone. La prise en considération soigneuse est nécessaire avant de mettre en application une telle conception que la bande passante utilisée par le protocole de routage peut raccourcir la bande passante disponible pour le transfert des données. La Fonction Snapshot Routing ou les artères statiques peut être utilisée à travers la liaison asynchrone, au lieu d'un protocole de routage.

[Avant de commencer](#)

[Conventions](#)

Pour plus d'informations sur les conventions des documents, référez-vous aux [Conventions utilisées pour les conseils techniques de Cisco](#).

[Conditions préalables](#)

Aucune condition préalable spécifique n'est requise pour ce document.

[Composants utilisés](#)

Les informations dans ce document sont basées sur les versions de logiciel et de matériel ci-dessous.

- Logiciel Cisco IOS Version 12.0(7)T
- Cisco 3640
- Serveur d'accès à distance de Cisco AS5200
- Cisco 7206

Les informations présentées dans ce document ont été créées à partir de périphériques dans un environnement de laboratoire spécifique. Tous les périphériques utilisés dans ce document ont démarré avec une configuration effacée (par défaut). Si vous travaillez dans un réseau opérationnel, assurez-vous de bien comprendre l'impact potentiel de toute commande avant de l'utiliser.

[Théorie générale](#)

Il est commun pour fournir aux chemins redondants pour des connexions WAN telles que le Relais de trames des circuits de Connexion à la demande. Les modems asynchrones et les lignes avec commutation à circuit de réseau téléphonique public commuté (POTS) sont régulièrement les interfaces WAN de sauvegarde utilisées. La planification rigoureuse est nécessaire en concevant des scénarios d'Accès direct secouru. Des facteurs tels que le trafic sur les liaisons de sauvegarde, le nombre de liens susceptibles du manque, et la planification de capacité de port de prendre en charge les circuits de sauvegarde doivent être considérés.

Trois méthodes classiques disponibles pour fournir la sauvegarde pour un lien WAN sont :

- Interfaces de sauvegarde
- Fonctions Dialer Watch
- Routes statiques flottantes

Une Interface de sauvegarde demeure inactive jusqu'à ce que la liaison principale descende. La liaison de sauvegarde est alors lancée, rétablissant la connexion entre les deux sites. En mettant en application des Interfaces de sauvegarde pour des liens de Relais de trames, les sous-interfaces point par point sur les liens de Relais de trames sont avantageuses puisque les interfaces principales ou multipoints peuvent demeurer dans un état up/up même si les circuits virtuels primaires (PVCs) descendent, causant l'Interface de sauvegarde de ne pas être lancée. Il est également recommandé de configurer des Fonction Frame Relay End-to-End Keepalive sur votre réseau pour la version de logiciel 12.05(T) ou ultérieures de Cisco IOS®. Référez-vous au pour en savoir plus de document de [Fonction Frame Relay End-to-End Keepalive](#).

Une Fonction Dialer Watch fournit la Connectivité fiable sans compter seulement sur définir le trafic intéressant pour déclencher des appels sortants au routeur central. Artères de particularité de moniteurs de Fonction Dialer Watch les certaines et, si ces réseaux sont inaccessibles, la

utilisateurs RNIS et de connexion d'accès asynchrone aussi bien que la connexion de sauvegarde.

La configuration de maui-rtr-06 (Cisco 7206) est inutile au scénario d'Accès direct secouru. Le Cisco 7206 est seulement utilisé pour terminer les liens WAN entrants. La configuration n'est pas nécessaire pour expliquer la sauvegarde asynchrone.

- [maui-nas-05 \(Cisco 3640\)](#)
- [maui-nas-02 \(Cisco AS5200\)](#)

maui-nas-05 (Cisco 3640)

```
Current configuration:
!
version 12.1
service timestamps debug datetime msec localtime show-timezone
service timestamps log datetime msec localtime show-timezone
service password-encryption
!
hostname maui-nas-05
!
enable secret <deleted>
!
username maui-nas-02 password <deleted>
  !--- username and password of the remote router for !---
  - Challenge Handshake Authentication Protocol (CHAP)
  authenticationip subnet-zero no ip domain-lookup !
interface Loopback0 ip address 172.22.63.5
255.255.255.255 ! interface Loopback1 ip address
172.22.69.254 255.255.255.0 ! interface Ethernet0/0 no
ip address shutdown ! interface Ethernet0/1 ip address
172.22.95.1 255.255.255.0 ! interface Serial3/0 !---
Frame Relay interface no ip address encapsulation frame-
relay frame-relay lmi-type cisco ! interface Serial3/0.1
point-to-point !--- Frame Relay subinterface backup
delay 5 10 !--- Enable backup interface 5 seconds after
subinterface is down !--- Disable dialer interface 10
seconds after subinterface comes back up backup
interface Dialer1 !--- Assigns dialer 1 as backup
interface ip address 192.168.10.1 255.255.255.252 frame-
relay interface-dlci 46 ! interface Async33 !--- Async
Interface set aside for dial backup no ip address
encapsulation ppp !--- Set PPP as encapsulation
mechanism for interface dialer in-band !--- Enable DDR
on interface dialer pool-member 2 !--- Assign async
interface to dialer pool 2 async default routing !---
Allows interface to pass routing updates over an async
line no fair-queue no cdp enable ! interface Dialer1 ip
unnumbered Loopback1 !--- Use IP address of Loopback 1
interface for Dialer Interface encapsulation ppp !---
Set PPP as encapsulation mechanism for interface dialer
pool 2 !--- Assign dialer interface to dialer pool 2
dialer idle-timeout 300 !--- Set idle time in seconds
before call is disconnected dialer string 10001 !---
Specify telephone number to be dialed (PRI on maui-nas-
03) dialer hold-queue 50 !--- Number of interesting
packets to hold in queue until !--- modem connection is
established dialer-group 1 !--- Assign dialer interface
```

```

to use dialer-list 1 to !--- determine interesting
traffic no peer default ip address !--- Disable peer
default IP address assignment to dialer interface no cdp
enable ppp authentication chap !--- Enforce CHAP
authentication on dialer interface ppp chap hostname
maui-backup !--- Use maui-backup for CHAP hostname
instead of maui-nas-05 !--- This username and password
must be configured on the AS5200 ppp chap password
<deleted> !--- Create CHAP password for user Maui-backup
! router ospf 1 network 172.22.0.0 0.0.255.255 area 0
network 192.168.10.0 0.0.0.3 area 0 ! ip classless no ip
http server ! dialer-list 1 protocol ip permit !---
Permit IP on dialer group 1 as interesting packets !
line con 0 transport input none line 33 !--- Physical
interface to be used for dialing !--- Matches with
interface Async 33 configured above script dialer mica.*
!--- Assign default chat script for mica modems to line
modem InOut transport input all line 34 40 modem InOut
transport input all line aux 0 line vty 0 4 login ! end

```

maui-nas-02 (Cisco AS5200)

```

Current configuration:
!
version 12.0
service timestamps debug datetime msec localtime show-
timezone
service timestamps log datetime msec localtime show-
timezone
service password-encryption
!
hostname maui-nas-02
!
no logging console guaranteed
enable secret <deleted>
!
username maui-backup password <password>
!--- username and password used by dialin client !---
(configured on interface dialer 1 on the Cisco 3640)spe
2/0 2/3 firmware location
system:/ucode/mica_port_firmware ! resource-pool disable
! ip subnet-zero no ip domain-lookup ! isdn switch-type
primary-ni ! controller T1 0 !--- PRI used for dialin
users framing esf clock source line primary linecode
b8zs pri-group timeslots 1-24 description "NAS Phone
Number:10001" ! controller T1 1 clock source line
secondary ! ! interface Loopback0 ip address 172.22.87.2
255.255.255.255 no ip directed-broadcast ! interface
Loopback1 !--- Loopback 1 summarizes addresses in the ip
address pool !--- Note that Loopback 1 and the address
pool are in the same subnet ip address 172.22.83.254
255.255.255.0 no ip directed-broadcast ! interface
Ethernet0 ip address 172.22.80.2 255.255.255.0 no ip
directed-broadcast ! interface Serial0:23 !--- D channel
for T1 0 no ip address no ip directed-broadcast isdn
switch-type primary-ni isdn incoming-voice modem !---
This command is required to accept analog calls on the
PRI fair-queue 64 256 0 no cdp enable ! interface Group-
Async1 !--- Group-Async Interface for all dialin
connections !--- Note that this interface does not
distinguish between !--- a backup connection or a
regular dialup connection ip unnumbered Loopback1 !---
Use IP address of Loopback 1 interface for Dialer

```

```

Interface no ip directed-broadcast encapsulation ppp !--
- Set PPP as encapsulation mechanism for interface ip
tcp header-compression passive async default routing !--
- Allows interface to pass routing updates over an async
line async mode interactive !--- Enable interactive mode
on async interface peer default ip address pool default
!--- Assign IP addresses for incoming calls from default
address pool no fair-queue no cdp enable ppp max-bad-
auth 3 ppp authentication chap !--- Use CHAP
authentication group-range 1 24 ! router ospf 1 network
172.22.0.0 0.0.255.255 area 0 ! ip local pool default
172.22.83.2 172.22.83.254 !--- IP address pool for
dialin connection ip default-gateway 172.22.80.1 ip http
server ip classless ! ! line con 0 transport input none
line 1 24 exec-timeout 0 0 autoselect during-login
autoselect ppp absolute-timeout 240 refuse-message
^CCCCCCC!!! All lines are busy, try again later ###^C
modem InOut international transport preferred none
transport input telnet transport output telnet line aux
0 line vty 0 4 password <deleted> login ! ntp clock-
period 17180069 ntp server 172.22.255.1 scheduler
interval 3000 end

```

Vérifiez

Cette section présente des informations que vous pouvez utiliser pour vous assurer que votre configuration fonctionne correctement.

certaines commandes show sont prises en charge par l'outil Interpréteur de sortie, qui vous permet d'afficher une analyse de la sortie de la commande show.

- *ID utilisateur de **show caller détaillé*** - Pour afficher le Link Control Protocol détaillé (LCP) - paramètres négociés. **Note:** L'ordre de **show caller** a été ajouté au logiciel de Cisco IOS dans la release 11.3(5)AA. Si votre version de logiciel ne prend en charge pas l'ordre de **show caller**, utilisez l'ordre d'**utilisateur d'exposition**.
- **show dialer** - Pour déterminer si un appel physique a été fait.
- **show ip route** - Pour afficher toutes les artères dans la table de routage.
- **show ip ospf database** - Pour afficher la liste de relatif à l'information à la base de données de Protocole OSPF (Open Shortest Path First) pour un appareil spécifique.
- **show ip ospf interface [interface-nom]** - Pour afficher les informations liées à l'OSPF d'interface. Le pour en savoir plus, voyent que [ce qui fait la commande de show ip ospf interface indiquez ?](#) document.
- **détail de show ip ospf neighbor [interface-nom] [voisin-id]** - pour afficher les informations d'OSPF-voisin par interface. Le pour en savoir plus, voyent que [ce qui fait la commande de show ip ospf neighbor indiquez ?](#) document.
- **show ip protocols** - Pour afficher les paramètres et l'état actuel du processus actif de protocole de routage. Le pour en savoir plus, voyent les informations de **show ip protocols** dans la documentation d'[ordres de Protocol-indépendant de Routage IP](#).

Exemple de sortie avec show

Les sorties suivantes affiche la table de routage de maui-nas-05 tandis que le lien de Relais de trames est en hausse. Notez que les artères OSPF sont vues sur la sous-interface séquentielle.

```
maui-nas-05#show ip route
```

```
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
i - IS-IS, L1 - ISIS level-1, L2 - ISIS level-2, ia - ISIS inter area
* - candidate default, U - per-user static route, o - ODR
P - periodic downloaded static route
```

```
Gateway of last resort is not set
```

```
192.168.10.0/30 is subnetted, 1 subnets
C    192.168.10.0 is directly connected, Serial3/0.1
172.22.0.0/16 is variably subnetted, 7 subnets, 2 masks
O    172.22.83.254/32 [110/50] via 192.168.10.2, 00:04:40, Serial3/0.1
O    172.22.255.6/32 [110/49] via 192.168.10.2, 00:04:40, Serial3/0.1
C    172.22.63.5/32 is directly connected, Loopback0
C    172.22.95.0/24 is directly connected, Ethernet0/1
O    172.22.80.0/24 [110/49] via 192.168.10.2, 00:04:40, Serial3/0.1
O    172.22.87.2/32 [110/50] via 192.168.10.2, 00:04:42, Serial3/0.1
C    172.22.69.0/24 is directly connected, Loopback1
```

Quand la liaison principale échoue, la liaison de sauvegarde est évoquée, et la table de routage converge. Notez que les artères OSPF sont sur l'interface de numérotation.

```
maui-nas-05#show ip route
```

```
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
i - ISIS, L1 - ISIS level-1, L2 - ISIS level-2, IA - ISIS inter area
* - candidate default, U - per-user static route, o - ODR
P - periodic downloaded static route
```

```
Gateway of last resort is not set
```

```
172.22.0.0/16 is variably subnetted, 7 subnets, 2 masks
C    172.22.83.254/32 is directly connected, Dialer1
O    172.22.255.6/32 [110/1796] via 172.22.83.254, 00:00:48, Dialer1
C    172.22.63.5/32 is directly connected, Loopback0
C    172.22.95.0/24 is directly connected, Ethernet0/1
O    172.22.80.0/24 [110/1795] via 172.22.83.254, 00:00:48, Dialer1
O    172.22.87.2/32 [110/1786] via 172.22.83.254, 00:00:48, Dialer1
C    172.22.69.0/24 is directly connected, Loopback1
```

La sortie suivante affiche des détails spécifiques à l'utilisateur maui-nas-02 (le serveur d'accès du site central).

```
maui-nas-05#show caller user maui-nas-02 detail
```

```
User: maui-nas-02, line tty 33, service Async
Idle time 00:00:09
Timeouts:          Absolute  Idle      Idle
                  Session    Session   Exec
Limits:           -         -         00:10:00
Disconnect in:   -         -         -
TTY: Line 33, running PPP on As33
Location: PPP: 172.22.83.254
```

```
Line: Baud rate (TX/RX) is 9600/9600, no parity, 2 stopbits, 8 databits
Status: Ready, Active, No Exit Banner, Async Interface Active
      HW PPP Support Active
Capabilities: Modem Callout, Modem RI is CD, Integrated Modem
Modem State: Ready
```

```
User: maui-nas-02, line As33, service PPP
      Active time 00:00:35, Idle time 00:00:05
```

```
Timeouts:          Absolute Idle
Limits:            -          00:05:00
Disconnect in:    -          00:04:54
```

```
PPP: LCP Open, CHAP (local <--> local), IPCP
```

```
LCP: -> peer, ACCM, AuthProto, MagicNumber, PCompression, ACCompression
      <- peer, ACCM, AuthProto, MagicNumber, PCompression, ACCompression
```

```
!--- LCP Parameters negotiated NCP: Open IPCP IPCP: <- peer -> peer, Address !--- IPCP
Parameters negotiated Dialer: Connected 00:01:07 to 10001, outbound Idle timer 300 secs, idle 7
secs Type is IN-BAND ASYNC, group Dialer1 Cause: ip (s=172.22.63.5, d=224.0.0.5) !--- Reason for
Dialout IP: Local 172.22.63.5, remote 172.22.83.254 Counts: 23 packets input, 1204 bytes, 0 no
buffer 0 input errors, 0 CRC, 0 frame, 0 overrun 27 packets output, 1498 bytes, 0 underruns 0
output errors, 0 collisions, 0 interface resets
```

Dépannez

Cette section fournit des informations que vous pouvez utiliser pour dépanner votre configuration.

Dépannage des commandes

certaines commandes show sont prises en charge par l'outil Interpréteur de sortie, qui vous permet d'afficher une analyse de la sortie de la commande show.

Note: Avant d'exécuter les commandes **debug**, référez-vous à la section **Informations importantes sur les commandes Debug**.

- **debug dialer events** - Pour afficher les informations de débogage au sujet des paquets reçus sur une interface de numérotation. Quand le routage sur demande de cadran (DDR) est activé sur l'interface, les informations au sujet de la cause de n'importe quel appel (appelé la cause d'appel) sont également affichées. Le pour en savoir plus, voyent les informations d'événement de numérotation de débogage dans la documentation de [commandes de debug](#).
- **mettez au point les paquets de numéroteur** - Pour afficher les informations de débogage au sujet des paquets reçus sur une interface de numérotation. **Le forme no de** cette commande désactive la sortie de débogage. Le pour en savoir plus, voyent les informations de **paquets de numéroteur de débogage** dans la documentation de [commandes de debug](#).
- **debug ppp** - Pour afficher les informations sur le trafic et des échanges d'un interrèseau mettant en application le PPP. **Le forme no de** cette commande désactive la sortie de débogage. **[non] debug ppp {paquet | négociation | erreur | authentification}** Le pour en savoir plus, voyent les informations de **debug ppp** dans la documentation de [commandes de debug](#).
- **debug isdn event** - Pour afficher des événements RNIS se produisant du côté utilisateur (sur le routeur) de l'interface RNIS. Les événements RNIS Q.931 sont affichés (établissement d'appel et démontage de la connexion réseau RNIS). **Le forme no de** cette commande désactive la sortie de débogage.
- **debug isdn q931** - Pour afficher des informations sur l'établissement d'appel et le démontage de la connexion réseau RNIS (couche 3) entre le routeur local (côté utilisateur) et le réseau. **Le forme no de** cette commande désactive la sortie de débogage. Le pour en savoir plus,

voient les informations de **debug isdn q931** dans la documentation de [commandes de debug](#).

Exemple de sortie de débogage

```
maui-nas-05#debug ppp negotiation
PPP protocol negotiation debugging is on
maui-nas-05#debug ppp chap
PPP authentication debugging is on
maui-nas-05#debug modem
Modem control/process activation debugging is on
maui-nas-05#debug backup
Backup events debugging is on
maui-nas-05#debug dialer
Dial on demand events debugging is on
maui-nas-05#show debug
General OS:
  Modem control/process activation debugging is on
Dial on demand:
  Dial on demand events debugging is on
Backup:
  Backup events debugging is on
PPP:
  PPP authentication debugging is on
  PPP protocol negotiation debugging is on
maui-nas-05#
*Mar 1 00:03:49.927 UTC: BACKUP(Serial3/0.1): event = primary went down
*Mar 1 00:03:49.927 UTC: BACKUP(Serial3/0.1): changed state to "waiting to back up"
*Mar 1 00:03:51.859 UTC: %LINK-3-UPDOWN: Interface Serial3/0, changed state to down
*Mar 1 00:03:52.863 UTC: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial3/0, changed
state to down
!--- Primary Link is down *Mar 1 00:03:54.927 UTC: BACKUP(Serial3/0.1): event = timer expired
*Mar 1 00:03:54.927 UTC: BACKUP(Serial3/0.1): secondary interface (Dialer1) made active *Mar 1
00:03:54.927 UTC: BACKUP(Serial3/0.1): changed state to "backup mode" *Mar 1 00:03:55.663 UTC:
As33 DDR: rotor dialout [priority] *Mar 1 00:03:55.663 UTC: As33 DDR: Dialing cause ip
(s=172.22.63.5, d=224.0.0.5) !--- interesting traffic causes dialout *Mar 1 00:03:55.663 UTC:
As33 DDR: Attempting to dial 10001
!--- Number to be dialed (PRI on maui-nas-02) *Mar 1 00:03:55.663 UTC: CHAT33: Attempting async
line dialer script *Mar 1 00:03:55.663 UTC: CHAT33: no matching chat script found for 10001 *Mar
1 00:03:55.663 UTC: CHAT33: Dialing using Modem script: d0efault-d0ials0cript & System script:
none !--- using default modem chat script *Mar 1 00:03:55.663 UTC: CHAT33: process started *Mar
1 00:03:55.663 UTC: CHAT33: Asserting DTR *Mar 1 00:03:55.663 UTC: CHAT33: Chat script d0efault-
d0ials0cript started *Mar 1 00:03:56.927 UTC: %LINK-3-UPDOWN: Interface Dialer1, changed state
to up
!--- Dialer interface is brought up *Mar 1 00:03:56.927 UTC: Dil LCP: Not allowed on a Dialer
Profile *Mar 1 00:03:56.927 UTC: BACKUP(Dialer1): event = primary came up *Mar 1 00:03:57.271
UTC: Modem 1/0 Mcom: in modem state 'Dialing/Answering' *Mar 1 00:04:06.671 UTC: Modem 1/0 Mcom:
in modem state 'Waiting for Carrier' *Mar 1 00:04:18.135 UTC: Modem 1/0 Mcom: in modem state
'Connected' *Mar 1 00:04:18.543 UTC: Modem 1/0 Mcom: CONNECT at 31200/33600(Tx/Rx), V34, LAPM,
V42bis, Originate *Mar 1 00:04:18.599 UTC: CHAT33: Chat script d0efault-d0ials0cript finished,
status = Success *Mar 1 00:04:18.599 UTC: Modem 1/0 Mcom: switching to PPP mode *Mar 1
00:04:18.599 UTC: TTY33: no timer type 1 to destroy *Mar 1 00:04:18.599 UTC: TTY33: no timer
type 0 to destroy *Mar 1 00:04:20.599 UTC: %LINK-3-UPDOWN: Interface Async33, changed state to
up Dialer statechange to up Async33 !--- Interface Async 33 is changed to state Up *Mar 1
00:04:20.599 UTC: %DIALER-6-BIND: Interface As33 bound to profile Dil Dialer call has been
placed Async33 *Mar 1 00:04:20.599 UTC: As33 PPP: Treating connection as a callout *Mar 1
00:04:20.599 UTC: As33 PPP: Phase is ESTABLISHING, Active Open *Mar 1 00:04:20.599 UTC: Modem
1/0 Mcom: PPP escape map: TX map = FFFFFFFF, Rx map = 0 !--- LCP Negotiation begins *Mar 1
00:04:20.599 UTC: As33 LCP: O CONFREQ [Closed] id 1 len 25 ... *Mar 1 00:04:22.599 UTC: As33
LCP: O CONFREQ [REQsent] id 2 Len 25 *... *Mar 1 00:04:22.743 UTC: As33 LCP: I CONFACK [REQsent]
id 2 Len 25 ... *Mar 1 00:04:24.599 UTC: As33 LCP: O CONFREQ [ACKrcvd] id 3 Len 25 ... *Mar 1
00:04:24.787 UTC: As33 LCP: I CONFACK [REQsent] id 3 Len 25 ... *Mar 1 00:04:24.795 UTC: As33
```

```
LCP: I CONFREQ [ACKrcvd] id 4 Len 25 ... *Mar 1 00:04:24.795 UTC: As33 LCP: O CONFACK [ACKrcvd]
id 4 Len 25 ... *Mar 1 00:04:24.795 UTC: As33 LCP: State is Open !--- LCP negotiation complete
*Mar 1 00:04:24.795 UTC: Modem 1/0 Mcom: PPP escape map: TX map = A0000, Rx map= 0 *Mar 1
00:04:24.799 UTC: As33 PPP: Phase is AUTHENTICATING, by both *Mar 1 00:04:24.799 UTC: As33 CHAP:
Using alternate hostname Maui-backup
*Mar 1 00:04:24.799 UTC: As33 CHAP: O CHALLENGE id 1 Len 32 from "Maui-backup"
*Mar 1 00:04:24.799 UTC: As33 AUTH: Started process 0 pid 51
*Mar 1 00:04:24.939 UTC: As33 CHAP: I CHALLENGE id 2 Len 32 from "maui-nas-02"
*Mar 1 00:04:24.939 UTC: As33 CHAP: Using alternate hostname Maui-backup
*Mar 1 00:04:24.939 UTC: As33 CHAP: O RESPONSE id 2 Len 32 from "Maui-backup"
*Mar 1 00:04:24.955 UTC: As33 CHAP: I RESPONSE id 1 Len 32 from "maui-nas-02"
*Mar 1 00:04:24.955 UTC: As33 CHAP: O SUCCESS id 1 Len 4
*Mar 1 00:04:25.079 UTC: As33 CHAP: I SUCCESS id 2 Len 4
!--- CHAP Authentication successful *Mar 1 00:04:25.079 UTC: As33 PPP: Phase is UP !--- IPCP
negotiation begins *Mar 1 00:04:25.079 UTC: As33 IPCP: O CONFREQ [Not negotiated] id 1 Len 10
*Mar 1 00:04:25.079 UTC: As33 IPCP: Address 172.22.63.5 (0x0306AC163F05) *Mar 1 00:04:25.087
UTC: As33 IPCP: I CONFREQ [REQsent] id 3 Len 16 *Mar 1 00:04:25.091 UTC: As33 IPCP: CompressType
VJ 15 slots (0x0206002D0F00) *Mar 1 00:04:25.091 UTC: As33 IPCP: Address 172.22.83.254
(0x0306AC1653FE) *Mar 1 00:04:25.091 UTC: As33 IPCP: O CONFREQ [REQsent] id 3 Len 10 *Mar 1
00:04:25.091 UTC: As33 IPCP: CompressType VJ 15 slots (0x0206002D0F00) *Mar 1 00:04:25.215 UTC:
As33 IPCP: I CONFNAK [REQsent] id 1 Len 10 *Mar 1 00:04:25.215 UTC: As33 IPCP: Address
172.22.83.41 (0x0306AC165329)
!--- IP address assigned to the dialin client from the address pool *Mar 1 00:04:25.215 UTC:
As33 IPCP: O CONFREQ [REQsent] id 2 Len 4 *Mar 1 00:04:25.219 UTC: As33 IPCP: I CONFREQ
[REQsent] id 4 Len 10 *Mar 1 00:04:25.219 UTC: As33 IPCP: Address 172.22.83.254 (0x0306AC1653FE)
*Mar 1 00:04:25.219 UTC: As33 IPCP: O CONFACK [REQsent] id 4 Len 10 *Mar 1 00:04:25.223 UTC:
As33 IPCP: Address 172.22.83.254 (0x0306AC1653FE) *Mar 1 00:04:25.331 UTC: As33 IPCP: I CONFACK
[ACKsent] id 2 Len 4 *Mar 1 00:04:25.331 UTC: As33 IPCP: State is Open
*Mar 1 00:04:25.331 UTC: As33 DDR: dialer protocol up
*Mar 1 00:04:25.331 UTC: As33 DDR: Call connected, 3 packets unqueued, 3 transmitted, 0
discarded
*Mar 1 00:04:25.331 UTC: Dial IPCP: Install route to 172.22.83.254
!--- Installing route to loopback address of maui-nas-02 *Mar 1 00:04:26.079 UTC: %LINEPROTO-5-
UPDOWN: Line protocol on Interface Async33, changed state to up
!--- Async connection is up
```

[Informations connexes](#)

- [Configurer le NAS pour l'accès commuté de base](#)
- [Exécutions](#)
- [Commandes OSPF](#)
- [Configuration de OSPF](#)
- [Support technique - Cisco Systems](#)