

# すべての Cisco ルータのバッファ チューニング

## 目次

[概要](#)

[前提条件](#)

[要件](#)

[使用するコンポーネント](#)

[表記法](#)

[概要](#)

[ローエンドプラットフォーム \(Cisco 1600、2500、および 4000 シリーズ ルータ\)](#)

[ハイエンドプラットフォーム \(ルート プロセッサ、スイッチ プロセッサ、シリコン スイッチ プロセッサ、およびルート/スイッチ プロセッサ\)](#)

[パーティクルベース プラットフォーム](#)

[バッファ チューニング](#)

[ファブリック バッファの予約](#)

[バッファ リーク](#)

[関連情報](#)

## 概要

このドキュメントでは、現在のプラットフォームに基づくバッファ チューニングの概要を示し、`show buffers` コマンドに関する一般情報を提供します。

## 前提条件

### 要件

このドキュメントに関する固有の要件はありません。

### 使用するコンポーネント

このドキュメントは、特定のソフトウェアやハードウェアのバージョンに限定されるものではありません。

このドキュメントの情報は、特定のラボ環境にあるデバイスに基づいて作成されたものです。このドキュメントで使用するすべてのデバイスは、クリアな (デフォルト) 設定で作業を開始しています。対象のネットワークが実稼働中である場合には、どのような作業についても、その潜在的な影響について確実に理解しておく必要があります。

### 表記法

ドキュメント表記の詳細は、『[シスコ テクニカル ティップスの表記法](#)』を参照してください。

## 概要

バッファ チューニングを使用すると、ルータが使用可能なメモリからバッファを割り当てる方法を変更して、トラフィックの一時的なバースト時にパケットがドロップされないようにできます。

使用しているルータのバッファをチューニングする必要があるかどうかを判別するには、`show interfaces` コマンドと `show buffers` コマンドを使用します。

`show interfaces` および `show buffers` コマンドの出力、か Cisco デバイスからの `show technical-support` の出力が ( イネーブル モードから ) あれば、潜在的な問題および修正を表示するのに [Cisco CLI アナライザ](#)を使用できます。 [Cisco CLI アナライザ](#)を使用するために、[登録 ユーザ](#)である必要がありログオンされ、JavaScript を有効にしてもらいます。

`show interfaces` コマンドの出力例を次に示します。

```
Output queue 0/40, 1041 drops; input queue 0/75, 765 drops
35252345 packets input, 547082589 bytes, 940 no buffer
```

- インプットドロップおよびアウトプットドロップは、トラフィックのバーストによって入出力キューがあふれることが原因です。これはバッファの問題には関係なく、むしろプロセス交換のパフォーマンスの制限に関係します。
- 「No buffer」は、パケットをコピーする空きバッファがないために廃棄されたパケットの数を示します。

`show buffers` コマンドを使用して、インターフェイスの Maximum Transmission Unit ( MTU; 最大伝送ユニット ) に対応するバッファ サイズを確認します。

```
Output queue 0/40, 1041 drops; input queue 0/75, 765 drops
35252345 packets input, 547082589 bytes, 940 no buffer
```

次の表で出力を説明します。

### キーワード 説明

全体の	プール内のバッファ総数 ( 使用済みバッファと未使用バッファの両方を含む )。
permanent	プール内に固定で割り当てられるバッファ数。これらのバッファは常にプール内に存在して
in free list	プール内で現在利用可能な空きバッファの数。
最小	ルータが「in free list」を保持する必要があるバッファの最小数。「in free list」のバッファ数 ルータに対してさらにバッファを作成する必要があります。
max	「in free list」で使用できるバッファの最大数。「in free list」のバッファ数が「max allowed
allowed	アを削除する必要があります。
hits	空きリストから正常に割り当てられたバッファの数。
misses	バッファが要求されたときに、空きリストに利用可能なバッファがない、または空きリスト
trims	「in free list」のバッファ数が「max allowed」のバッファ数を上回る場合に、プールから削除
created	「in free list」のバッファ数が「min」より少ない場合にプールで作成されたバッファの数。
no memory	ルータが新しいバッファを作成しようとしたが、ルータ内の空きメモリが十分ではなかった
failures	割り込み時にリクエストにバッファを付与できなかった数 ( ルータはプロセススイッチング memory」でない限り「failure」は発生しない )。「failures」の数は、バッファ不足のため

### ルータによるバッファの処理方法

「in free list」のバッファ数は、使用可能なバッファの数です。バッファ要求が発生すると、「in free list」からバッファが割り当てられます。

IOS バッファは、主に次の 2 つの理由で使用されます。

- ルータで終端するトラフィックを処理するため。
- パケットがプロセス スイッチングされている場合。

使用可能なバッファがなく、ファースト スイッチングが有効だと、バッファ failure が発生し、パケットがドロップされます。バッファ プール マネージャ プロセスがバッファ failure を検出すると、さらに failure が発生しないように新しいバッファが「作成」されます。

「in free list」の数値が「max allowed」値と同じ場合、ルータは新しいバッファを作成しません。新しいバッファを作成するために十分なメモリがルータにない場合、「no memory」として記録されます。「in free list」の数が「max allowed」の数よりも大きい場合、ルータによって過剰なバッファが一部削除されます。

注意する点は、「failures」と「no memory」の数だけです。failure は発生する可能性があります、これはしばらくして安定します。ルータは必要に応じてバッファを作成または削除して、failure の数を安定させます。failure の数が増加し続ける場合は、バッファのチューニングが必要になる可能性があります。

新しいバッファを作成するために十分なメモリがない場合は、[バッファリーク](#)または[一般的なメモリ障害](#)がないか確認してください。ファースト スイッチング パスではバッファは作成されないため、ルータがパケットのファースト スイッチングを実行しようとした場合に使用できるバッファがないと、パケットがドロップされ、failure が報告されます。次回、バッファ プール マネージャが実行されたときに新しいバッファが作成されます。

## ローエンド プラットフォーム ( Cisco 1600、2500、および 4000 シリーズ ルータ )

ファーストスイッチ パケットとプロセススイッチパケットは、同じバッファを共有します。これらのバッファは、共有メモリにあります。共有メモリは Cisco 1600 および 2500 シリーズ ルータではダイナミック RAM ( DRAM ) に、あるいは Cisco 4000、4500、および 4700 シリーズ ルータでは共有 RAM ( SRAM ) にあります。

**show memory** コマンドの最初の行から、共有メモリの容量、現在の使用量、および最低ポイントがわかります。パケットをファースト スイッチできない場合、プロセススイッチのインプットキューにパケットへのポインタが挿入されますが、パケット自体はコピーされません。

次に、ローエンド プラットフォーム ( Cisco 4500 ) での**show buffers** コマンド出力を示します。

```
router# show buffers

Buffer elements:
  471 in free list (500 max allowed)
  870696495 hits, 0 misses, 0 created

Public buffer pools:
Small buffers, 104 bytes (total 50, permanent 50):
  49 in free list (20 min, 150 max allowed)
  27301678 hits, 23 misses, 20 trims, 20 created
  0 failures (0 no memory)
Middle buffers, 600 bytes (total 150, permanent 25):
  147 in free list (10 min, 150 max allowed)
  61351931 hits, 137912 misses, 51605 trims, 51730 created
  91652 failures (0 no memory)
Big buffers, 1524 bytes (total 67, permanent 50):
  67 in free list (5 min, 150 max allowed)
  46293638 hits, 455 misses, 878 trims, 895 created
  0 failures (0 no memory)
VeryBig buffers, 4520 bytes (total 96, permanent 10):
```

```
79 in free list (0 min, 100 max allowed)
11818351 hits, 246 misses, 98 trims, 184 created
243 failures (0 no memory)
Large buffers, 5024 bytes (total 10, permanent 0):
10 in free list (0 min, 10 max allowed)
4504003 hits, 873040 misses, 759543 trims, 759553 created
873040 failures (0 no memory)
Huge buffers, 18024 bytes (total 0, permanent 0):
0 in free list (0 min, 4 max allowed)
0 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
```

#### Interface buffer pools:

```
TokenRing0 buffers, 4516 bytes (total 48, permanent 48):
0 in free list (0 min, 48 max allowed)
3099742 hits, 9180771 fallbacks
16 max cache size, 1 in cache
TokenRing1 buffers, 4516 bytes (total 48, permanent 48):
0 in free list (0 min, 48 max allowed)
335172 hits, 403668 fallbacks
16 max cache size, 16 in cache
Serial1 buffers, 1524 bytes (total 96, permanent 96):
63 in free list (0 min, 96 max allowed)
33 hits, 0 fallbacks
0 max cache size, 0 in cache
Serial2 buffers, 1524 bytes (total 96, permanent 96):
63 in free list (0 min, 96 max allowed)
701370936 hits, 268 fallbacks
0 max cache size, 0 in cache
Serial3 buffers, 1524 bytes (total 96, permanent 96):
63 in free list (0 min, 96 max allowed)
33 hits, 0 fallbacks
0 max cache size, 0 in cache
Serial0 buffers, 4546 bytes (total 96, permanent 96):
28 in free list (0 min, 96 max allowed)
346854 hits, 5377043 fallbacks
32 max cache size, 27 in cache
```

インターフェイス バッファ プールは、入出力 (I/O) のインターフェイスで使用されます。インターフェイス バッファの空きリストにバッファがそれ以上ない場合、ルータはフォールバックとしてパブリック バッファ プールに移動します。フォールバックによるパフォーマンスへの影響はありません。

キャッシングとは、一部のオーバーヘッドをバイパスすることによって、割り込みレベル ドライバ コードがバッファを速く使用できるようにするソフトウェア操作です。

注: 通常、インターフェイス バッファはチューニングしないでください。

## ハイエンド プラットフォーム ( ルート プロセッサ、スイッチ プロセッサ、シリコン スイッチ プロセッサ、およびルート/スイッチ プロセッサ )

ハイエンド プラットフォームでの **show buffers** コマンドの出力を次に示します。

```
Router# show buffers
```

```
Buffer elements:
498 in free list (500 max allowed)
326504974 hits, 0 misses, 0 created
```

```
Public buffer pools:
Small buffers, 104 bytes (total 150, permanent 150):
  140 in free list (30 min, 250 max allowed)
  564556247 hits, 148477066 misses, 16239797 trims, 16239797 created
  29356200 failures (0 no memory)
Middle buffers, 600 bytes (total 120, permanent 120):
  116 in free list (20 min, 200 max allowed)
  319750574 hits, 85689239 misses, 9671164 trims, 9671164 created
  26050704 failures (0 no memory)
Big buffers, 1524 bytes (total 100, permanent 100):
  98 in free list (10 min, 300 max allowed)
  20130595 hits, 14796572 misses, 251916 trims, 251916 created
  11813639 failures (0 no memory)
VeryBig buffers, 4520 bytes (total 15, permanent 15):
  14 in free list (5 min, 300 max allowed)
  22966334 hits, 3477687 misses, 13113 trims, 13113 created
  2840089 failures (0 no memory)
Large buffers, 5024 bytes (total 12, permanent 12):
  12 in free list (0 min, 30 max allowed)
  849034 hits, 1979463 misses, 1028 trims, 1028 created
  1979456 failures (0 no memory)
Huge buffers, 18024 bytes (total 6, permanent 5):
  4 in free list (2 min, 13 max allowed)
  338440 hits, 1693496 misses, 1582 trims, 1583 created
  1640218 failures (0 no memory)
```

## ヘッダー プール

パブリック バッファ プールは DRAM にあり、システム バッファと呼ばれています。Route/Switch Processor ( RSP; ルート/スイッチ プロセッサ ) 上の共有メモリは、システム パケット メモリ ( MEMD ) と呼ばれ、2 MB のメモリが使用できます。Route Processor ( RP; ルート プロセッサ ) と Switch Processor ( SP; スイッチ プロセッサ ) ( または Silicon Switch Processor ( SSP; シリコン スイッチ プロセッサ ) ) では、システム バッファは RP 上にあり、MEMD は SP ( または SSP ) にあります。

パケットが着信すると、そのパケットは受信側インターフェイス プロセッサにより MEMD に保存されます ( 多用途インターフェイス プロセッサ ( VIP ) の場合を除きます )。ファースト スイッチできない場合は、パケット全体が DRAM のシステム バッファにコピーされます。したがって、**show buffers** コマンドで表示されるバッファは、DRAM 内のシステム バッファです。

[show controllers cbus コマンドは、MEMD 内のインターフェイス バッファを表示します。](#) インターフェイス バッファをチューニングすることはお勧めしません。パケットをファースト スイッチできず、システム バッファにコピーされる場合、使用できるシステム バッファがなければ、パケットはドロップされ、failure がカウントされます。

## パーティクルベース プラットフォーム

Cisco 3600 および 7200 シリーズ ルータは、パーティクルを使用します。インターフェイス バッファは、パケットが分割されるパーティクルと呼ばれるアトミック バッファです。パケットがファースト スイッチできない場合、ルータはシステム バッファの 1 つにそのパケットを再構成する必要があります。これはプロセス交換コードではパーティクルを処理できないためです。

Cisco 3600 での **show buffers** コマンドの出力を次に示します。

```
Router# show buffers
Buffer elements:
  499 in free list (500 max allowed)
```

136440 hits, 0 misses, 0 created

Public buffer pools:

Small buffers, 104 bytes (total 50, permanent 50):

49 in free list (20 min, 150 max allowed)

4069435 hits, 141 misses, 73 trims, 73 created

52 failures (0 no memory)

Middle buffers, 600 bytes (total 25, permanent 25):

25 in free list (10 min, 150 max allowed)

628629 hits, 21 misses, 21 trims, 21 created

3 failures (0 no memory)

Big buffers, 1524 bytes (total 50, permanent 50):

50 in free list (5 min, 150 max allowed)

9145 hits, 0 misses, 0 trims, 0 created

0 failures (0 no memory)

VeryBig buffers, 4520 bytes (total 10, permanent 10):

10 in free list (0 min, 100 max allowed)

0 hits, 0 misses, 0 trims, 0 created

0 failures (0 no memory)

Large buffers, 5024 bytes (total 0, permanent 0):

0 in free list (0 min, 10 max allowed)

0 hits, 0 misses, 0 trims, 0 created

0 failures (0 no memory)

Huge buffers, 18024 bytes (total 0, permanent 0):

0 in free list (0 min, 4 max allowed)

0 hits, 0 misses, 0 trims, 0 created

0 failures (0 no memory)

Interface buffer pools:

CD2430 I/O buffers, 1524 bytes (total 0, permanent 0):

0 in free list (0 min, 0 max allowed)

0 hits, 0 fallbacks

Header pools:

Header buffers, 0 bytes (total 265, permanent 256):

9 in free list (10 min, 512 max allowed)

253 hits, 3 misses, 0 trims, 9 created

0 failures (0 no memory)

256 max cache size, 256 in cache

Particle Clones:

1024 clones, 0 hits, 0 misses

Public particle pools:

F/S buffers, 256 bytes (total 384, permanent 384):

128 in free list (128 min, 1024 max allowed)

256 hits, 0 misses, 0 trims, 0 created

0 failures (0 no memory)

256 max cache size, 256 in cache

Normal buffers, 1548 bytes (total 512, permanent 512):

356 in free list (128 min, 1024 max allowed)

188 hits, 0 misses, 0 trims, 0 created

0 failures (0 no memory)

128 max cache size, 128 in cache

Private particle pools:

Ethernet0/0 buffers, 1536 bytes (total 96, permanent 96):

0 in free list (0 min, 96 max allowed)

96 hits, 0 fallbacks

96 max cache size, 64 in cache

Serial0/0 buffers, 1548 bytes (total 14, permanent 14):

0 in free list (0 min, 14 max allowed)

14 hits, 0 fallbacks

```
14 max cache size, 14 in cache
BRI0/0 buffers, 1548 bytes (total 14, permanent 14):
  0 in free list (0 min, 14 max allowed)
  14 hits, 0 fallbacks
  14 max cache size, 14 in cache
BRI0/0:1 buffers, 1548 bytes (total 14, permanent 14):
  0 in free list (0 min, 14 max allowed)
  14 hits, 0 fallbacks
  14 max cache size, 14 in cache
BRI0/0:2 buffers, 1548 bytes (total 14, permanent 14):
  0 in free list (0 min, 14 max allowed)
  14 hits, 0 fallbacks
  14 max cache size, 14 in cache
TokenRing0/0 buffers, 1548 bytes (total 64, permanent 64):
  0 in free list (0 min, 64 max allowed)
  64 hits, 0 fallbacks
  64 max cache size, 64 in cache
  4 buffer threshold, 0 threshold transitions
```

専用パーティクルプールはインターフェイスによって使用されるため、チューニングしないでください。空きリストに使用可能なバッファがない場合、ルータはパブリックパーティクルプールを使います。

ヘッダーバッファは、パケットに属するすべてのパーティクルのリストを記録するために使用されます。

注: システムバッファは、プロセススイッチングに使用されます。Cisco 3600では、これらのバッファはすべて、DRAM内のI/Oメモリにあります。I/Oメモリの量は、[memory-size iomem](#) コマンドを使用して指定できます。Cisco 7200では、広帯域Port Adapter (PA; ポートアダプタ)用のインターフェイスパーティクルバッファプールは、SRAM内にあります。

## バッファチューニング

`show buffers` コマンドの例を次に示します。

```
Router# show buffers
Buffer elements:
  499 in free list (500 max allowed)
  136440 hits, 0 misses, 0 created

Public buffer pools:
Small buffers, 104 bytes (total 50, permanent 50):
  49 in free list (20 min, 150 max allowed)
  4069435 hits, 141 misses, 73 trims, 73 created
  52 failures (0 no memory)
Middle buffers, 600 bytes (total 25, permanent 25):
  25 in free list (10 min, 150 max allowed)
  628629 hits, 21 misses, 21 trims, 21 created
  3 failures (0 no memory)
Big buffers, 1524 bytes (total 50, permanent 50):
  50 in free list (5 min, 150 max allowed)
  9145 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
VeryBig buffers, 4520 bytes (total 10, permanent 10):
  10 in free list (0 min, 100 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
Large buffers, 5024 bytes (total 0, permanent 0):
  0 in free list (0 min, 10 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
```

```
0 failures (0 no memory)
Huge buffers, 18024 bytes (total 0, permanent 0):
0 in free list (0 min, 4 max allowed)
0 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)

Interface buffer pools:
CD2430 I/O buffers, 1524 bytes (total 0, permanent 0):
0 in free list (0 min, 0 max allowed)
0 hits, 0 fallbacks

Header pools:
Header buffers, 0 bytes (total 265, permanent 256):
9 in free list (10 min, 512 max allowed)
253 hits, 3 misses, 0 trims, 9 created
0 failures (0 no memory)
256 max cache size, 256 in cache

Particle Clones:
1024 clones, 0 hits, 0 misses

Public particle pools:
F/S buffers, 256 bytes (total 384, permanent 384):
128 in free list (128 min, 1024 max allowed)
256 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
256 max cache size, 256 in cache
Normal buffers, 1548 bytes (total 512, permanent 512):
356 in free list (128 min, 1024 max allowed)
188 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
128 max cache size, 128 in cache

Private particle pools:
Ethernet0/0 buffers, 1536 bytes (total 96, permanent 96):
0 in free list (0 min, 96 max allowed)
96 hits, 0 fallbacks
96 max cache size, 64 in cache
Serial0/0 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache
BRI0/0 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache
BRI0/0:1 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache
BRI0/0:2 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache
TokenRing0/0 buffers, 1548 bytes (total 64, permanent 64):
0 in free list (0 min, 64 max allowed)
64 hits, 0 fallbacks
64 max cache size, 64 in cache
4 buffer threshold, 0 threshold transitions
```

この例では、ミドルバッファに多数の failure があります。これは重大な問題ではありません。この数値はヒットのわずか 0.1% に過ぎないからです。これらの数値は、バッファ チューニングによって簡単に改善できます。



バッファ チューニングが行われるのは、パケットの CEF スイッチができない場合のみです。

チューニングするバッファは通常、ルータのアーキテクチャに応じて、I/O メモリ ( ローエンド ) またはメイン メモリ ( ハイエンド ) のいずれかに属しています。バッファをチューニングする前に、まず **show memory** コマンドの最初の行で、I/O メモリまたはメイン メモリに十分な空き容量があるかどうかを確認します。

使用できる一般的な値を次に示します。

- **permanent** : プール内のバッファ総数に、約 20 % を追加します。
- **min-free** : プール内で permanent に割り当てられたバッファ数の約 20 ~ 30 % を min-free に設定します。
- **max-free** : permanent と minimum の合計より大きな値を max-free に設定します。

上記のバッファ チューニングの例では、グローバル コンフィギュレーション モードで次のコマンドを入力できます。

```
Router# show buffers
Buffer elements:
  499 in free list (500 max allowed)
  136440 hits, 0 misses, 0 created

Public buffer pools:
Small buffers, 104 bytes (total 50, permanent 50):
  49 in free list (20 min, 150 max allowed)
  4069435 hits, 141 misses, 73 trims, 73 created
  52 failures (0 no memory)
Middle buffers, 600 bytes (total 25, permanent 25):
  25 in free list (10 min, 150 max allowed)
  628629 hits, 21 misses, 21 trims, 21 created
  3 failures (0 no memory)
Big buffers, 1524 bytes (total 50, permanent 50):
  50 in free list (5 min, 150 max allowed)
  9145 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
VeryBig buffers, 4520 bytes (total 10, permanent 10):
  10 in free list (0 min, 100 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
Large buffers, 5024 bytes (total 0, permanent 0):
  0 in free list (0 min, 10 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
Huge buffers, 18024 bytes (total 0, permanent 0):
  0 in free list (0 min, 4 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)

Interface buffer pools:
CD2430 I/O buffers, 1524 bytes (total 0, permanent 0):
  0 in free list (0 min, 0 max allowed)
  0 hits, 0 fallbacks

Header pools:
Header buffers, 0 bytes (total 265, permanent 256):
  9 in free list (10 min, 512 max allowed)
  253 hits, 3 misses, 0 trims, 9 created
  0 failures (0 no memory)
  256 max cache size, 256 in cache

Particle Clones:
```

1024 clones, 0 hits, 0 misses

Public particle pools:

F/S buffers, 256 bytes (total 384, permanent 384):

128 in free list (128 min, 1024 max allowed)

256 hits, 0 misses, 0 trims, 0 created

0 failures (0 no memory)

256 max cache size, 256 in cache

Normal buffers, 1548 bytes (total 512, permanent 512):

356 in free list (128 min, 1024 max allowed)

188 hits, 0 misses, 0 trims, 0 created

0 failures (0 no memory)

128 max cache size, 128 in cache

Private particle pools:

Ethernet0/0 buffers, 1536 bytes (total 96, permanent 96):

0 in free list (0 min, 96 max allowed)

96 hits, 0 fallbacks

96 max cache size, 64 in cache

Serial0/0 buffers, 1548 bytes (total 14, permanent 14):

0 in free list (0 min, 14 max allowed)

14 hits, 0 fallbacks

14 max cache size, 14 in cache

BRI0/0 buffers, 1548 bytes (total 14, permanent 14):

0 in free list (0 min, 14 max allowed)

14 hits, 0 fallbacks

14 max cache size, 14 in cache

BRI0/0:1 buffers, 1548 bytes (total 14, permanent 14):

0 in free list (0 min, 14 max allowed)

14 hits, 0 fallbacks

14 max cache size, 14 in cache

BRI0/0:2 buffers, 1548 bytes (total 14, permanent 14):

0 in free list (0 min, 14 max allowed)

14 hits, 0 fallbacks

14 max cache size, 14 in cache

TokenRing0/0 buffers, 1548 bytes (total 64, permanent 64):

0 in free list (0 min, 64 max allowed)

64 hits, 0 fallbacks

64 max cache size, 64 in cache

4 buffer threshold, 0 threshold transitions

通常、Cisco IOS® ソフトウェアはこれらの設定がうまくあるようにバッファを動的に作成します。ただし、バーストトラフィックの場合、ルータには新しいバッファを作成するだけの時間がない可能性があるため、failure の数が増加し続けることがあります。デフォルトのバッファプール設定を変更するには、**buffers** コマンドを使用します。バッファの設定が不適切な場合、システムのパフォーマンスに影響が出る可能性があるため、バッファ値の変更は慎重に行ってください。バッファカウンタをクリアする場合は、ルータをリロードする必要があります。

バーストトラフィックには 2 種類あります。

- スローバースト：この場合、ルータには新しいバッファを作成するのに十分な時間があります。min-free バッファの数を増やします。空きバッファを使用することにより、min-free の値を確保し、新しいバッファを作成できます。
- ファーストバースト：ファーストバーストの場合、ルータには新しいバッファを作成するのに十分な時間がないため、空きバッファを使用する必要があります。この場合は、固定バッファの数を変更します。

**結論：**初期チューニング後に create カウンタが増加した場合は、min-free を大きくします (スローバースト)。failure カウンタが増加して、create カウンタが増加しない場合 (ファーストバースト) は、permanent 値を大きくします。

## ファブリック バッファの予約

`fabric buffer-reserve` コマンドを入力することにより、システムのスループットを改善し、ASIC バッファを予約できます。

このコマンドは、次のモジュールでサポートされています。

- WS-X6704-10GE
- WS-X6748-SFP
- WS-X6748-GE-TX
- WS-X6724-SFP

このコマンドは、Supervisor Engine 32 が構成されている Cisco 7600 シリーズ ルータではサポートされません。

`fabric buffer-reserve [high | low | medium | value]`

注意：このコマンドは、Cisco TAC の指示でのみ使用してください。

このコマンドが役立つ一般的な状況を次に示します。

- 複数のインターフェイスで回線プロトコルがダウンする場合
- 複数のインターフェイスでオーバーランが発生している場合
- ポートで EtherChannel との Join と Leave が頻繁に発生する場合
- DFC を備えたラインカードで TestMacNotification テストが繰り返し失敗する場合

## バッファ リーク

`show buffers` コマンドの出力例を次に示します。

`fabric buffer-reserve [high | low | medium | value]`

この出力は、ビッグ バッファ プールのバッファリークを示します。ルータには合計で 1556 のビッグ バッファがあり、そのうち 52 のみが空きリストにあります。何らかの原因ですべてのバッファが使用され、バッファが解放されていません。バッファリークの詳細は、『[トラブルシューティング：バッファリーク](#)』を参照してください。

## 関連情報

- [メモリの問題に関するトラブルシューティング](#)
- [バッファリークのトラブルシューティング](#)
- [基本的なシステム管理コマンド](#)
- [システム バッファ サイズの変更](#)
- [テクニカルサポート - Cisco Systems](#)