

Procedimento de recuperação de senha para os Cisco 2600 e 2800 Series Router

Índice

[Introdução](#)

[Pré-requisitos](#)

[Requisitos](#)

[Componentes Utilizados](#)

[Produtos Relacionados](#)

[Convenções](#)

[Procedimentos Passo a Passo](#)

[Procedimento 1](#)

[Procedimento 2](#)

[Exemplo de procedimento de recuperação de senha](#)

[Informações Relacionadas](#)

[Introdução](#)

Este documento descreve como recuperar as senhas **enable password** e **enable secret**. Essas senhas protegem o acesso aos modos EXEC privilegiado e de configuração. A senha **enable password** pode ser recuperada, mas a senha **enable secret** é criptografada e deve ser substituída por uma nova senha. Utilize o procedimento descrito neste documento para substituir a **senha enable secret**.

[Pré-requisitos](#)

[Requisitos](#)

Não existem requisitos específicos para este documento.

[Componentes Utilizados](#)

As informações neste documento são baseadas nas seguintes versões de hardware:

- Cisco 2600 Series Router
- Cisco 2800 Series Router

As informações neste documento foram criadas a partir de dispositivos em um ambiente de laboratório específico. Todos os dispositivos utilizados neste documento foram iniciados com uma configuração (padrão) inicial. Se a sua rede estiver ativa, certifique-se de que entende o impacto potencial de qualquer comando.

[Produtos Relacionados](#)

Consulte [Procedimentos de Recuperação de Senhas](#) para obter informações sobre como recuperar senhas para os produtos relacionados.

[Convenções](#)

Consulte as [Convenções de Dicas Técnicas da Cisco](#) para obter informações sobre convenções de documentos.

[Procedimentos Passo a Passo](#)

Esta seção descreve dois procedimentos para recuperar suas senhas.

[Procedimento 1](#)

Conclua estes passos para recuperar a sua senha:

1. Conecte um terminal ou PC com emulação de terminal à porta de console do roteador. Utilize estas configurações de terminal: taxa de baud 9600 Sem paridade 8 bits de dados 1 bit de parada Nenhum controle de fluxo Consulte estes documentos para obter informações sobre como cabear e conectar um terminal à porta de console ou à porta AUX: [Manual de cabeamento para console e portas AUX](#) [Conexão de um Terminal à Porta de Console dos Switches Catalyst](#) [Conexão de um Terminal aos Catalyst 2948G-L3, 4908G-L3 e 4840G Series Switches](#)
2. Se você puder acessar o roteador, digite **show version** no prompt e registre a opção de registro de configuração. Consulte [Exemplo de Procedimento de Recuperação de Senhas](#) para exibir a saída de um **comando show version**. **Nota:** O registro de configuração é geralmente definido como 0x2102 ou 0x102. Se você não for mais capaz de acessar o roteador (devido a um login ou senha de TACACS esquecidos), poderá afirmar com segurança que seu registro de configuração está definido como 0x2102.
3. Use a chave liga/desliga para desligar o roteador. Em seguida, ligue-o novamente. **Notas Importantes:** Para simular este passo em um Cisco 6400, remova e reinsira a placa Node Route Processor (NRP) ou Node Switch Processor (NSP). Para simular este passo em um Cisco 6x00 com NI-2, remova e reinsira a placa NI-2.
4. Pressione a **ruptura** no teclado terminal dentro de 60 segundos da potência a fim colocar o roteador em ROMmon. Se a sequência de interrupção não funcionar, consulte [Combinações de Sequências de Teclas de Interrupção Padrão Durante a Recuperação de Senhas](#) para obter outras combinações de chaves.
5. Digite **confreg 0x2142** no prompt rommon 1> para inicializar da Flash. Este passo ignora a configuração de inicialização onde as senhas são armazenadas.
6. Digite **reset** no prompt rommon 2>. O roteador é reinicializado, mas ignora a configuração salva.
7. Digite **no** após cada pergunta de instalação ou pressione **Ctrl-C** para pular o procedimento de configuração inicial.
8. Digite **enable** no prompt Router>. Você está no modo enable e deve ver o prompt Router#.
9. Digite **configure memory** ou **copy startup-config running-config** para copiar a RAM não volátil

(NVRAM) para a memória. **aviso:** Não digite **copy running-config startup-config** ou **write**. Esses comandos apagam sua configuração de inicialização.

10. Digite **show running-config**. O comando **show running-config** exibe a configuração do roteador. Nesta configuração, o comando **shutdown** é mostrado em todas as interfaces, o que indica que todas as configurações estão desativadas no momento. Além disso, as senhas (enable password, enable secret, vty, console) podem estar em um formato criptografado ou não criptografado. Você pode reutilizar senhas não criptografadas. No entanto, as senhas criptografadas devem ser alteradas para um novo valor.
11. Digite **configure terminal**. O prompt **hostname(config)#** é exibido.
12. Digite **enable secret <password>** para alterar a senha **enable secret**. Por exemplo:

```
hostname(config)#enable secret cisco
```
13. Execute o comando **no shutdown** em cada interface usada. Se você executar um comando **show ip interface brief**, todas as interfaces que você desejar usar deverão exibir *up up*.
14. Digite **config-register <configuration_register_setting>**. Onde **configuration_register_setting** é o valor que você registrou no passo 2 ou **0x2102**. Por exemplo:

```
hostname(config)#config-register 0x2102
```
15. Pressione **Ctrl-z** ou **end** para sair do modo de configuração. O prompt **hostname#** é exibido.
16. Digite **write memory** ou **copy running-config startup-config** para confirmar as alterações.

Procedimento 2

Conclua estes passos para recuperar a sua senha:

1. Encerre o roteador.
2. Remova a memória flash compacta que está na parte traseira do roteador.
3. Ligue o roteador.
4. Quando a indicação **Rommon1>** aparecer, insira este comando:

```
confreg 0x2142
```

5. Insira a memória flash compacta.
6. Digite **reset**.
7. Quando é solicitado que você *ingresse a configuração inicial*, digite **No** e pressione **Enter**.
8. Na indicação **Router>**, digite **enable**.
9. Na indicação **Router#**, insira o **comando configure memory** e pressione **Enter** para copiar a configuração de inicialização na configuração de execução.
10. Utilize o **comando config t** para ingressar o modo de configuração global.
11. Utilize este comando para criar um nome e senha de novo usuário:

```
router(config)#username cisco privilege 15 password  
cisco
```

12. Utilize este comando para mudar a instrução de inicialização:

```
config-register  
0x2102
```

13. Utilize este comando para salvar a configuração:

```
write
memory
```

14. Reinicialize o roteador e, em seguida, utilize o nome e a senha do novo usuário para entrar no roteador.

[Exemplo de procedimento de recuperação de senha](#)

Esta seção fornece um exemplo do procedimento de recuperação de senhas. Esse exemplo foi criado com um Cisco 2600 Series Router. Mesmo se você não utiliza um Cisco 2600 Series Router, a saída fornece um exemplo do que você deve encontrar em seu produto.

```
Router>enable
Password:
Password:
Password:
% Bad secrets
```

```
Router>show version
Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Tue 07-Dec-99 02:21 by phanguye
Image text-base: 0x80008088, data-base: 0x80C524F8
```

```
ROM: System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE (fc1)
```

```
Router uptime is 3 minutes
System returned to ROM by abort at PC 0x802D0B60
System image file is "flash:c2600-is-mz.120-7.T"
```

```
cisco 2611 (MPC860) processor (revision 0x202) with 26624K/6144K bytes of memory.
Processor board ID JAB031202NK (3878188963)
M860 processor: part number 0, mask 49
Bridging software.
X.25 software, Version 3.0.0.
Basic Rate ISDN software, Version 1.1.
2 Ethernet/IEEE 802.3 interface(s)
2 Serial(sync/async) network interface(s)
1 ISDN Basic Rate interface(s)
32K bytes of non-volatile configuration memory.
8192K bytes of processor board System flash partition 1 (Read/Write)
8192K bytes of processor board System flash partition 2 (Read/Write)
```

```
Configuration register is 0x2102
```

```
Router>
```

```
!--- The router was just powercycled, and during bootup a !--- break sequence was sent to the
router. ! *** System received an abort due to Break Key *** signal= 0x3, code= 0x500, context=
0x813ac158 PC = 0x802d0b60, Vector = 0x500, SP = 0x80006030 rommon 1 > confreg 0x2142
```

You must reset or power cycle for new config to take effect

```
rommon 2 > reset
```

```
System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE (fc1)
Copyright (c) 1999 by cisco Systems, Inc.
```

TAC:Home:SW:IOS:Specials for info
C2600 platform with 32768 Kbytes of main memory

program load complete, entry point: 0x80008000, size: 0x6fdb4c

Self decompressing the image : #####

[OK]

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) of the Commercial Computer Software - Restricted Rights clause at FAR sec. 52.227-19 and subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS sec. 252.227-7013.

cisco Systems, Inc.
170 West Tasman Drive
San Jose, California 95134-1706

Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Tue 07-Dec-99 02:21 by phanguye
Image text-base: 0x80008088, data-base: 0x80C524F8

cisco 2611 (MPC860) processor (revision 0x202) with 26624K/6144K bytes of memory.
Processor board ID JAB031202NK (3878188963)
M860 processor: part number 0, mask 49
Bridging software.
X.25 software, Version 3.0.0.
Basic Rate ISDN software, Version 1.1.
2 Ethernet/IEEE 802.3 interface(s)
2 Serial(sync/async) network interface(s)
1 ISDN Basic Rate interface(s)
32K bytes of non-volatile configuration memory.
8192K bytes of processor board System flash partition 1 (Read/Write)
8192K bytes of processor board System flash partition 2 (Read/Write)

--- System Configuration Dialog ---

Would you like to enter the initial configuration dialog? [yes/no]: **n**

Press RETURN to get started!

00:00:19: %LINK-3-UPDOWN: Interface BRI0/0, changed state to up
00:00:19: %LINK-3-UPDOWN: Interface Ethernet0/0, changed state to up
00:00:19: %LINK-3-UPDOWN: Interface Ethernet0/1, changed state to up
00:00:19: %LINK-3-UPDOWN: Interface Serial0/0, changed state to down
00:00:19: %LINK-3-UPDOWN: Interface Serial0/1, changed state to down
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface BRI0/0,
changed state to down
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0,
changed state to up
Router>
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/1,
changed state to up

```

00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0,
changed state to down
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/1,
changed state to down
00:00:50: %SYS-5-RESTART: System restarted --
Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Tue 07-Dec-99 02:21 by phanguye
00:00:50: %LINK-5-CHANGED: Interface BRI0/0,
changed state to administratively down
00:00:52: %LINK-5-CHANGED: Interface Ethernet0/0,
changed state to administratively down
00:00:52: %LINK-5-CHANGED: Interface Serial0/0,
changed state to administratively down
00:00:52: %LINK-5-CHANGED: Interface Ethernet0/1,
changed state to administratively down
00:00:52: %LINK-5-CHANGED: Interface Serial0/1,
changed state to administratively down
00:00:53: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0,
changed state to down
00:00:53: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/1,
changed state to down
Router>
Router>enable
Router#copy startup-config running-config
Destination filename [running-config]?
1324 bytes copied in 2.35 secs (662 bytes/sec)
Router#
00:01:24: %LINEPROTO-5-UPDOWN: Line protocol on Interface BRI0/0:1,
changed state to down
00:01:24: %LINEPROTO-5-UPDOWN: Line protocol on Interface BRI0/0:2,
changed state to down
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#enable secret < password >
Router(config)#^Z
00:01:54: %SYS-5-CONFIG_I: Configured from console by console
Router#show ip interface brief

```

Interface	IP-Address	OK?	Method	Status	Protocol
Ethernet0/0	10.200.40.37	YES	TFTP	administratively down	down
Serial0/0	unassigned	YES	TFTP	administratively down	down
BRI0/0	193.251.121.157	YES	unset	administratively down	down
BRI0/0:1	unassigned	YES	unset	administratively down	down
BRI0/0:2	unassigned	YES	unset	administratively down	down
Ethernet0/1	unassigned	YES	TFTP	administratively down	down
Serial0/1	unassigned	YES	TFTP	administratively down	down
Loopback0	193.251.121.157	YES	TFTP	up	up

```

Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#interface Ethernet0/0
Router(config-if)#no shutdown
Router(config-if)#
00:02:14: %LINK-3-UPDOWN: Interface Ethernet0/0, changed state to up
00:02:15: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0,
changed state to up
Router(config-if)#interface BRI0/0
Router(config-if)#no shutdown
Router(config-if)#
00:02:26: %LINK-3-UPDOWN: Interface BRI0/0:1, changed state to down
00:02:26: %LINK-3-UPDOWN: Interface BRI0/0:2, changed state to down
00:02:26: %LINK-3-UPDOWN: Interface BRI0/0, changed state to up
00:02:115964116991: %ISDN-6-LAYER2UP: Layer 2 for Interface BR0/0,

```

```
TEI 68 changed to up
Router(config-if)#^Z
Router#
00:02:35: %SYS-5-CONFIG_I: Configured from console by console
Router#copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
Router#show version
Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Tue 07-Dec-99 02:21 by phanguye
Image text-base: 0x80008088, data-base: 0x80C524F8
```

```
ROM: System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE (fc1)
```

```
Router uptime is 3 minutes
System returned to ROM by abort at PC 0x802D0B60
System image file is "flash:c2600-is-mz.120-7.T"
```

```
cisco 2611 (MPC860) processor (revision 0x202)
with 26624K/6144K bytes of memory.
Processor board ID JAB031202NK (3878188963)
M860 processor: part number 0, mask 49
Bridging software.
X.25 software, Version 3.0.0.
Basic Rate ISDN software, Version 1.1.
2 Ethernet/IEEE 802.3 interface(s)
2 Serial(sync/async) network interface(s)
1 ISDN Basic Rate interface(s)
32K bytes of non-volatile configuration memory.
8192K bytes of processor board System flash partition 1 (Read/Write)
8192K bytes of processor board System flash partition 2 (Read/Write)
```

```
Configuration register is 0x2142
```

```
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#config-register 0x2102
Router(config)#^Z
00:03:20: %SYS-5-CONFIG_I: Configured from console by console
```

```
Router#show version
Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Tue 07-Dec-99 02:21 by phanguye
Image text-base: 0x80008088, data-base: 0x80C524F8
```

```
ROM: System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE (fc1)
```

```
Router uptime is 3 minutes
System returned to ROM by abort at PC 0x802D0B60
System image file is "flash:c2600-is-mz.120-7.T"
```

```
cisco 2611 (MPC860) processor (revision 0x202)
with 26624K/6144K bytes of memory.
Processor board ID JAB031202NK (3878188963)
M860 processor: part number 0, mask 49
Bridging software.
X.25 software, Version 3.0.0.
Basic Rate ISDN software, Version 1.1.
```

2 Ethernet/IEEE 802.3 interface(s)
2 Serial(sync/async) network interface(s)
1 ISDN Basic Rate interface(s)
32K bytes of non-volatile configuration memory.
8192K bytes of processor board System flash partition 1 (Read/Write)
8192K bytes of processor board System flash partition 2 (Read/Write)

Configuration register is 0x2142 (will be **0x2102** at next reload)

Router#

[Informações Relacionadas](#)

- [Procedimentos de recuperação de senhas](#)
- [Manual de cabeamento para console e portas AUX](#)
- [Conexão de um Terminal à Porta de Console dos Switches Catalyst](#)
- [Conexão de um Terminal aos Catalyst 2948G-L3, 4908G-L3 e 4840G Series Switches](#)
- [Combinações de sequência chave de ruptura padrão durante a recuperação de senha](#)
- [Suporte Técnico - Cisco Systems](#)