

Setting-Up um servidor de NTP em SPA3102

Índice

[Introdução](#)

[Como ajustar o servidor de NTP em SPA3102?](#)

[Informações Relacionadas](#)

[Introdução](#)

Este artigo é um em uma série para auxiliar na instalação, no troubleshooting e na manutenção de produtos Cisco Small Business.

Q. [Como ajustar o servidor de NTP em SPA3102?](#)

A.

Estabelecer um servidor de NTP em SPA3102

Passo 1:

Alcance a página de instalação com base na Web SPA3102. Para instruções, clique [aqui](#).

Passo 2:

Quando a página de instalação com base na Web se publica, clique o **início de uma sessão Admin**.



Passo 3:

Instalação macilento do clique, **avançada** então.

Passo 4:

Sob o **servidor de NTP preliminar**, incorpore o endereço do servidor de NTP no campo fornecido.

LINKSYS[®]
A Division of Cisco Systems, Inc. *Linksys Phone Adapter Configuration*

Click **Wan Setup.** Click **advanced.**

Status **Wan Setup** Lan Setup Application User Login basic | advanced

Internet Connection Settings
Connection Type: DHCP

Static IP Settings
Static IP: NetMask:
Gateway:

PPPoE Settings
PPPOE Login Name: PPPOE Login Password:
PPPOE Service Name:

Optional Settings
HostName: Domain:
Primary DNS: Secondary DNS:
DNS Server Order: Manual Parallel
Primary NTP Server: Enter the **Primary NTP Server** here.

Passo 5:

Clique

[Informações Relacionadas](#)

- [Suporte Técnico e Documentação - Cisco Systems](#)