

适用于所有Cisco 路由器的缓冲调节

目录

[简介](#)

[先决条件](#)

[要求](#)

[使用的组件](#)

[规则](#)

[综述](#)

[低端平台 \(Cisco 1600、2500 及 4000 系列路由器 \)](#)

[高端平台\(路由处理器、交换处理器、硅交换处理器和路由/交换处理器\)](#)

[基于粒子的平台](#)

[缓冲微调](#)

[保留构造缓冲区](#)

[缓冲泄漏](#)

[相关信息](#)

简介

本文档概述了基于当前平台进行缓冲区调节，同时还介绍了有关 show buffers 命令的一般信息。

[先决条件](#)

[要求](#)

本文档没有任何特定的要求。

[使用的组件](#)

本文档不限于特定的软件和硬件版本。

本文档中的信息都是基于特定实验室环境中的设备创建的。本文档中使用的所有设备最初均采用原始（默认）配置。如果您是在真实网络上操作，请确保您在使用任何命令前已经了解其潜在影响。

[规则](#)

有关文档规则的详细信息，请参阅 [Cisco 技术提示规则](#)。

综述

缓冲微调允许您修改在数据流期间，临时突发路由器从其可利用的内存分配缓冲区的方式，并且帮助防止信息包丢弃。

要确定您的路由器是否需要有其被调整的缓冲区，请使用 **show interfaces** 和 **show buffer** 命令。

如果有show interfaces和show buffer命令的输出或者show technical-support的输出(从特权模式)从您的Cisco设备，您能使用[Cisco CLI分析器](#)显示潜在问题和修正。要使用[Cisco CLI分析器](#)，您必须是一个注册的用户，登陆，并且安排Javascript被启用。

下面show interfaces命令输出的示例：

```
Output queue 0/40, 1041 drops; input queue 0/75, 765 drops
35252345 packets input, 547082589 bytes, 940 no buffer
```

- 输入和输出丢弃归结于突发数据流被超出的输入和输出队列。这没有与缓冲问题，然而相当与进程交换性能限制有关。
- 因为没有复制信息包的空闲的缓存"no buffer"表示被丢弃的数据包的编号。

使用show buffers命令，请查看缓冲大小与接口的最大传输单元(MTU)相应：

```
Output queue 0/40, 1041 drops; input queue 0/75, 765 drops
35252345 packets input, 547082589 bytes, 940 no buffer
```

下表说明了该输出：

关键字 说明

总数	池中缓冲区的总数，包括使用和未使用的缓冲区。
永久性	分配的缓冲区的固定数量在池的。这些缓冲区始终位于池中，不会被清理掉。
in free list	是自由的为使用的缓冲区数现在可以得到在池。
分钟	路由器在自由列表应该尝试保留“的最低的缓冲区数”。如果缓冲区数“在自由列表”在" min "值之下池的更多缓冲区。
max allowed	最大缓冲区数在自由列表允许“”。如果缓冲区数“在自由列表”比" max allowed "值极大，路由器应该
命中	从自由列表成功分配缓冲区数。
错过	缓冲区被请求了的次数，但是缓冲区不是可用的在自由列表，或者，当少于“在自由列表的分钟”缓冲
修整	从池修整的缓冲区数，当缓冲区数“在自由列表”超出“最大允许的”缓冲区的数量。
创建	在池被创建了的缓冲区数，当缓冲区数“在自由列表”比“min.”是较少
no memory	路由器尝试新建缓冲区（但由于路由器中可用内存不足而无法创建）的次数。
故障	疏忽的数量授予缓冲区请求方在中断时间下(请切记路由器能创建新的缓冲区在交换的进程平实，memory)。“故障的”数量表示下降的归结于缓冲短缺信息包的数量。

路由器如何处理缓冲区

“in free list”中的缓冲区数即为可用缓冲区数。当缓冲区请求传入时，系统会分配“in free list”中的缓冲区。

使用 IOS 缓冲区的两个主要原因如下：

- 处理在路由器上终止的流量。
- 数据包通过进程进行交换。

如果没有可用的缓冲区，并且启用了快速交换，则存在缓冲失败并会丢弃数据包。当缓冲池管理器进程检测到缓冲失败时，它会“创建”一个新的缓冲区来避免以后出现失败情况。

如果“in free list”中的缓冲区数等于“max allowed”值，路由器不会创建新的缓冲区。如果路由器中的内存不足，无法创建新的缓冲区，则会记录为“no memory”。如果“in free list”中的缓冲区数大于“max allowed”数，则路由器会“trims”其中一些多余的缓冲区。

只需关注“failures”数量和“no memory”这两方面的情况即可。失败也许会发生，但过一会就会趋于稳定。路由器根据需要创建或排除缓冲区，以使失败数趋于稳定。如果失败数继续增加，可能有必要进行缓冲区调节。

如果由于内存不足而无法创建新的缓冲区，请查找是否存在[缓冲区泄漏](#)，或更[常见的内存问题](#)。缓冲区并不是以快速交换方式创建的，因此，如果路由器尝试快速交换数据包，并且没有可用的缓冲区，则数据包会被丢弃，同时会报告失败。在缓冲池管理器下一次运行时，会创建新的缓冲区。

低端平台 (Cisco 1600、2500 及 4000 系列路由器)

快速交换信息包和程序交换信息包共享同样缓冲区。这些缓冲区位于共享内存。共享内存位于在共享RAM (SRAM)的动态RAM (DRAM)在Cisco 1600及2500系列路由器，或者Cisco 4000、4500及4700系列路由器的。

第一条线路**show memory**命令告诉您多少共享内存您有，当前使用多少和其最低的点。当信息包不可能快速交换时，对信息包的一台指示器在进程交换的输入队列插入，但是信息包没有被复制。

这是输出的**show buffers**命令在一个低端平台(Cisco4500)：

```
router# show buffers
```

```
Buffer elements:
```

```
  471 in free list (500 max allowed)
 870696495 hits, 0 misses, 0 created
```

```
Public buffer pools:
```

```
Small buffers, 104 bytes (total 50, permanent 50):
```

```
  49 in free list (20 min, 150 max allowed)
 27301678 hits, 23 misses, 20 trims, 20 created
 0 failures (0 no memory)
```

```
Middle buffers, 600 bytes (total 150, permanent 25):
```

```
 147 in free list (10 min, 150 max allowed)
 61351931 hits, 137912 misses, 51605 trims, 51730 created
 91652 failures (0 no memory)
```

```
Big buffers, 1524 bytes (total 67, permanent 50):
```

```
  67 in free list (5 min, 150 max allowed)
 46293638 hits, 455 misses, 878 trims, 895 created
 0 failures (0 no memory)
```

```
VeryBig buffers, 4520 bytes (total 96, permanent 10):
```

```
  79 in free list (0 min, 100 max allowed)
 11818351 hits, 246 misses, 98 trims, 184 created
 243 failures (0 no memory)
```

```
Large buffers, 5024 bytes (total 10, permanent 0):
```

```
  10 in free list (0 min, 10 max allowed)
 4504003 hits, 873040 misses, 759543 trims, 759553 created
 873040 failures (0 no memory)
```

```
Huge buffers, 18024 bytes (total 0, permanent 0):
```

```
  0 in free list (0 min, 4 max allowed)
 0 hits, 0 misses, 0 trims, 0 created
 0 failures (0 no memory)
```

```
Interface buffer pools:
```

```
TokenRing0 buffers, 4516 bytes (total 48, permanent 48):
```

```
  0 in free list (0 min, 48 max allowed)
 3099742 hits, 9180771 fallbacks
 16 max cache size, 1 in cache
```

```
TokenRing1 buffers, 4516 bytes (total 48, permanent 48):
```

```
0 in free list (0 min, 48 max allowed)
335172 hits, 403668 fallbacks
16 max cache size, 16 in cache
Serial1 buffers, 1524 bytes (total 96, permanent 96):
63 in free list (0 min, 96 max allowed)
33 hits, 0 fallbacks
0 max cache size, 0 in cache
Serial2 buffers, 1524 bytes (total 96, permanent 96):
63 in free list (0 min, 96 max allowed)
701370936 hits, 268 fallbacks
0 max cache size, 0 in cache
Serial3 buffers, 1524 bytes (total 96, permanent 96):
63 in free list (0 min, 96 max allowed)
33 hits, 0 fallbacks
0 max cache size, 0 in cache
Serial0 buffers, 4546 bytes (total 96, permanent 96):
28 in free list (0 min, 96 max allowed)
346854 hits, 5377043 fallbacks
32 max cache size, 27 in cache
```

接口使用接口缓冲池输入-输出(I/O)。当那儿不在接口缓冲区自由列表时的无缓冲区，路由器去公共缓冲池作为退路。没有退路的性能命中率。

缓存是通过绕过若干开销加速缓冲区可用性中断级别驱动程序代码的软件处理。

注意：通常，不应该调整接口缓冲区。

高端平台(路由处理器、交换处理器、硅交换处理器和路由/交换处理器)

下面是高端平台上 **show buffers** 命令的输出：

```
Router# show buffers

Buffer elements:
 498 in free list (500 max allowed)
326504974 hits, 0 misses, 0 created

Public buffer pools:
Small buffers, 104 bytes (total 150, permanent 150):
 140 in free list (30 min, 250 max allowed)
564556247 hits, 148477066 misses, 16239797 trims, 16239797 created
29356200 failures (0 no memory)
Middle buffers, 600 bytes (total 120, permanent 120):
 116 in free list (20 min, 200 max allowed)
319750574 hits, 85689239 misses, 9671164 trims, 9671164 created
26050704 failures (0 no memory)
Big buffers, 1524 bytes (total 100, permanent 100):
 98 in free list (10 min, 300 max allowed)
20130595 hits, 14796572 misses, 251916 trims, 251916 created
11813639 failures (0 no memory)
VeryBig buffers, 4520 bytes (total 15, permanent 15):
 14 in free list (5 min, 300 max allowed)
22966334 hits, 3477687 misses, 13113 trims, 13113 created
2840089 failures (0 no memory)
Large buffers, 5024 bytes (total 12, permanent 12):
 12 in free list (0 min, 30 max allowed)
849034 hits, 1979463 misses, 1028 trims, 1028 created
```

```
1979456 failures (0 no memory)
Huge buffers, 18024 bytes (total 6, permanent 5):
  4 in free list (2 min, 13 max allowed)
  338440 hits, 1693496 misses, 1582 trims, 1583 created
  1640218 failures (0 no memory)
```

标题池

公共缓冲池位于 DRAM，称为“系统缓冲区”。路由/交换处理器 (RSP) 上的共享内存称为“系统数据包内存 (MEMD)”，允许 2 MB 的内存空间。对于路由处理器 (RP) 和交换处理器 (SP) (或硅交换处理器 - SSP)，系统缓冲区位于 RP，MEMD 位于 SP (或 SSP)。

在数据包传入时，它会由接收接口处理器 (通用接口处理器 - VIP 除外) 保存在 MEMD 中。如果数据包无法被快速交换，整个数据包会被复制到 DRAM 的系统缓冲区中。因此，您在 **show buffers** 命令中看到的缓冲区是位于 DRAM 中的系统缓冲区。

show controllers cbus 命令显示 MEMD 中的接口缓冲区。此外，不建议调整接口缓冲区。在某数据包无法被快速交换并且无法复制到系统缓冲区时，该数据包会被丢弃，如果没有可用的系统缓冲区，则会计为一次失败。

基于粒子的平台

Cisco 3600及7200系列路由器使用微粒。接口缓冲区是极小的缓冲区 (称为粒子)，数据包会被拆分到这些缓冲区中。当某数据包无法被快速交换时，路由器必须在一个系统缓冲区中重组该数据包，因为进程交换代码不能处理这些粒子。

下面输出的**show buffers**命令在Cisco3600：

```
Router# show buffers
Buffer elements:
  499 in free list (500 max allowed)
  136440 hits, 0 misses, 0 created

Public buffer pools:
Small buffers, 104 bytes (total 50, permanent 50):
  49 in free list (20 min, 150 max allowed)
  4069435 hits, 141 misses, 73 trims, 73 created
  52 failures (0 no memory)
Middle buffers, 600 bytes (total 25, permanent 25):
  25 in free list (10 min, 150 max allowed)
  628629 hits, 21 misses, 21 trims, 21 created
  3 failures (0 no memory)
Big buffers, 1524 bytes (total 50, permanent 50):
  50 in free list (5 min, 150 max allowed)
  9145 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
VeryBig buffers, 4520 bytes (total 10, permanent 10):
  10 in free list (0 min, 100 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
Large buffers, 5024 bytes (total 0, permanent 0):
  0 in free list (0 min, 10 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
Huge buffers, 18024 bytes (total 0, permanent 0):
  0 in free list (0 min, 4 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
```

Interface buffer pools:

CD2430 I/O buffers, 1524 bytes (total 0, permanent 0):
0 in free list (0 min, 0 max allowed)
0 hits, 0 fallbacks

Header pools:

Header buffers, 0 bytes (total 265, permanent 256):
9 in free list (10 min, 512 max allowed)
253 hits, 3 misses, 0 trims, 9 created
0 failures (0 no memory)
256 max cache size, 256 in cache

Particle Clones:

1024 clones, 0 hits, 0 misses

Public particle pools:

F/S buffers, 256 bytes (total 384, permanent 384):
128 in free list (128 min, 1024 max allowed)
256 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
256 max cache size, 256 in cache

Normal buffers, 1548 bytes (total 512, permanent 512):
356 in free list (128 min, 1024 max allowed)
188 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
128 max cache size, 128 in cache

Private particle pools:

Ethernet0/0 buffers, 1536 bytes (total 96, permanent 96):
0 in free list (0 min, 96 max allowed)
96 hits, 0 fallbacks
96 max cache size, 64 in cache

Serial0/0 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache

BRI0/0 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache

BRI0/0:1 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache

BRI0/0:2 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache

TokenRing0/0 buffers, 1548 bytes (total 64, permanent 64):
0 in free list (0 min, 64 max allowed)
64 hits, 0 fallbacks
64 max cache size, 64 in cache
4 buffer threshold, 0 threshold transitions

专用粒子池由接口使用，不得对其进行调整。当缓冲区不是可用的在自由列表时，路由器落回到公共微粒池。

报头缓冲区用于记录属于信息包的所有微粒列表。

注意：系统缓冲区用于进程交换。在Cisco3600，所有这些缓冲区在位于DRAM的输入输出存储器。使用[memory-size iomem命令](#)，您能指定输入/输出内存容量。在Cisco7200，高带宽端口适配器

的(PA)接口微粒缓冲池位于SRAM。

缓冲微调

下面从show buffers命令的一个示例：

```
Router# show buffers
Buffer elements:
  499 in free list (500 max allowed)
  136440 hits, 0 misses, 0 created

Public buffer pools:
Small buffers, 104 bytes (total 50, permanent 50):
  49 in free list (20 min, 150 max allowed)
  4069435 hits, 141 misses, 73 trims, 73 created
  52 failures (0 no memory)
Middle buffers, 600 bytes (total 25, permanent 25):
  25 in free list (10 min, 150 max allowed)
  628629 hits, 21 misses, 21 trims, 21 created
  3 failures (0 no memory)
Big buffers, 1524 bytes (total 50, permanent 50):
  50 in free list (5 min, 150 max allowed)
  9145 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
VeryBig buffers, 4520 bytes (total 10, permanent 10):
  10 in free list (0 min, 100 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
Large buffers, 5024 bytes (total 0, permanent 0):
  0 in free list (0 min, 10 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
Huge buffers, 18024 bytes (total 0, permanent 0):
  0 in free list (0 min, 4 max allowed)
  0 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)

Interface buffer pools:
CD2430 I/O buffers, 1524 bytes (total 0, permanent 0):
  0 in free list (0 min, 0 max allowed)
  0 hits, 0 fallbacks

Header pools:
Header buffers, 0 bytes (total 265, permanent 256):
  9 in free list (10 min, 512 max allowed)
  253 hits, 3 misses, 0 trims, 9 created
  0 failures (0 no memory)
  256 max cache size, 256 in cache

Particle Clones:
  1024 clones, 0 hits, 0 misses

Public particle pools:
F/S buffers, 256 bytes (total 384, permanent 384):
  128 in free list (128 min, 1024 max allowed)
  256 hits, 0 misses, 0 trims, 0 created
  0 failures (0 no memory)
  256 max cache size, 256 in cache
Normal buffers, 1548 bytes (total 512, permanent 512):
  356 in free list (128 min, 1024 max allowed)
```

```
188 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
128 max cache size, 128 in cache
```

Private particle pools:

```
Ethernet0/0 buffers, 1536 bytes (total 96, permanent 96):
  0 in free list (0 min, 96 max allowed)
  96 hits, 0 fallbacks
  96 max cache size, 64 in cache
Serial0/0 buffers, 1548 bytes (total 14, permanent 14):
  0 in free list (0 min, 14 max allowed)
  14 hits, 0 fallbacks
  14 max cache size, 14 in cache
BRI0/0 buffers, 1548 bytes (total 14, permanent 14):
  0 in free list (0 min, 14 max allowed)
  14 hits, 0 fallbacks
  14 max cache size, 14 in cache
BRI0/0:1 buffers, 1548 bytes (total 14, permanent 14):
  0 in free list (0 min, 14 max allowed)
  14 hits, 0 fallbacks
  14 max cache size, 14 in cache
BRI0/0:2 buffers, 1548 bytes (total 14, permanent 14):
  0 in free list (0 min, 14 max allowed)
  14 hits, 0 fallbacks
  14 max cache size, 14 in cache
TokenRing0/0 buffers, 1548 bytes (total 64, permanent 64):
  0 in free list (0 min, 64 max allowed)
  64 hits, 0 fallbacks
  64 max cache size, 64 in cache
  4 buffer threshold, 0 threshold transitions
```

在本示例中，中间缓冲区出现很多失败。因为它只表示 0.1% 的命中率，所以这不是严重问题。通过一些缓冲区调节工作可以轻松地减少失败数。

仅当数据包无法进行 CEF 交换时，才进行缓冲区调节。

根据路由器的体系结构，您所调节的缓冲区通常属于 I/O 内存（低端）或主内存（高端）。在调节缓冲区之前，通过 **show memory** 命令的前几行首先检查可用 I/O 内存或主内存是否充足。

这是您能使用的一些一般值：

- **永久性**：提取池中缓冲区的总数，并增加约 20% 的缓冲区。
- **min-free**：设置 min-free 到大约 20-30% 分配的缓冲区的固定数量在池的。
- **max-free**：比永久性和最小数量的总和设置 max-free 对事极大。

在上述缓冲区调节示例中，我们可以在全局配置模式中输入如下命令：

```
Router# show buffers
Buffer elements:
  499 in free list (500 max allowed)
  136440 hits, 0 misses, 0 created

Public buffer pools:
Small buffers, 104 bytes (total 50, permanent 50):
  49 in free list (20 min, 150 max allowed)
  4069435 hits, 141 misses, 73 trims, 73 created
  52 failures (0 no memory)
Middle buffers, 600 bytes (total 25, permanent 25):
  25 in free list (10 min, 150 max allowed)
  628629 hits, 21 misses, 21 trims, 21 created
```


3 failures (0 no memory)
Big buffers, 1524 bytes (total 50, permanent 50):
50 in free list (5 min, 150 max allowed)
9145 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
VeryBig buffers, 4520 bytes (total 10, permanent 10):
10 in free list (0 min, 100 max allowed)
0 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
Large buffers, 5024 bytes (total 0, permanent 0):
0 in free list (0 min, 10 max allowed)
0 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
Huge buffers, 18024 bytes (total 0, permanent 0):
0 in free list (0 min, 4 max allowed)
0 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)

Interface buffer pools:
CD2430 I/O buffers, 1524 bytes (total 0, permanent 0):
0 in free list (0 min, 0 max allowed)
0 hits, 0 fallbacks

Header pools:
Header buffers, 0 bytes (total 265, permanent 256):
9 in free list (10 min, 512 max allowed)
253 hits, 3 misses, 0 trims, 9 created
0 failures (0 no memory)
256 max cache size, 256 in cache

Particle Clones:
1024 clones, 0 hits, 0 misses

Public particle pools:
F/S buffers, 256 bytes (total 384, permanent 384):
128 in free list (128 min, 1024 max allowed)
256 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
256 max cache size, 256 in cache
Normal buffers, 1548 bytes (total 512, permanent 512):
356 in free list (128 min, 1024 max allowed)
188 hits, 0 misses, 0 trims, 0 created
0 failures (0 no memory)
128 max cache size, 128 in cache

Private particle pools:
Ethernet0/0 buffers, 1536 bytes (total 96, permanent 96):
0 in free list (0 min, 96 max allowed)
96 hits, 0 fallbacks
96 max cache size, 64 in cache
Serial0/0 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache
BRI0/0 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache
BRI0/0:1 buffers, 1548 bytes (total 14, permanent 14):
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache
BRI0/0:2 buffers, 1548 bytes (total 14, permanent 14):

```
0 in free list (0 min, 14 max allowed)
14 hits, 0 fallbacks
14 max cache size, 14 in cache
TokenRing0/0 buffers, 1548 bytes (total 64, permanent 64):
0 in free list (0 min, 64 max allowed)
64 hits, 0 fallbacks
64 max cache size, 64 in cache
4 buffer threshold, 0 threshold transitions
```

通常，Cisco IOS® 软件会动态创建缓冲区，使这些设置可行。然而，在流量突发的情况下，路由器可能没有足够的时间创建新的缓冲区，并且故障的数量可能继续增加。请使用 **buffers** 命令更改默认缓冲池设置。确保在更改缓冲区值时要格外小心，因为不适当的缓冲区设置可能会影响系统的性能。如果要清除缓冲区计数器，则需要重新加载路由器。

有两流量突发：

- **缓慢突发**：在这种情况下，路由器有充足的时间新建缓冲区。增加min-free缓冲区的数量。通过使用可用缓冲区，可以得到最小可用值，然后新建缓冲区。
- **快速突发**：在快速流量突发的情况下，路由器来不及新建缓冲区，因此您应该使用可用缓存区。为此，请修改永久缓冲区的数量。

结论：如果在最初调整以后的Create计数器增量，增加min-free (缓慢的突发)。如果故障计数器增加，但是不是Create计数器(快速地突发传输)，请增加永久性值。

保留构造缓冲区

您可以输入 **fabric buffer-reserve** 命令来改进系统吞吐量以及保留 ASIC 缓冲区。

下列模块支持此命令：

- WS-X6704-10GE
- WS-X6748-SFP
- WS-X6748-GE-TX
- WS-X6724-SFP

配置有 Supervisor 引擎 32 的 Cisco 7600 系列路由器不支持此命令。

```
fabric buffer-reserve [high | low | medium | value]
```

警告：仅在 Cisco TAC 指导下使用此命令。

此命令在以下常见情况下非常有用：

- 线路协议对于多个接口失效
- 在多个接口上看到超出限度
- 端口频繁地退出并加入 EtherChannel
- TestMacNotification 测试因线路卡上的 DFC 频繁失败

缓冲泄漏

下面输出的示例的**show buffers**命令：

```
fabric buffer-reserve [high | low | medium | value]
```

此输出指示大缓冲池中的缓冲区泄漏。路由器中共有 1556 个大缓冲区，其中只有 52 个在可用列表中。某些内容占用了所有缓冲区，并且没有释放这些缓冲区。有关缓冲区泄漏的详细信息，请参阅[排除缓冲区泄漏故障](#)。

相关信息

- [排除存储器问题故障](#)
- [排除缓冲泄漏故障](#)
- [基本的系统管理命令](#)
- [修改系统缓冲区大小](#)
- [技术支持 - Cisco Systems](#)