

# 目录

[简介](#)

[开始使用前](#)

[规则](#)

[先决条件](#)

[使用的组件](#)

[升级 Cisco IOS 软件镜像](#)

[相关信息](#)

## 简介

本文包含升级您的Cisco NI-2 DSLAM一个逐步程序。必须在 TCP/IP 就绪工作站上安装 TFTP 服务器或远程复制协议 (RCP) 服务器应用。一旦安装了应用程序，则必须执行最低配置。首先，TFTP应用程序必须配置成TFTP服务器，而不是用作TFTP客户端。其次，必须指定出站文件目录。这是将在其中存储 Cisco IOS 软件映像的目录。大多数 TFTP 应用会提供一个帮助执行这些配置任务的设置例程。

## 开始使用前

### 规则

有关文档规则的详细信息，请参阅 [Cisco 技术提示规则](#)。

### 先决条件

本文档没有任何特定的前提条件。

### 使用的组件

本文档不限于特定的软件和硬件版本。

## 升级 Cisco IOS 软件镜像

使用以下步骤升级Cisco IOS软件镜像。

1. 在 TFTP 服务器的出站目录中安装新的 Cisco IOS 软件镜像。TFTP server寻找在此目录的 DSLAM的Cisco IOS软件镜像。确保您想复制到您的闪存的镜像位于此目录中。每镜像的内存要求也在TFTP server的出局目录。使用 **show version** 命令，确认您有足够的内存。

```
DSLAM#show versionCisco Internetwork Operating System SoftwareIOS (tm) NI2 Software (NI2-DSL-M), Version 12.1(5)DA, EARLY DEPLOYMENT RELEASE SOFTWARE (fc2)Copyright (c) 1986-2000 by cisco Systems, Inc.Compiled Thu 07-Dec-00 19:27 by pnicosiaImage text-base: 0x800082C0, data-base: 0x811EA000ROM: System Bootstrap, Version 12.0(5)DA, EARLY DEPLOYMENT RELEASE SOFTWARE (fc1)BOOTFLASH: NI2 Software (NI2-DBOOT-M), Version 12.1(3)DA, EARLY DEPLOYMENT RELEASE SOFTWARE (fc1)6130A uptime is 1 day, 18 hours, 19 minutesSystem returned to ROM by
```





