

目录

[简介](#)

[先决条件](#)

[要求](#)

[使用的组件](#)

[规则](#)

[安装Aironet的DOS驱动](#)

[相关信息](#)

简介

本文解释如何安装在Microsoft DOS (MS-DOS)的Cisco Aironet驱动程序-基于笔记本电脑。

先决条件

要求

Cisco 建议您了解以下主题：

- 无线局域网(WLAN)技术和期限
- 个人计算机硬件主题
- MS-DOS配置命令

使用的组件

本文档中的信息基于以下软件和硬件版本：

- Aironet PCM 3xx或LMC 3xx客户端适配器
- MS-DOS 6.22
- DOS版本6.22的Aironet驱动程序

规则

有关文档规则的详细信息，请参阅 [Cisco 技术提示规则](#)。

安装Aironet的DOS驱动

完成这些步骤为了安装DOS驱动：

1. 这样创建**config.sys**文件：IBMDSS14.SYS、IBMDOSCS.SYS和DICRMU01.SYS文件是PCMCIA卡，并且示例的插槽服务模拟IBM笔记本电脑。从笔记本电脑制造商的替代适当的文件如适当。

2. 定制包括的cscpkt.ini文件对各自的需要：[CSCPkt] ;Initialization file for Infrastructure operating mode ; NOTE: The following are some keyword parameters that may ;be modified. Any commented or omitted keyword parameter ;assumes the factory default. For most situations the ;factory defaults will be appropriate. In situations where ;the factory default needs to be modified, uncomment or add the ;keyword parameter line and set the appropriate keyword value. **SSID="network_ssid"** ;Must match Access Point setting ;FragThreshold=2312 ;Packet size to start fragmenting ;RTSThreshold=2312 ;Packet size to start sending RTS/CTS ;DataRate1=0x02 ;(1) Mbps supported data bit rate ;DataRate2=0x04 ;(2) Mbps supported data bit rate ;DataRate3=0x0B ;(5.5) Mbps supported data bit rate ;DataRate4=0x16 ;(11) Mbps supported data bit rate ;RefreshInterval=10000 ;Inactivity time to check association ;PowerSaveMode="CAM" ;Constant Awake Mode ;MaxPowerSave="OFF" ;Maximum power save mode **NodeName="CiscoPC"** ;Descriptive station name **AuthType="WEPOPEN"** ;WEP with open authentication ;The adapter needs 32 16-bit I/O ports, and 1 non-sharable IRQ. ;The following lines should be uncommented and the appropriate ;values set in the following scenarios: ; 1) PCMCIA mode: Override the I/O port base and/or IRQ assigned by PCMCIA card services. ; 2) PCMCIA mode: PCMCIA card services is not being used. ; 3) ISA mode: Override the I/O port base and/or IRQ assigned ; by Plug and Play. ; 4) ISA mode: Non-Plug and Play operation. ;PortBase=0x140 ;IRQ=5 ;If the PCMCIA interface is being used without PCMCIA card services, ;uncomment the following lines and set the appropriate values. **Memory=0xD000** **Socket=0** ;If the PCMCIA interface is not being used, set the appropriate ;value of "ISA" or "PCI". **BusType="PCMCIA"**

3. 启动计算机装载上述config.sys文件。

4. 发出以下命令：a:>wepdos -365 -tx1 12345678901234567890123456a:>wepdos -365 -tx1 12345678901234567890123456

5. 发出以下命令：a:>cscpkt 0x65a:>cscpkt 0x65

相关信息

- [Cisco Aironet无线局域网客户端适配器配置指南](#)
- [Cisco无线产品](#)
- [Cisco Aironet Windows 客户端常见问题](#)
- [技术支持和文档 - Cisco Systems](#)