



Send documentation comments to mdsfeedback-doc@cisco.com.

CHAPTER 15

Q Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See the “Command Modes” section to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family Configuration Guide*.

- [qos control priority, page 15-2](#)

Send documentation comments to mdsfeedback-doc@cisco.com.

qos control priority

To enable the QoS priority assignment for control traffic feature on the Cisco MDS 9000 family of switches, use the **qos control** command in configuration mode. To disable the QoS priority assignment for control traffic feature, use the **no** form of the command.

qos control priority *value*

no qos control *value*

Syntax	Description
qos control	Controls QoS traffic from one fabric controller to another.
priority	Sets the priority level.
<i>value</i>	Specifies priority value ranging from 0 to 7.

Defaults Enabled and priority 7 are the defaults.

Command Modes Configuration mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example disables the QoS priority assignment feature.

```
switch# config t
switch(config)# no qos control priority
```

Related Commands	Command	Description
	show qos internal	Displays internal debug information.
	show qos statistics	Displays QoS related statistics.